

# High Power Programmable DC Power Supply

## IT-M3900D Series User Manual



Model: IT-M3900D Series Version: V2.5/12,2024



## **Notices**

© Itech Electronic, Co., Ltd. 2024

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior permission and written consent from Itech Electronic, Co., Ltd. as governed by international copyright laws.

#### **Manual Part Number**



#### **Trademarks**

Pentium is U.S. registered trademarks of Intel Corporation.
Microsoft, Visual Studio, Windows and MS Windows are registered trademarks of Microsoft Corporation in the United States and/or other countries and regions.

#### Warranty

The materials contained in this document are provided "as is", and is subject to change, without prior notice, in future editions. Further, to the maximum extent permitted by applicable laws, ITECH disclaims all warrants, either express or implied, with regard to this manual and any information contained herein, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. ITECH shall not be held liable for errors or for incidental or indirect damages in connection with the furnishing, use or application of this document or of any information contained herein. Should ITECH and the user enter into a separate written agreement with warranty terms covering the materials in this document that conflict with these terms, the warranty terms in the separate agreement shall prevail.

#### **Technology Licenses**

The hardware and/or software described herein are furnished under a license and may be used or copied only in accordance with the terms of such license.

#### Restricted Rights Legend

Restricted permissions of the U.S. government. Permissions for software and technical data which are authorized to the U.S. Government only include those for custom provision to end users. ITECH follows FAR 12.211 (technical data), 12.212 (computer software). DFARS 252.227-7015 (technical data—commercial products) and DFARS 227.7202-3 (permissions for commercial computer software or computer software documents) while providing the customized business licenses of software and technical data.

#### **Safety Notices**

#### CAUTION

A CAUTION sign denotes a hazard. It calls attention to an operating procedure or practice that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a CAUTION sign until the indicated conditions are fully understood and met.

#### WARNING

A WARNING sign denotes a hazard. It calls attention to an operating procedure or practice that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a WARNING sign until the indicated conditions are fully understood and met.



A NOTE sign denotes important hint. It calls attention to tips or supplementary information that is essential for users to refer to.



## **Quality Certification and Assurance**

We certify that series instrument meets all the published specifications at time of shipment from the factory.

## Warranty

ITECH warrants that the product will be free from defects in material and workmanship under normal use for a period of one (1) year from the date of delivery (except those described in the Limitation of Warranty below).



Visit https://www.itechate.com/en/support/register.html to complete product registration by filling out the necessary information to extend the warranty to two (2) years.

For warranty service or repair, the product must be returned to a service center designated by ITECH.

- The product returned to ITECH for warranty service must be shipped PRE-PAID. And ITECH will pay for return of the product to customer.
- If the product is returned to ITECH for warranty service from overseas, all the freights, duties and other taxes shall be on the account of customer.

## **Limitation of Warranty**

This Warranty will be rendered invalid in case of the following:

- Damage caused by circuit installed by customer or using customer own products or accessories;
- Modified or repaired by customer without authorization;
- Damage caused by circuit installed by customer or not operating our products under designated environment;
- The product model or serial number is altered, deleted, removed or made illegible by customer;
- Damaged as a result of accidents, including but not limited to lightning, moisture, fire, improper use or negligence.



## **Safety Symbols**

	Direct current		ON ( power)
$\sim$	Alternating current	0	OFF ( power)
$\overline{}$	Both direct and alternating current	Ф	Power-on state
	Chassis (earth ground) symbol.	Д	Power-off state
<del>-</del>	Earth ( ground) terminal	土	Reference terminal
	Caution, risk of electric shock	+	Positive terminal
<u> </u>	Warning ( refer to this manual for specific Warning or Caution information)		Negative terminal
	Caution, hot surface	777	A chassis terminal
0 to 40 °C 32 to 104 °F	Working temper- ature of the machine.	-	-

## **Safety Precautions**

The following safety precautions must be observed during all phases of operation of this instrument. Failure to comply with these precautions or specific warnings elsewhere in this manual will constitute a default under safety standards of design, manufacture and intended use of the instrument. ITECH assumes no liability for the customer's failure to comply with these precautions.



#### WARNING

- Do not use the instrument if it is damaged. Before operation, check the casing to see whether it cracks. Do not operate the instrument in the presence of inflammable gasses, vapors or dusts.
- The instrument is provided with a power cord during delivery and should be connected to a socket with a protective earth terminal, a junction box or a three-phase distribution box. Before operation, be sure that the instrument is well grounded.
- Please always use the provided cable to connect the instrument.
- Check all marks on the instrument before connecting the instrument to power supply.
- Ensure the voltage fluctuation of mains supply is less than 10% of the working voltage range in order to reduce risks of fire and electric shock.
- Do not install alternative parts on the instrument or perform any unauthorized modification.
- Do not use the instrument if the detachable cover is removed or loosen.
- To prevent the possibility of accidental injuries, be sure to use the power adapter supplied by the manufacturer only.
- We do not accept responsibility for any direct or indirect financial damage or loss of profit that might occur when using the instrument.
- This instrument is used for industrial purposes, do not apply this product to IT power supply system.
- Never use the instrument with a life-support system or any other equipment subject to safety requirements.



#### WARNING

- SHOCK HAZARD Ground the Instrument. This product is provided
  with a protective earth terminal. To minimize shock hazard, the instrument must be connected to the AC mains through a grounded
  power cable, with the ground wire firmly connected to an electrical
  ground (safety ground) at the power outlet or distribution box. Any
  interruption of the protective (grounding) conductor or disconnection of the protective earth terminal will cause a potential shock
  hazard that could result in injury or death.
- Before applying power, verify that all safety precautions are taken.
   All connections must be made with the instrument turned off, and must be performed by qualified personnel who are aware of the hazards involved. Improper actions can cause fatal injury as well as equipment damage.
- SHOCK HAZARD, LETHAL VOLTAGES This product can output the dangerous voltage that can cause personal injury, and the operator must always be protected from electric shock. Ensure that the output electrodes are either insulated or covered using the safety covers provided, so that no accidental contact with lethal voltages can occur.
- Never touch cables or connections immediately after turning off the instrument. Verify that there is no dangerous voltage on the electrodes or sense terminals before touching them.
- After using the device, turn off the power switch of the device before unplugging the power cord or disassembling the terminals. Do not touch the cable or the terminal immediately. Depending on the model, the dangerous voltage at the plug or terminal is maintained for 10 seconds after the device is switched off. Make sure that there is no dangerous voltage before touching them.

#### CAUTION

- Failure to use the instrument as directed by the manufacturer may render its protective features void.
- Always clean the casing with a dry cloth. Do not clean the internals.
- Make sure the vent hole is always unblocked.

### **Environmental Conditions**

The instrument is designed for indoor use and an area with low condensation. The table below shows the general environmental requirements for the instrument.



<b>Environmental Conditions</b>	Requirements
Operating temperature	0°C ~ 40°C
Operating humidity	20% ~ 80%( non-condensation)
Storage temperature	-10°C ~ 70 °C
Altitude	Operating up to 2,000 meters
Installation category	II
Pollution degree	Pollution degree 2



In order to ensure the accuracy of measurement, it is recommended to operate the instrument half an hour after start-up.

## **Regulation Tag**

CE	The CE tag shows that the product complies with the provisions of all relevant European laws (if the year is shown, it indicates that the year when the design is approved).
UK	The UKCA tag shows that the product complies with the provisions of all relevant United Kingdom laws (if the year is shown, it indicates that the year when the design is approved).
C US 261694	The CSA mark is a registered trademark of the Canadian Standards Association.



	This instrument complies with the WEEE directive (2002/96/EC) tag requirements. This attached product tag shows that the electrical/electronic product cannot be discarded in household waste.
10	This symbol indicates that no danger will happen or toxic substances will not leak or cause damage in normal use within the specified period. The service life of the product is 10 years. The product can be used safely within the environmental protection period; otherwise, the product should be put into the recycling system.

## Waste Electrical and Electronic Equipment (WEEE) Directive



Waste electrical and electronic equipment (WEEE) directive, 2002/96/EC
The product complies with tag requirements of the WEEE directive
(2002/96/EC). This tag indicates that the electronic equipment cannot be disposed of as ordinary household waste. Product Category
According to the equipment classification in Annex I of the WEEE directive, this instrument belongs to the "Monitoring" product.

If you want to return the unnecessary instrument, please contact the near-

est sales office of ITECH.



# CE Compliance Information

Complies with the essential requirements of the following applicable European Directives, and carries the CE marking accordingly:

- Electromagnetic Compatibility (EMC) Directive 2014/30/EU
- Low-Voltage Directive (Safety) 2014/35/EU

Conforms with the following product standards:

#### **EMC Standard**

IEC 61326-1 / EN 61326-1 123

Reference Standards

CISPR 11, Class A

IEC 61000-3-2

IEC 61000-3-3

IEC 61000-4-2

IEC 61000-4-3

IEC 61000-4-4

IEC 61000-4-5

IEC 61000-4-6

IEC 61000-4-11

- 1. The product is intended for use in non-residential/non-domestic environments. Use of the product in residential/domestic environments may cause electromagnetic interference.
- 2. Connection of the instrument to a test object may produce radiations beyond the specified limit
- 3. Use high-performance shielded interface cable to ensure conformity with the EMC standards listed above.

#### **Safety Standard**

IEC 61010-1:2010+A1:2016



This section provides general and universal terms. For more detailed information on the *Declaration of Conformity*, please contact ITECH personnel.



#### Content

	Quality Certification and Assurance	
	Warranty	<u>!</u>
	Limitation of Warranty	
	Safety Symbols	
	Safety Precautions	
	Environmental Conditions	IV
	Regulation Tag	V
	Waste Electrical and Electronic Equipment (WEEE) Directive	VI
	Compliance Information  Quick Reference  1.1 Brief Introduction	VII
1	Quick Reference	1
	1.1 Brief Introduction	1
	1.2 Front-Panel Overview	
	1.3 Keyboard Introduction	
	1.4 Push-on Knob	
	1.5 Rear Panel Introduction	
	1.6 VFD Indicator Lamps Description	
	1.7 Configuration Menu Function	
	1.8 System Menu Function	
	1.9 Options Introduction	
2	Inspection and Installation	
_	2.1 Verifying the Shipment	
	2.2 Instrument Size Introduction	
	2.3 Connecting the Power Cord	
	2.4 Connecting the Device Under Test (DUT)	
	2.5 Remote Interface Connection	20 27
	2.5.1 USB Interface	
	2.5.2 LAN Interface	
	2.5.3 CAN Interface	
	2.5.4 GPIB Interface (Optional)	
	2.5.5 RS–232 Interface (Optional)	
	2.5.6 EtherCAT Interface (Optional)	
3	Getting Started	
0	3.1 Power-on Self-Test	
	3.2 Set Output Value	
	3.3 Use the Front Panel Menu.	
	3.4 On/Off Control	
4	Power Supply Function	
_	4.1 Set the Output Voltage	
	4.2 Set the Output Current	
	4.3 Set the Output Power	
	4.4 Config Menu for Power Supply	
	4.4.1 Set the CC/CV Priority Mode	
	4.4.2 Set the Internal Resistance	
	4.4.3 Set the Output-On/Output-Off Delay	
	4.5 Protection Function for Power Supply	
	4.5.1 Set Over-Voltage Protection (OVP)	
	4.5.2 Set Over-Current Protection (OCP)	
	4.5.3 Set Over-Power Protection (OPP)	
	4.5.4 Set Under-Current Protection (UCP)	
	4.5.5 Set Under-Voltage Protection (UVP)	
	4.5.6 Over-Temperature Protection (OTP)	
	4.5.7 Sense Reverse Protection	ວ/



	4.6 Function Menu for Power Supply	. 57
	4.6.1 LIST Function	. 57
	4.6.2 Battery Charging Test Function	
5	Basic Operation	. 67
	5.1 Local/Remote Mode Switch	
	5.2 Key Lock Function	
	5.3 Save and Recall Operations	. 68
	5.3.1 Save Operation	. 68
	5.3.2 Recall Operation	69
	5.4 Data Logging Function	69
	5.5 Set the Beeper Status (Beep)	. 72
	5.6 Set the Power-on State (PowerOn)	. 73
	5.7 Sense Function (Sense)	. 74
	5.8 Select Trigger Source (Trig Source)	. 75
	5.9 Set the Communication Information (I/O Con)	. 76
	5.10 Set Parallel Operation Mode (Parallel)	
	5.11 Digital I/O Function (Digital Port)	
	5.11.1 IO–1. Ps-Clear, Not-Invert	
	5.11.2 IO–2. Ps, Not-Invert	
	5.11.3 IO-3. Off-Status, Not-Invert	
	5.11.4 IO–4.Trig(in), Not-Invert	
	5.11.5 IO–5. INH-Living, Not-Invert	
	5.11.6 IO–6. Sync-On, Not-Invert	
	5.11.7 IO–7. Sync-Off, Not-Invert	
	5.12 Analogue Function (Ext-Program) (Optional)	99
	5.13 View the System Information (System Info)	104
	5.14 Restored to Factory Setting (System Reset)	
	5.15 System Upgrade	
6	Technical Specification	
•	6.1 Main Specification	
	6.1.1 IT-M3901D-10-170	112
	6.1.2 IT-M3903D-10-340	114
	6.1.3 IT-M3905D-10-510	116
	6.1.4 IT-M3910D-10-1020	110
	6.1.5 IT-M3902D-32-80	
	6.1.6 IT-M3904D-32-160	121
	6.1.7 IT-M3906D-32-240	
	6.1.8 IT-M3912D-32-480	
	6.1.9 IT-M3902D-80-40	
	6.1.10 IT-M3904D-80-80	
	6.1.11 IT-M3906D-80-120	
	6.1.12 IT-M3912D-80-240	
	6.1.13 IT-M3902D-300-20	
	6.1.13 IT-M3904D-300-20	
	6.1.15 IT-M3906D-300-60	
	6.1.16 IT-M3912D-300-120	
	6.1.17 IT-M3902D-500-12	
	6.1.18 IT-M3904D-500-24	
	6.1.19 IT-M3906D-500-36	
	6.1.20 IT-M3912D-500-72	
	6.1.21 IT-M3902D-800-8	
	6.1.22 IT-M3904D-800-16	
	6.1.23 IT-M3906D-800-24	
	6.1.24 IT-M3912D-800-48	
	6.1.25 IT-M3906D-1500-12	
	6.1.26 IT-M3912D-1500-24	
,	6.27 Supplemental Characteristics	
7	Routine Maintenance	1 / K



	7.1	Instrument Self-Test	178
	7.2	Cleaning and Maintenance	178
		Contact of ITECH Engineers	
		Return for Repair	
Α		ndix	
		Specifications of Red and Black Test Cables	
		Troubleshooting	
		Fuse Replacement	



## 1 Quick Reference

This Chapter will introduce power-on check steps of this series to ensure normal start-up and usage under initialization status of the power. Besides, to facilitate usage, this part also displays the functions of front board, rear board and keyboard keys as well as display functions to a quick view of power appearance, structure and key usage functions before operation.

- Brief Introduction
- ◆ Front-Panel Overview
- ♦ Keyboard Introduction
- ♦ Push-on Knob
- ◆ Rear Panel Introduction
- ♦ VFD Indicator Lamps Description
- ◆ Configuration Menu Function
- ◆ System Menu Function
- Options Introduction

## 1.1 Brief Introduction

IT-M3900 series integrates the features of a DC power supply, a bi-directional power supply, a source and load system, and a regenerative electronic load in one. It keeps the advantages of high power density and architecture design of M series, power up to 6kw, current up to 510A, and voltage up to 1500V within one 1U unit, effectively reducing the equipment occupation space and cabinet time. wide-range models could meet different test requirements while matching with multi-functional, high energy-saving, high-safety, and high-stability product design, let the customer be confident to face a variety of complex testing, improving the products competition ability.

The IT-M3900D series is a single channel output programmable DC power supply. The density structure design can effectively save rack space. Also with wide-range output design, can provide a wider range of voltage and current combinations within the specified power range. One unit can be used as multiple power supplies, more flexibility. The CC/CV priority allows user to switch the output mode according to the different needs of the DUT priority, match with the high-precision and high-speed product characteristics, and a variety of standard communication interfaces, simplifying and speeding up the test development, can meet users' variety testing application, widely used in laboratories, production lines, and automatic test systems.

#### **FEATURE**



Compact design , power up to 6kW in 1U space, power up to12kW in 2U space

• Voltage range: 10-1500V

Current range:8A~1020A

Power range:1700W~12kW

- Wide range of output design, one unit can be used as multiple power supplies
- Master/slave parallel connection, keep good performance while power extension
- CC/CV priority
- Adjustable output impedance
- Built-in function generator, support arbitrary-waveform generating
- List function, up to 200 steps can be set
- Support multiple working modes, adjustable rise and fall time The front panel supports the insertion of USB storage devices to meet the import of List files/ Export, data logging functions, etc.
- Standard build-in USB/CAN/LAN/digital IO communication interface, optional GPIB/analog & RS232

Voltage Level	Model	Current	Power	Height
	IT-M3901D-10-170	170A	1.7kW	1U
40)/	IT-M3903D-10-340	340A	3.4kW	1U
10V	IT-M3905D-10-510	510A	5.1kW	1U
	IT-M3910D-10-1020	1020A	10.2kW	2U
	IT-M3902D-32-80	80A	2kW	1U
	IT-M3904D-32-160	160A	4kW	1U
32V	IT-M3906D-32-240	240A	6kW	1U
	IT-M3912D-32-480	480A	12kW	2U
	IT-M3902D-80-40	40A	2kW	1U
00)/	IT-M3904D-80-80	80A	4kW	1U
80V	IT-M3906D-80-120	120A	6kW	1U
	IT-M3912D-80-240	240A	12kW	2U
300V	IT-M3902D-300-20	20A	2kW	1U



Voltage Level	Model	Current	Power	Height
	IT-M3904D-300-40	40A	4kW	1U
	IT-M3906D-300-60	60A	6kW	1U
	IT-M3912D-300-120	120A	12kW	2U
	IT-M3902D-500-12	12A	2kW	1U
500) (	IT-M3904D-500-24	24A	4kW	1U
500V	IT-M3906D-500-36	36A	6kW	1U
	IT-M3912D-500-72	72A	12kW	2U
	IT-M3902D-800-8	8A	2kW	1U
2001	IT-M3904D-800-16	16A	4kW	1U
800V	IT-M3906D-800-24	24A	6kW	1U
	IT-M3912D-800-48	48A	12kW	2U
4500)/	IT-M3906D-1500-12	12A	6kW	1U
1500V	IT-M3912D-1500-24	24A	12kW	2U

## ∭Note


- Naming rules for each series of model are as follows: IT-M39XXD-YYY-ZZZ, wherein, XX means rated power; YYY means rated voltage; and ZZZ means rated current.
- The above model is permanently connected, Equipment Class I, Pollution Degree 2, Installation Category II.
- Mode of operation: Continuous.

## 1.2 Front-Panel Overview

The front panel of this series of instruments is shown in the figure below.



#### 1U Model




- 1 Power On/Off switch
- 2 USB storage device connec-

tion port

- 3 Vacuum fluorescent display (VFD)
- 4 Function and composite keys
- 5 Numeric and composite keys
- 6 Push-on knob
- 7 Left, and right cursor navigation keys

#### **2U Model**




- 1 Power On/Off switch
- 2 USB storage device connection port
- 3 Vacuum fluorescent display (VFD)
- 4 Function and composite keys
- 5 Numeric and composite keys
- 6 Up, down, left, and right cursor navigation keys and Enter key
- 7 Push-on knob

## 1.3 Keyboard Introduction

The keyboard introduction of this series instrument is shown as follows.



#### 1U Model



#### **2U Model**



Keys	Description	
[Shift]	Composite key, combined with other keys to realize functions marked above keys.	
[On/Off]	Turn the power supply output on or off. When lit, indicates that the output is enabled or on.	
[V-set]	Note  In CV priority (default) mode, press [V-set], the interface displays "Vset=0.00V" (Setting value of voltage). In CC priority mode, press [V-set], the interface displays "Vlim=0.00V" (Upper limit of voltage), the lower limit of the voltage is 0.	
[I-set]	Set the output current value	



Keys	Description
	Note
	In CV priority (default) mode, press [I-set], the interface displays "Ilim=0.00A" (Upper limit of current), the lower limit of the current is 0. In CC priority mode, press [I-set], the interface displays "Iset=0.00A" (Setting value of current).
[P-set]	Set the output power value
	Note  Press [P-set], the interface displays "Plim=0.00W"  (Upper limit of power), the lower limit of the power is 0.
[Recall]	Returns the instrument to the specified setup.
[Enter]	Operation confirmation key
[Esc]	Press this key to exit the current operation interface.
[0]-[9]	Numeric keys
+/-	Positive and negative signs
	Decimal point
Left / Right navigation keys	The left and right navigation keys are used to adjust the cursor to the specified position or scrolls pages to view menu items.

Composite key [Shift], combined with other keys to realize functions marked above keys. The detailed functions are listed as follows.



The **[Shift]+[XXX]**(YYY) combination key form identified in this document refers to pressing **[Shift]** button first, then press the **[XXX]** button, please pay attention to the sequence.

Keys	Description
[Shift]+[Protect] (Short)	Short circuit function key
[Shift]+[On/Off] (Trigger)	Generate a local trigger signal.



Keys	Description
[Shift]+[V-set] (Config)	Enter to Configuration menu.
[Shift]+[I-set] (Function)	Enter the <b>Function</b> menu.
[Shift]+[P-set] (System)	Enter the <b>System</b> menu.
[Shift]+[Recall] (Save)	Save the common parameter settings.
[Shift]+[1] (Log)	Enter the data logging function menu.
[Shift]+[2] (Lock)	Turn the keyboard lock on or off.
[Shift]+[3] (Local)	Switch remote control mode to local control mode.

## 1.4 Push-on Knob

This series High power Programmable DC Power Supply provides a knob on the front panel as shown in the next figure.



The functions of the posh-on knob is described as follows.

- Adjust the value setting
- Select menu item
- Confirm the set value or the selected menu item

#### **Adjust the Value Setting**

In the value setting interface, rotate the knob clockwise to increase the set value and anticlockwise to decrease the set value.

#### **Select Menu Item**

The knob can also be used to view menu items. In the menu item display interface, turning the knob clockwise indicates that the next menu item is selected,



and turning the knob anticlockwise indicates that the previous menu item is selected.


#### **Confirm settings**

After completing the value setting or selecting a menu item, pushing the knob acts like pressing **[Enter]** key to confirm the operation.


### 1.5 Rear Panel Introduction

The rear panel of the of the this series model (after removing the protective cover) is shown below.

#### 1U Models



#### 2U Models



- 1. Sense terminals (Vs+, Vs-)
- 2. DC output terminals of the power supply
- 3. Interface for optional accessories IT-E176 and IT-E177 (For details, see 1.9 Options Introduction)
- 4. Digital I/O interface: P-IO
- 5. LAN communication interface
- 6. CAN communication interface
- 7. USB communication interface
- 8. Communication interface of outer ring optical fiber (TX and RX)



This interface is used for the parallel connection between the units for the communication of units in parallel.

9. AC power input terminals (L1, L2, L3, and PE)



## 1.6 VFD Indicator Lamps Description

This series instrument VFD indicator lamps description is as follows:

Table 1–1 VFD Indicator Lamps Description

Flag	Function Description	Flag	Function Description
OFF	The output of the power supply is turned off.	Sense	Sense function of the power supply is enabled.
cv	The power supply is in a state of constant voltage output.	Rear	Analog function begin to work.
CC	The power supply is in a state of constant current output.	Addr	When received command successfully, the flag will display 3 seconds.
*	The keyboard lock is turned on.	Rmt	Indicates that the instrument is working in remote control mode.
CR	None	Error	Error occur
Shift	Using composite function key	Prot	The instrument enters the protection state.
SRQ	Indicates that the internal status request event occurs.	Trig	The instrument is in a state of waiting for a trigger.
CW	The power supply is in a state of constant power output.	Auto	When the data logging function is enabled, the 'Auto' character is displayed. When the data logging function is running, the 'Auto' character blinks.



## 1.7 Configuration Menu Function

This section gives an overview of the configuration menu of the this series instrument.

The procedures to operate the configuration menu are as follows.

 Press the composite keys [Shift]+[V-set] (Config) on the front panel to enter the configuration menu.

The VFD shows configuration menu items and each menu item is marked with a number. The user can use knob to scroll pages to view the other menu items.

2. Press [Enter] to select the desired menu item.

Enter the parameter setting interface of this menu item.

3. After finishing the menu setting, press [Enter] key to save the setting.



Press [Esc] key to return to the previous menu level.

The descriptions of configuration menu of the power supply are listed in the table below.

Config	Configuration menu of the power supply				
	Mode	CC/CV priority mode setting			
		CV	CV Constant voltage loop priority n		
			Speed= High/Low	Loop response speed setting: high speed / low speed	
		CC Constant current loop pr		oriority mode	
			Speed= High/Low	Loop response speed setting: high speed / low speed	
	V-Rise Time/I-Rise Time = 0.001s		Displays the voltage or current rise time setting according to the selected priority mode. If CC priority mode is selected, the parameter setting of <b>I-Rise Time</b> will be displayed here.		



V-Fall Time/I-Fall Time = 0.001s	Displays the voltage or current fall time setting according to the selected priority mode. If CC priority mode is selected, the parameter setting of <b>I-Fall Time</b> will be displayed here.
Output Res	Set the internal resistance of the power supply. This parameter needs to be set only when <b>Mode</b> is set to <b>CV</b> .
On Delay	Set the delay time to turn on the output.
Off Delay	Set the delay time to turn off the output.
Voltage Max	Set the upper limit of the voltage (default is the rated voltage of the instrument). Once the voltage upper limit is modified here, the parameters related to the voltage setting will be limited by the upper limit here.

## 1.8 System Menu Function

This Chapter offers a general introduction of system menus, allowing users to have a preliminary understanding of system functions of this series instrument.

The steps of the system menu function are as follows:

1. Press the composite keys [Shift]+[P-set] (System) on the front panel to enter the system menu.

At this point, the VFD screen displays the system menu items. Each menu item has a numbering identifier. The user can use the knob for scrolling display of other menu items.

- 2. Press [Enter] on a menu interface to enter the setting interface.
- 3. After the menu items are set, press **[Enter]** again to save the modified contents.



You can press [Esc] to return to the previous menu.

The description of the menu items is shown in the table below.



Веер	Set the beeper state.			
	On	Turn the beeper on.		
	Off	Turn the beeper off.		
PowerOn	Set the power-o	on state.		
	Reset	When the instrument is powered on, the instrument will tialize some settings and <b>[On/Off]</b> state.		
	Last		strument is powered on, the instrument will re- ne settings and <b>[On/Off]</b> state as last time you e instrument.	
	Last+Off	main the san	strument is powered on, the instrument will re- ne settings as last time you turned off the in- t the <b>[On/Off]</b> is OFF state.	
Sense	Set the sense fu	ınction state.		
	Off	Turn the sen	se function off.	
	On	Turn the sen	se function on.	
ListTrig Source	Set the trigger n	nethod for the	List files running.	
	Immediate	Trigger imme	ediately	
	Manual	Manual trigg	er	
	Bus	Bus trigger		
	External	External trigger		
DLogTrig Source	Set the trigger m	method for the data logging.		
	Immediate	Trigger immediately		
	Manual	Manual trigg	er	
	Bus	Bus trigger		
	Voltage	Voltage trigg	er	
	Current	Current trigg	er	
	External	External trigg	ger	
I/O	Set the commun	nication inform	ation between instrument and PC.	
	USB	USB commu	nication interface	
		TMC	USB-TMC protocol	
		VCP	Virtual serial port	
			Display as the following format: baud rate_data bit_parity bit_stop bit.  • Baud rate: 9600  • Data bit: 8  • Parity bit: N	



		Stop bi	t: 1
	LAN	this option nication pa menu item	N communication. After selecting, you also need to set the communarameters of the LAN, and the same as those in the (see below).
LAN	LAN commu	nication inte	erface
	Info	View the L	AN information.
		LAN Statu IP Mode: A IP: 0.0.0.0 Mask: 0.0. Gateway: DNS1: 0.0 DNS2: 0.0 MAC: 8C:0 MDNS State HostName HostDesc: Domain: TCPIP:INS Socket Po	Auto 0.0 0.0.0.0 .0.0 .0.0 .0.0 28:F4:40:01:E1 itus:
	IP-Conf	Configure	LAN IP information.
		IP-Mode	Configure LAN IP mode.
			Auto: automatically configure the address of the instrument.
			Manual: manually configure the address of the instrument.  • IP: 0.0.0.0
			Set the IP address.
			• Mask: 0.0.0.0
			Set the subnet mask.
			• Gateway: 0.0.0.0
			Set the gateway address.
			• DNS1: 0.0.0.0
			Set the preferred address of the DNS server. If it is not in- volved, there is no need to set it.
			• DNS2: 0.0.0.0
			Set the DNS server alternate address. If it is not involved, there is no need to set it.
			Socket Port: 30000



				Set the port number.	
		Restore	Select who settings or NO  YES	ether to reset the LAN to the default not.	
				ether to confirm the LAN setting or	
		<b>D</b> (	not.	strier to commit the LAN Setting of	
		Reset	• NO		
			• YES		
	CAN	CAN commu			
		Baudrate	tions: 5k/1	baud rate from the following op- 0k/20k/40k/50k/80k/100k/125k/ /400k/500k/600k/800k/1000k.	
		Address	Set the ins 0 to 127.	strument address to a number from	
			Canfes	stival: Use standard can protocol.	
		Protocol		Jse the protocol for docking with S system.	
	BOARD	Select the optional communication interface. After inserting the optional interface, it can be used normally.			
		GPIB	Select GP	IB communication interface.	
			Address	Set the communication address (1 to 30).	
		ECAT	Select ECAT communication interface.		
	RS232	Select RS-23	-232 communication interface.		
	Display RS232 ac- cording to op- tional inter- face. In addition, RS232 inter-	Baudrate	Baud rate: 4800/9600/19200/38400/57600/ 115200		
		Databit	Data bit: 5/6/7/8		
		Parity	Parity bit: N (No parity) / E (Even parity) / O (Odd parity)		
	face and the	Stopbit	Stop bit: 1/2		
analog inter- face share an interface position.	interface	Addr	Address (*	I to 31).	
Parallel	Set the instrume	nents to parallel operation mode.		mode.	
	Single	Set the instrument to single mode, i.e., disable the paralle operation mode.		gle mode, i.e., disable the parallel	
	Master	Set the instrument to master mode.		aster mode.	
		Total Unit	Number of	parallel instruments.	



	Slave	Set the instrument to slave mode.		
Digital Port	Set Digital I/O By default, the menu item displays 7 options. You can set parameters for each option respectively. After setting, the corresponding change to each option becomes valid immediately. When re-entering <b>DigPort</b> , the interface can display the changed option. For detailed introduction of menus and functions, see 5.11 Digital I/O Function (Digital Port).			
	IO-1. Ps-Clear,	Not-Invert	Function setting of pin 1	
	IO-2. Ps, Not-In	vert	Function setting of pin 2	
	IO-3. Off-Status	, Not-Invert	Function setting of pin 3	
	IO-4. Ext-Trig, N	lot-Invert	Function setting of pin 4	
	IO-5. INH-Living	g, Not-Invert	Function setting of pin 5	
	IO-6. Sync-On,	Not-Invert	Function setting of pin 6	
	IO-7. Sync-Off, Not-Invert		Function setting of pin 7	
Ext-Program	External Analog Function. This function is optional. The menu can only display when corresponding board card is inserted. For details, see 5.12 Analogue Function (Ext-Program) (Optional).			
System Reset	Select whether to restore the factory default settings or not.			
System Rzero	Used to control whether the voltage is quickly zeroed after the output is turned off.  Off: No  On: Yes			
System Info	View the system information. For details, see 5.13 View the System Information (System Info).			

## 1.9 Options Introduction

This series instrument supports the following types of optional accessories (sold separately), the details are as below:

#### Optional interface card


- IT-E176: Interface card for GPIB communication. When users need to use GPIB communication, they can choose to purchase this accessory.
  - For details, see 2.5.4 GPIB Interface (Optional).
- IT-E1601-black: Interface card for EtherCAT communication. When users need to use EtherCAT communication, they can choose to purchase this accessory.

For details, see 2.5.6 EtherCAT Interface (Optional).



 IT-E177: Interface card that includes RS-232 communication interface, external analog and other functions.

The accessory has a total of 10 pins, and the details of each pin are as follows:




Pins	Description
1	RS-232 TXD pin for transmitting data.
2	RS-232 RXD pin for receiving data.
3	RS-232 DGND pin for grounding.
4	Ground terminal, that is, the negative terminal of pin 5 to pin 10.
5	Voltage monitoring terminal. It can output a voltage of 0 to 10V to monitor the output voltage from 0 to full scale.
6	Current monitoring terminal.  It can output a voltage of 0 to 10V to monitor the output current from 0 to full scale output current.
7	Reference voltage (10V) test terminal. The accuracy is 0.03%. You can use a multimeter to measure this pin. When the output voltage of the pin is in the range of 10±0.03%*10, it indicates that the accessory is functioning normally. Otherwise, the function is abnormal and cannot be used.
8/9/	Terminals for external analog function. For details, see 5.12 Analogue Function (Ext-Program) (Optional).



#### Fiber optic modules and cables

Fiber optic modules and cables are used for data transmission and communication between parallel units, and are highly resistant to interference. The fiber optic module and cable are the necessary accessories for the parallel connection. Different numbers of fiber optic modules and cables are used in different numbers of parallels.



IT-E168: Used for parallel connection between the units, including one fiber module and two fiber cables, with lengths of 1.5 meters and 0.3 meters.

IT-E165A: Anti-reverse connection and anti-spark module

It is suitable for battery products. This module can be selected to avoid sparking and reverse connection during battery wiring.

• IT-E165B: Anti electromotive force module

It is suitable for motor products, which can prevent the electromotive force generated during the operation of the motor from damaging the power supply products.

#### Cabinet installation

This series of instruments can be mounted on a standard 19-inch cabinet. ITECH provides rack mount kits for users as mounting accessories.

- IT-E155A+IT-E155C: Select this mounting kit when mounting a 1U instrument to an ITECH cabinet. Please refer to 《IT-E155 User Manual》 for detailed description about the installation method.
- IT-E155A+IT-E155B: Select this mounting kit when mounting 1U instruments to other cabinets. Please refer to 《IT-E155 User Manual》 for detailed description about the installation method.
- IT-E156: Select this mounting kit when the 2U instrument is mounted in the ITECH cabinet.



# **Inspection and Installation**

- Verifying the Shipment
- ♦ Instrument Size Introduction
- ◆ Connecting the Power Cord◆ Connecting the Device Under Test (DUT)
- ♦ Remote Interface Connection

## 2.1 Verifying the Shipment

Unpack the box and check the contents before operating the instrument. If wrong items have been delivered, if items are missing, or if there is a defect with the appearance of the items, contact the dealer from which you purchased the instrument immediately.

The package contents include:

Item	Qty.	Model	Remarks
High power Program- mable DC Power Supply	x1	IT-M3900D Series	For the specific models included in this series, refer to 1.1 Brief Introduction.
Power cord	x1	-	Depending on the instrument model. For details, see 2.3 Connecting the Power Cord.
USB communication cable	x1	-	This accessory is selected when the USB interface is used for starting up remote operation.
LAN communication cable	x1	-	This accessory is selected when the LAN interface is used for starting up remote operation.
Calibration Report	x1	-	It contains the test report and calibration report of the instrument before delivery.






Upon verification of the shipment, keep the package and relevant contents thereof in a safe place. When returning the instrument for warranty service or repair, the specified packing requirements shall be met.

## 2.2 Instrument Size Introduction

The instrument should be installed at well-ventilated and rational-sized space. Please select appropriate space for installation based on the instrument size.


The detailed dimension drawings of this series instrument are as follows (unit: mm, deviation: ±1 mm):

#### **1U Models**





#### **2U Models**



## 2.3 Connecting the Power Cord

#### **Precautions**

To prevent electric shock and damage to the instrument, observe the following precautions.



#### WARNING

- Before connecting power cord, be sure to confirm that the power voltage matches with the rated input voltage of the instrument.
- Before connecting power cord, be sure to switch off the instrument.
   Verify that there is no dangerous voltage on the connection terminals.
- To avoid fire or electric shock, make sure to use the power cord supplied by ITECH.
- Be sure to connect the power cord to the AC distribution box with protective grounding. Do not use terminal board without protective grounding.
- Do not use an extended power cord without protective grounding, otherwise the protection function will fail.
- Ensure that the power cord connection terminals are either insulated or covered by the supplied protective cover so that no accidental contact with lethal voltage can occur.


#### CAUTION

Safety agency requirements dictate that there must be a way to physically disconnect the AC mains cable from the unit. A disconnect device, either a switch or circuit breaker must be provided in the final installation. The disconnect device must be close to the equipment, be easily accessible, and be marked as the disconnect device for this equipment.

#### **Categories of Power Cords**

Standard three-phase power input cord

The standard power cord specifications for this series instruments are divided into the following types according to different regions:



The yellow-green wire is grounding wire, which is connected to the PE terminal of power input on the rear panel; the others are live wires, which are correspondingly connected to the L1, L2 and L3 terminals of power input on the rear panel of the instrument.



#### **AC Power Input Level**


This series 1U models support single-phase or three-phase AC input, and 2U models support three-phase AC input. Please refer to the corresponding specification for the voltage level range and frequency. In addition, the Output DC power will be derated when the instrument is AC input at a low-grade voltage. The derating formula is as follows.

- Single-phase utility, the Output DC power limit is, P = phase voltage \* maximum input current \* efficiency.
- Three-phase utility, the Output DC power limit is, P = line voltage \* maximum input current \* efficiency \* 1.732.

#### **Connecting the Power Cord**


#### Wiring Diagram:

 When the 1U and 2U models are connected to three-phase power, the wiring diagram is shown below.



When the 1U model is connected to single-phase power (L/N), the wiring diagram is shown below.





#### **Operation procedures:**

- For 1U/2U model, see the steps below to connect the power cable.
  - 1. Confirm that the switch of the AC power distribution box is off.
  - 2. Confirm that the power switch is in the OFF position and verify that there is no dangerous voltage on the connection terminals.
  - 3. Remove the protective cover outside the AC input terminal on the rear panel.
  - 4. Connect one end of the power cable's round terminal to the AC power input terminal on the instrument's rear panel.
    - a. You only need to connect the red/green/yellow (or brown/black/gray) live wires to the terminals on the rear panel, which are not required to correspond to L1, L2 and L3 terminals one by one.
    - b. The yellow-green wire is grounding wire, which is connected to the protective grounding terminal (PE).
  - 5. Mount the protective cover back to its original position.
  - 6. Refer to the suggestion connection diagram, connect the other end of the power cable to the required AC distribution box.

## 2.4 Connecting the Device Under Test (DUT)

This section describes how to connect the test cables between the instrument and DUT.



#### **Precautions**

To prevent electric shock and damage to the instrument, observe the following precautions.

#### WARNING

- Before connecting test cables, be sure to switch off the instrument.
   Power switch is in Off position, otherwise touching the output terminals on the rear panel may result in personal injury or death due to electric shock.
- To avoid electrical shock, before testing, please make sure the rating values of the testing cables, and do not measure the current that higher than the rating value. All test cables shall be capable of withstanding the maximum short circuit current of the instrument without causing overheat.
- If several loads are provided, each pair of load wires shall safely withstand the rated short circuit output current of the power supply under full load.
- Do not short the battery when connecting or disconnecting the battery testing circuit. Short circuit may cause severe accident.
- Always use test cables provided by ITECH to connect the equipment. If test cables from other factories are used, please confirm the maximum current that the test cables can withstand.
- During wiring, check that the positive and negative poles of the test cables are properly and tightly connected. Do not connect the positive pole and disconnect the negative pole.
- Ensure that the output terminals are either insulated or covered using the safety covers provided, so that no accidental contact with lethal voltages can occur.

#### **Specification for Test Cables**

Test cables are not standard accessories for the instrument. Please select optional red and black test cables for individual sales based on the maximum current value. For specifications of test cables and maximum current values, refer to A.1 Appendix-Specifications of Red and Black Test Lines.

#### **Electrode introduction**


The wiring apertures of the DC terminal electrodes for 1U/2U models are M8.



### **Connecting the DUT (Local Measurement)**

The instrument supports two kinds of wiring methods with the DUT: local measurement and remote measurement (SENSE). The default test mode is local measurement.

The connection diagram and steps of local measurement are as follows:



- 1. Confirm that the power switch is in the OFF position and verify that there is no dangerous voltage on the connection terminals.
- 2. Remove the output terminals cover of the power supply.
- 3. Loosen the screws of the output terminals and connect the red and black test cables to the output terminals. Re-tighten the screws.
  - When maximum current that one test cable can withstand fails to meet the rated current, use multiple pieces of red and black test cables. For example, the maximum current is 1,200A, then 4 pieces of 360A red and black cables are required.
- 4. Thread the red and black test cables through the output terminals cover of the power supply and install the cover.
- 5. (Optional) According to the actual situation of DUT, connect the grounding terminal on the rear panel of the instrument to the DUT to ensure the safe grounding.
  - For the location information, see 1.5 Rear Panel Introduction.
- 6. Connect the other end of the red and black cables to the DUT. The positive and negative poles must be properly connected and fastened when wiring.

### Connecting the DUT (Remote Sensing)

Remote measurement is available for the following scenarios:


When the DUT consumes large current or the wires are too long, there is a voltage drop on the wires between DUT and output terminals of the power supply. To maximize measurement accuracy, the power supply provides the remote measurement terminals VS+ and VS- on the rear panel, which can be used to measure the terminal voltage of the DUT.

When the power supply is used for battery testing in actual applications, the voltage drop of the wire will lead to voltage inconsistency of both ends and



inconsistency of the cutoff voltage of power supply and the actual voltage of battery, resulting in inaccurate measurement.

The connection diagram and steps of remote measurement are as follows:



- 1. Confirm that the power switch is in the OFF position and verify that there is no dangerous voltage on the connection terminals.
- 2. Refer to the wiring diagram and connect the Vs+ and Vs- with armored twisted-pair cables.



To ensure the stability of the system, use armored twisted-pair cables between the remote sense terminals and the DUT. Pay attention to the positive and negative poles when wiring, otherwise it will damage the instrument.

- 3. Remove the output terminals cover of the power supply.
- 4. Loosen the screws of the output terminals and connect the red and black test cables to the output terminals. Re-tighten the screws.

When maximum current that one test cable can withstand fails to meet the rated current, use multiple pieces of red and black test cables. For example, the maximum current is 1,200A, then 4 pieces of 360A red and black cables are required.

- 5. Thread the red and black test cables through the output terminals cover of the power supply and install the cover.
- 6. (Optional) According to the actual situation of DUT, connect the grounding terminal on the rear panel of the instrument to the DUT to ensure the safe grounding.

For the location information, see 1.5 Rear Panel Introduction.

- 7. Connect the other end of the remote sense cables to the DUT.
- 8. Connect the other end of the red and black cables to the DUT. The positive and negative poles must be properly connected and fastened when wiring.
- 9. Power on the instrument and turn on the Sense function of the instrument. For details, see 5.7 Sense Function (Sense).



### WARNING

- During the operation of 10V model instrument, there may be a risk of high voltage to ground from the DC output, and the test object may also have high voltage to ground. Test cables must be fully insulated, and exposed metal parts are strictly prohibited to ensure operational safety.
- Never touch cables or connections immediately after turning off the instrument at the end of the test. Lethal voltages may remain at the output terminals after turn-off. Verify that there is no dangerous voltage on the output or sense terminals before touching them.

# 2.5 Remote Interface Connection

This series power supply comes standard with four communication interfaces: USB, LAN and CAN, and supports three optional communication interfaces: GPIB, RS-232, EtherCAT. You can choose one of them to communicate with your computer.



When you use the remote interface to send SCPI instructions, if you use the programming commands that involve modifying the instrument settings, such as modifying the output voltage value, after completing the communication connection between the instrument and the host computer, and after the communication settings are completed, you must execute the **SYST:REM** command firstly.

### 2.5.1 USB Interface

The USB interface is located on the rear panel of the instrument. You can connect the instrument to the computer via a cable with a USB interface on both ends (USB A-type connector on one end and USB B-type connector on the other).

The user needs to select the USB interface type in the System menu before using the USB interface. The following types are optional.

- TMC: USB TMC interface;
- VCP: Virtual serial port. For Win7 system, you can download IT-M3900 VCP driver from ITECH official website or contact technical support engineer; for Win10 system, you do not need to install VCP driver.

The operation steps to change the USB interface type in System Menu are as follows.



- Press the composite keys [Shift]+[P-set] (System) on the front panel to enter the system menu.
- 2. Rotate the knob to select **I/O** and press **[Enter]**.
- 3. Rotate the knob or press the Left/Right key to select **USB**, and press **[Enter]**.
- 4. Rotate the knob or press the Left/Right key to select the communication method



If you select **VCP**, you also need to set the baud rate and other parameters of the virtual serial port, and the baud rate must be the same as the configuration on the computer side.

### 2.5.2 LAN Interface

When the user connect PC through LAN interface, the following is required to use the LAN interface. The LAN interface complies with the LXI standard.

### **Connect Interface**

Use the following steps to quickly connect your instrument to your LAN and configure it. Two typical LAN interface systems are described below: private LAN and site LAN.

### Connect to the private LAN

A private LAN is a network in which LAN-enabled instruments and computers are directly connected. They are typically small, with no centrally-managed resources. When connected to a computer, a standard network cable can be used to connect directly to the computer via the LAN interface.

#### Connect to the site LAN

A site LAN is a local area network in which LAN-enabled instruments and computers are connected to the network through routers, hubs, and/or switches. They are typically large, centrally-managed networks with services such as DHCP and DNS servers. When connected to a computer, a network cable can be used to connect to the router, and the computer is also connected to the router.



### Note

- When using one crossover cable to connect PC directly, the gateway address of the instrument should be consistent with that of the PC, and the IP address should be at the same network segment with the PC's IP address.
- When the instrument and computer are connected to the router, an independent IP address must be assigned for the instrument.

### **View LAN Interface Information**

The operation steps to view the LAN interface information in the System Menu are as follows.

- Press the composite keys [Shift]+[P-set] (System) on the front panel to enter the system menu.
- 2. Rotate the knob to select I/O and press [Enter].
- 3. Press the Left/Right key to select LAN and press [Enter].
- 4. Press the Left/Right key to select **Info** and press **[Enter]**.
- 5. Rotate the knob to view the LAN parameters. See the information in 1.8 System Menu Function for details.

### **Configure LAN Interface Information**

The configurable parameters of this series power supply are described as follows.

#### **IP-Conf**

- IP: This value is the Internet Protocol (IP) address of the instrument. An IP address is required for all IP and TCP/IP communications with the instrument. An IP Address consists of 4 decimal numbers separated by periods. Each decimal number ranges from 0 through 255 with no leading zeros (for example, 169.254.2.20).
- Mask: This value is used to enable the instrument to determine if a client IP
  address is on the same local subnet. The same numbering notation applies
  as for the IP Address. When a client IP address is on a different subnet, all
  packets must be sent to the Default Gateway.
- Gateway: This value is the IP Address of the default gateway that allows the
  instrument to communicate with systems that are not on the local subnet, as
  determined by the subnet mask setting. The same numbering notation applies as for the IP Address. A value of 0.0.0.0 indicates that no default gateway is defined.
- DNS1: This field enters the primary address of the server. Contact your LAN
  administrator for server details. The same numbering notation applies as for
  the IP Address. A value of 0.0.0.0 indicates that no default server is defined.



DNS is an internet service that translates domain names into IP addresses. It is also needed for the instrument to find and display its hostname assigned by the network. Normally, DHCP discovers the DNS address information; you only need to change this if DHCP is unused or not functional.

- DNS2: This field enters the secondary address of the server. Contact your LAN administrator for server details. The same numbering notation applies as for the IP Address. A value of 0.0.0.0 indicates that no default server is defined.
- Socket Port: This value indicates the port number corresponding to the service.


### 2.5.2.1 Using Web Server

The instrument has a built-in Web server for monitoring and controlling the instrument via a Web browser in PC. To use the Web server, connect the instrument and PC over LAN interface and enter the instrument's IP address into the address bar at the top of your PC's Web browser, you can access the front panel control functions including the LAN configuration parameters.



- If you want to remotely control the instrument using the built-in web server, you
  must enable the web service. See 2.5.2 LAN Interface for details.
- The format of the address entered in the address bar of the browser is http://
  192.168.0.100. The specific IP address is subject to the actual instrument settings.

The opened page is displayed as follows:





# Note

The homepage of different models are different. The actual shown page shall be subject to the connected instrument.

You can select different pages by clicking the buttons shown in the navigation bar on the left side of the window. The detailed descriptions are as follows.

- Home: Web home interface, displays the model and appearance of the instrument;
- Information: Displays the serial number of the instrument and more system information as well as LAN configuration parameters;
- Web Control: Enables the Web control to begin controlling the instrument.
   This page allows you to monitor and control the instrument;
- Manual: Go to the ITECH official website and view or download the relevant documents.
- Upload: Performs a system upgrade.

Click **CONNECT** to connect the PC with the instrument, then click **BROWSE** to select the system upgrade installation package (for example, itech\_3900\_P.itech), and then click **UPLOAD** performs the upgrade operation. After the upgrade is complete, the instrument needs to be restarted.

### 2.5.2.2 Using Telnet

The Telnet utility (as well as sockets), is another way to communicate with the instrument without using I/O libraries or drivers. In all cases, you must first establish a LAN connection from your computer to the instrument as previously described.

In an MS-DOS Command Prompt box, type "telnet hostname" where hostname is the instrument's hostname or IP address. Press the Enter key and you should get a Telnet session box with a title indicating that you are connected to the instrument and 23 is the instrument's telnet port. Type the SCPI commands at the prompt.

### 2.5.2.3 Using Sockets

### CAUTION

- Before using this function, you need to configure Socket Port, and the configuration on the instrument side should be consistent with the configuration on the PC side.
- The instruments allow any combination of up to six simultaneous socket and telnet connections to be made.



ITECH instruments have SCPI socket services, which can be used to send and receive SCPI commands, queries, and query responses. All commands must be terminated with a newline for the message to be parsed. All query responses will also be terminated with a newline.

### 2.5.3 CAN Interface

The CAN interface is located on the rear panel of the instrument and is connected to the computer using a CAN communication cable.

### **Definition of CAN Pins**

The definition of CAN pins are as follows.

Pins	Description	
Н	CAN_H	
L	CAN_L	
GND	CAN_GND	

### **CAN Configuration**

The user needs to configure the CAN interface parameters in the system menu before using the remote control. The CAN interface parameters are as follows.

Name	Description	
Address	Range: 0 – 127	
Baud rate	Select the baud rate from the following options: 5k/10k/20k/40k/50k/80k/100k/125k/200k/250k/400k/500k/600k/800k/1000k	
Protocol	<ul> <li>DeviceNet: Use standard can protocol.</li> <li>BMS: Use the protocol for docking with the BMS system.</li> </ul>	

The operation steps are as follows.

- 1. Press the composite keys [Shift]+[P-set] (System) on the front panel to enter the system menu.
- 2. Rotate the knob to select I/O and press [Enter].




- 3. Press the Left/Right key to select CAN and press [Enter].
- 4. Set the baud rate, address and other parameters, press [Enter].


### **CAN Troubleshooting**

If you meet some problems when communicating with PC by CAN interface, please check the following items:

- PC and the instrument must have the same baud rate.
- Ensure you have used the correct communication cable (CAN\_H, CAN\_L).
   Please pay attention that some cable may not have a correct internal wiring even it is with an appropriate plug.
- The interface cable is correctly connected (CAN\_H to CAN\_H, CAN\_L to CAN\_L).
- If the communication signal is poor or unstable, it is recommended to connect a 120  $\Omega$  terminating resistance.
  - The connection diagram of a single device is as below.



The connection diagram of multiple devices is as below.





When multiple devices are connected, it is recommended to connect the pin 8 (GND) of the P-IO terminal on the rear panel of these devices in parallel, and the communication quality will be improved in the entire CAN network.

# 2.5.4 GPIB Interface (Optional)

The GPIB (IEEE-488) interface is assembled in the IT-E176 communication board. Use a GPIB cable to connect GPIB interfaces of the instrument and PC. Please ensure that the screws have been screwed down in order to have a full connection.



### **GPIB Configuration**

Each device on the GPIB (IEEE-488) interface must have a unique whole number address between 1 and 30. Your computer's GPIB interface card address must not conflict with any instrument on the interface bus. This setting is nonvolatile; it will not be changed by \*RST.

When you purchase the interface accessory and successfully insert it into the corresponding position on the rear panel of the instrument, the menu item for changing the GPIB address appears in the System menu. The specific steps are as follows:

- 1. Ensure that the instrument's power switch is off, that is, the instrument is in Power Off state.
- 2. Insert the separately purchased GPIB interface card into the card slot on the rear panel of the instrument.
- 3. Connect the instrument with the computer via the GPIB cable. After the connection is successful, turn on the power switch of the instrument.
- 4. Press the composite keys [Shift]+[P-set] (System) on the front panel to enter the system menu.
- 5. Rotate the knob to select I/O and press [Enter].
- 6. Press the Left/Right key to select **BOARD** and press [Enter].
- 7. Press the Left/Right key to select **GPIB** and press **[Enter]**.
- 8. Press the numeric keys to set the GPIB address and press [Enter].


# 2.5.5 RS-232 Interface (Optional)

The RS-232 interface shares the same communication card (IT-E177) with the analog function.

### **Definition of RS-232 Pins**

The definition of RS-232 pins are as follows.





When using the RS-232 interface for communication, connect the pin 1, pin 2, and pin 3 of the IT-E177 to the PC. The pin description is as follows:

Pins	Description	
1	TXD, transmit data	
2	RXD, receive data	
3	DGND, ground	

### **RS-232 Configuration**

When you purchase the interface accessory and successfully insert it into the corresponding position on the rear panel of the instrument, the RS–232 menu item will appear in the System menu. The specific steps are as follows:

- 1. Ensure that the instrument's power switch is off, that is, the instrument is in Power Off state.
- 2. Insert the separately purchased RS–232 interface card into the card slot on the rear panel of the instrument.
- 3. Connect the instrument to the computer via an RS–232 cable. After the connection is successful, turn on the power switch of the instrument.
- 4. Press the composite keys [Shift]+[P-set] (System) on the front panel to enter the system menu.
- 5. Rotate the knob to select I/O and press [Enter].
- 6. Press the Left/Right key to select **RS232** and press **[Enter]**.
- 7. Set the relevant communication parameters in turn, and press [Enter].



### RS-232 Troubleshooting

If you meet some problems when communicating with PC by RS-232 interface, please check the following items:

- Check that whether the baud rate of the computer and instrument are the same:
- Make sure the correct cable and adapter are connected. Note that internal wiring may not be correct even if the cable has a suitable plug;
- The cable must be connected to the correct serial ports (COM1, COM2, etc) of PC.

## 2.5.6 EtherCAT Interface (Optional)

The EtherCAT interface is assembled in the IT-E1601-black communication board. You can connect the instrument to the computer via a network cable.

### **EtherCAT Configuration**

When you purchase the interface accessory and successfully insert it into the corresponding position on the rear panel of the instrument, the menu item for EtherCAT configuration appears in the System menu. The specific steps are as follows:

- 1. Ensure that the instrument's power switch is off, that is, the instrument is in Power Off state.
- 2. Insert the separately purchased EtherCAT interface card into the card slot on the rear panel of the instrument.
- 3. Connect the instrument with the computer via the network cable. After the connection is successful, turn on the power switch of the instrument.
- 4. Press the composite keys [Shift]+[P-set] (System) on the front panel to enter the system menu.
- 5. Rotate the knob to select **I/O** and press **[Enter]**.
- 6. Press the Left/Right key to select **BOARD** and press [Enter].
- 7. Press the Left/Right key to select **ECAT** and press **[Enter]**.
- 8. After making the communication setting, to ensure normal communication, you need to restart the instrument.
- 9. Repeat steps 4~7 above to view the EtherCAT information.

Display Information	Function
ECAT INFO	
1.State: Init/Preop/Safeop/Op	State: Initialization/Pre-operational/Safe-operational/Operational.



Display Information	Function
2.Addr: 4097	Slave address (this address is assigned to this slave by the EtherCAT master).
3.Alias Addr: 0	Slave address alias.
4.HW Ver: 256	Communication card hardware version number.
5.Soft Ver: 1	Communication card software version number.



# **3** Getting Started

- ♦ Power-on Self-Test
- ♦ Set Output Value
- ♦ Use the Front Panel Menu.
- ♦ On/Off Control

# 3.1 Power-on Self-Test

Before operation, please confirm that you have fully understood the safety instructions.

When you turn the POWER switch on for the first time after purchase, the instrument starts with its factory default settings. Each time thereafter, the instrument starts according to the setting that you selected as outlined in 5.6 Set the Power-on State (PowerOn).



### **Precautions**


### WARNING


- Before connecting power cord, be sure to confirm that the power voltage matches with the supply voltage.
- Before connecting power cord, be sure to switch off the instrument.
   Verify that there is no dangerous voltage on the terminals before touching them.
- To avoid fire or electric shock, make sure to use the power cord supplied by ITECH.
- Be sure to connect the main power socket to the power outlet with protective grounding. Do not use terminal board without protective grounding.
- Do not use an extended power cord without protective grounding, otherwise the protection function will fail.
- Ensure that the input electrodes are either insulated or covered using the safety covers provided, so that no accidental contact with lethal voltages can occur.
- If you notice strange sounds, unusual odors, fire, or smoke around or from inside the instrument, flip the POWER switch to the (O) side to turn the instrument off, or remove the power cord plug from the outlet. The detachable power cord may be used as an emergency disconnecting device. Removing the power cord will disconnect AC input power to the unit.

### **Power Switch Introduction**

The power switch is located in the lower left corner of the front panel. The power switch is a button, and pressing once indicates **ON** and pressing again indicates **OFF**.







### Turning the POWER Switch On / Off

Turning the POWER Switch On

Check that the power cord is connected properly.

Flip the POWER switch to the ( | ) side to turn the instrument on. The front panel display will light up after a few seconds. It may take about 30 seconds or so for the power supply to initialize before it is ready for use.

Turning the POWER Switch Off

Flip the POWER switch to the (O) side to turn the instrument off. After you turn the POWER switch off, wait at least 10 seconds after the fan stops before you turn the POWER switch back on. Turning the instrument on too soon after you turn it off can cause damage to the inrush current limiter circuit, as well as reduce the life of components such as the POWER switch and the internal input fuses.

### **Self-Test Procedures**

A successful self-test indicates that the purchased product meets delivery standards and it is available for normal usage. Normal self-test procedures:

1. Correctly connect the power cord and power on the instrument.

The instrument starts the self-test.

2. After the instrument is self-tested normally, the VFD shows the output voltage, current, power and other information (CV mode).

If an error occurs during the self-test, an error message is displayed. The following table lists the error messages you might see.

Error message	Error Description
Eeprom Failure	The EEPROM is damaged.
Main FrameInitializeLost	The system setting data is lost.
Calibration Data Lost	The factory calibration data in EE-PROM is lost.



Error message	Error Description
Config Data Lost	The latest operation state of the instrument is lost.
NETWORKING	The parallel operations are abnormal and cannot finish the networking.
FIBER MULTI MASTER	Multi-master conflict
FIBER EXT UNLOCK	The outer ring of the fiber is not locked.

### **Exception Handling**

If the instrument cannot start normally, please check and take measures by reference to steps below.

- 1. Check whether the power cord is correctly connected and confirm whether the instrument is powered.
- 2. Check whether the power in On. The power switch is under "|" On status.
- 3. Check whether the power voltage matches with the supply voltage. Please refer to 2.3 Connecting the Power Cord to select proper AC input.
- After multiple units are connected in parallel and powered on, the error related to the fiber-optic is indicated. Please refer to the following steps for troubleshooting.
  - FIBER MULTI MASTER: Multiple units (with panel) are connected in parallel, please confirm whether multiple Masters are set. Select System→ Parallel menu to reset. There can only be one single unit as the Master, and the other single units must be set to Slave. After the setting is completed, power off and restart each single unit.
  - FIBER EXT UNLOCK: Multiple units (with panel) are connected in parallel, check whether the cable connection of the fiber outer ring (TX and RX) is closed. Then confirm that whether the System→Parallel menu is set. There can only be one single unit as the Master, and the other single units must be set to Slave. After the setting is completed, power off and restart each single unit.
- 5. If the instrument still does not start, contact ITECH technical support engineer.



# 3.2 Set Output Value

The voltage value, current value, power value can all be programmed. The user can set different output parameters within the range of specifications according to the need to satisfy a range of test requirement.

After selecting the operation mode, the interface displays the setting value under the selected operation mode and the cursor blinks to prompt. The user can use the following methods to set the values.

- Directly use the number keys to set the value.
- Rotate the knob to set the data in the cursor position. Rotate the knob clockwise to increase the set value and anticlockwise to decrease the set value. Once the data in the cursor position increases to ten, the value will add one to the front position automatically. and once the data in the cursor position decreases to zero, the value will minus one from the front position automatically. This provides convenience for the user to set. The knob can works with the left or right keys. Use the left or right keys to move the cursor position.



After entering the menu interface, the knob can also be used to scroll pages to view menu items.

# 3.3 Use the Front Panel Menu.

The front panel provides multiple menu keys and the user can access the instrument menu by using the front panel keys, including **Config** menu, **System** menu, **Protect** menu and **Function** menu. And the user can change the related system setting in the menu. Each menu is briefly described as follows.

- The user can set the parameters related to electrical properties in the Config menu, including the current operation mode, slope, output delay time, internal resistance.
- The user can set the function related to instrument system in the System menu, including the key beeper, Sense function, power-on state, trigger source, communication method, data logger method, digital I/O function setting, parallel function, system information and so on.
- The user can set the parameters related to instrument protection function in the Protect menu, including OCP /OVP/OPP /UCP/UVP.
- Function menu includes output list, batterycharging test function and so on.



The user press the complex keys to enter into the menu interface. The menu is divided according to the function item and the corresponding operation is set in the lowest level menu item. For example, the key beeper is set in **System→- Beep**. Set the **Beep** item to off or on. Please refer to 1.7 Configuration Menu Function, 1.8 System Menu Function and the corresponding chapters for detailed menu description.

After entering the menu interface, the screen displays the optional menu. Rotate the knob to view the menu items. When the number in front of the menu item is blinking, indicates this item is selected currently. Press [Enter] key to enter the selected menu item and press [Esc] to exit the menu.

### 3.4 On/Off Control

### WARNING

- The [On/Off] key is used to turn the output/input on or off under normal circumstances. Even if the instrument is in control by PC or the keyboard is locked, the [On/Off] is still valid.
- The [On/Off] key light is off and turning the output off does not place the instrument in a safe state. Hazardous voltages may be present on all output and guard terminals. Putting the equipment into an output-off state does not guarantee that the outputs are powered off if a hardware or software fault occurs. See the cautions about connecting the test lines before connecting test lines.

You can press the **[On/Off]** key on the front panel to control the output status of the power supply. If the **[On/Off]** key light is on, indicates that the output is turned on. If the **[On/Off]** key light is off, indicates that the output is turned off. When the output of the power supply is on, the operating status flag (CV/CC/CW) on the VFD will be illuminated.



It is recommended that you turn on the **[On/Off]** after the power supply is connected to the DUT. If the power supply has no output after the output is turned on, check the voltage and current setting value, set the voltage and current to a non-zero value, and then turn on the output.



# 4

# **Power Supply Function**

This chapter describes the functions and features of the power supply. Divided into the following sections:

- Set the Output Voltage
- ♦ Set the Output Current
- ♦ Set the Output Power
- Config Menu for Power Supply
- ◆ Protection Function for Power Supply
- ◆ Function Menu for Power Supply

# 4.1 Set the Output Voltage

In CV priority (default) mode, press **[V-set]**, the interface displays "Vset=0.00V" (Setting value of voltage). In CC priority mode, press **[V-set]**, the interface displays "Vlim=0.00V" (Upper limit of voltage), the lower limit of the voltage is 0.

The voltage setting range is from 0V to the maximum rated output voltage. When **[V-set]** key is pressed, the key light is lit and the output voltage value can be set. Press numeric keys or rotate the knob to adjust the value in the voltage setting area indicated by the cursor. This value takes effect when you press **[Enter]**.

# 4.2 Set the Output Current

In CV priority (default) mode, press [I-set], the interface displays "Ilim=0.00A" (Upper limit of current), the lower limit of the current is 0. In CC priority mode, press [I-set], the interface displays "Iset=0.00A" (Setting value of current).

The range of current settings is between the data ranges defined in the specifications. When **[I-set]** key is pressed, the key light is lit and the output current value can be set. Press numeric keys or rotate the knob to adjust the value in the current setting area indicated by the cursor. This value takes effect when you press **[Enter]**.



# 4.3 Set the Output Power

Press **[P-set]**, the interface displays "Plim=0.00W" (Upper limit of power), the lower limit of the power is 0.

The range of power settings is between the data ranges defined in the specifications. When **[P-set]** key is pressed, the key light is lit and the output power value can be set. Press numeric keys or rotate the knob to adjust the value in the power setting area indicated by the cursor. This value takes effect when you press **[Enter]**.

# 4.4 Config Menu for Power Supply

In this chapter, the setting items under the configuration menu are described in detail.


# 4.4.1 Set the CC/CV Priority Mode

### **CV** Priority

In CV priority mode, the output is controlled by a constant-voltage feedback loop, which maintains the output voltage at its programmed setting as long as the load current remains within the current limit settings. CV priority mode is best suited for use with resistive or high impedance loads, and loads that are sensitive to voltage overshoots. Do not use CV priority mode with low-impedance sources such as batteries, power supplies, or large charged capacitors.

In CV priority mode, the output voltage should be programmed to the desired value. A current limit value should also be set. The current limit should always be set to a value that is greater than the actual input current requirement of the external load. The following figure shows the CV priority operating locus of the output.





The heavy solid line illustrates the locus of possible operating points as a function of output. As shown by the horizontal portion of the line, the output voltage remains regulated at its programmed setting as long as the load current remains within the current limit setting. A CV status flag indicates that the output voltage is being regulated and the output current is within its limit settings.


Note that when the output current reaches current limit, the unit no longer operates in constant voltage mode and the output voltage is no longer held constant. Instead, the unit will now regulate the output current at its current limit setting.

### **CC Priority**

In CC priority mode, the output is controlled by a constant current feedback loop, which maintains the output current at its programmed setting. The output current remains at its programmed setting, provided the load voltage remains within the voltage limit setting. CC priority mode is best suited for use with batteries, power supplies, large charged capacitors, and loads that are sensitive to current overshoots.

In CC priority mode, the output current should be programmed to the desired value. A positive voltage limit range should also be set. The voltage upper limit should always be set to a value that is greater than the actual input voltage requirement of the external load. The following figure shows the CC priority operating locus of the output.





The heavy solid line illustrates the locus of possible operating points as a function of output. As shown by the vertical portion of the line, the output current remains regulated at its programmed setting as long as the output voltage remains within its limit setting. A CC (constant current) status flag indicates that the output current is being regulated and the output voltage is within its limit settings.

Note that when the output voltage reaches the upper limit, the unit no longer operates in constant current mode and the output current is no longer held constant. Instead, the unit will now regulate the output voltage at its voltage limit setting.

### How to Set

The procedures to set the output priority mode are as follows.

- Press the composite keys [Shift]+[V-set] (Config) on the front panel to enter the configuration menu.
- 2. Select **Mode** and press **[Enter]** to enter into the setting interface.
- Select CC or CV, and press [Enter].
   Enter the setting interface of the loop response speed.
- Select High or Low, and press [Enter].
   At this point, return to the Config menu settings interface.
- 5. Rotate the knob to set the voltage/current rise time. When finished, press **[Enter]**.
- 6. Set the other Config menu items in the same way.
- 7. Set the output voltage and current value.
  - CV priority



- a. Press the [V-set] key on the front panel to set the output voltage value Vset.
- b. Press the **[I-set]** key on the front panel to set the current upper limit **Ilim**, and the current lower limit is 0.
- CC priority
  - a. Press the [I-set] key on the front panel to set the output current value lset.
  - b. Press the **[V-set]** key on the front panel to set the voltage upper limit **Vlim**, and the voltage lower limit is 0.

### 4.4.2 Set the Internal Resistance

This series instrument provides internal resistance setting (CV priority mode only). The procedures are shown as below.

- 1. Press the composite keys **[Shift]+[V-set]** (Config) on the front panel to enter the configuration menu.
- 2. Rotate the knob to select **Output Res** and press **[Enter]** to confirm.
- 3. Set the internal resistance value and press [Enter] to confirm.

### 4.4.3 Set the Output-On/Output-Off Delay

You can set the output-on/output-off delay time within the range from 0.001 seconds to 60 seconds.

- On Delay: Indicates from the time that a command to turn on the output is received until the output actually turns on.
- Off Delay: Indicates from the time that a command to turn off the output is received until the output actually turns off.

The procedures to set the output delay time are as follows.

- Press the composite keys [Shift]+[V-set] (Config) on the front panel to enter the configuration menu.
- 2. Rotate the knob to select **On Delay** or **Off Delay**, and press **[Enter]** to confirm.
- 3. Set the output-on/output-off delay time and press [Enter] to confirm.

# 4.5 Protection Function for Power Supply

This series instrument provides the general protection functions such as overvoltage, overcurrent, overpower, undercurrent and undervoltage protection. The corresponding protection parameters can be configured in the Protect menu. In



addition, the power supply also provides over temperature protection and Sense reverse connection protection.

The descriptions of Protect menu are listed in the table below.

Protect	Protection	Protection function menu for the power supply			
	OVP	Overvoltage pr	otection		
		Off	Turn the OVP function off. (Def)		
		On	Turn the OVP function on.		
			Level	OVP limit	
			Delay	Protection delay time, see Protection Delay.	
	OCP	Overcurrent pr	otection		
		Off	Turn the OC	CP function off. (Def)	
		On	Turn the OC	CP function on.	
			Level	OCP limit	
			Delay	Protection delay time, see Protection Delay.	
	OPP	Overpower protection			
		Off	Turn the OPP function off. (Def)  Turn the OPP function on.		
		On			
			Level	OPP limit	
			Delay	Protection delay time, see Protection Delay.	
	UCP	Undercurrent p	nt protection		
		Off	Turn the UCP function off. (Def)		
		On	Turn the UC	P function on.	
			Warm-up	Indicates the instrument warm-up time. This time is set to prevent the instrument from triggering protection when the current is rising. Because this transient condition should not be	



			considered as an undercurrent fault and there is no need to trigger protection.
		Level	UCP limit
		Delay	Protection delay time, see Protection Delay.
UVP	Undervoltage p	orotection	
	Off	Turn the UV	P function off. (Def)
	On	Turn the UV	P function on.
		Warm-up	Indicates the instrument warm-up time. This time is set to prevent the instrument from triggering protection when the voltage is rising. Because this transient condition should not be considered as an undervoltage fault and there is no need to trigger protection.
		Level	UVP limit
		Delay	Protection delay time, see Protection Delay.

### **Protection Delay**

You can specify an OCP/OVP/OPP/UCP/UVP delay to prevent momentary output settings and status changes from tripping the protection. In most cases these momentary conditions would not be considered an protection fault, and having an OCP/OVP/OPP/UCP/UVP condition disable the output when they occur would be a nuisance. Specifying an protection delay (**Delay**) can ignore these momentary changes during the specified delay period. Once the delay time has expired and the protection limit condition persists, the output will shut down.



### **Protection Prompt**

When the instrument enters the protection state, the buzzer sounds (if **Beep** menu item is set as default state **On**), the VFD status indicators **Prot** and **Off** are lit, and **[On/Off]** is turned off.

### WARNING

Although [On/Off] is turned off, there may be dangerous voltage at the output electrodes. Do not touch the wiring cable or the electrode terminals.

When protection is generated, the VFD screen displays the following information:

- The first row shows the meter voltage and the meter current value.
- The left side of the second row shows the specific protection information (such as overvoltage protection OVP), the right side shows the duration of the protection (hour: minute: second) and the number of protection information in the message queue and the total number of protection information.

Users can turn the page through the knob to view all the protection information.

### **Clear the Protection**

After the instrument triggers protection and generates a protection message, you need to troubleshoot the possible cause. When the protection is resolved, the VFD will still prompt the protection information. You can manually clear the protection information record through the following methods.

 Input a pulse signal to pin 1 of the rear panel P-IO to clear the protection information.

For details, see 5.11.1 IO-1. Ps-Clear, Not-Invert.

- Press the **[Esc]** or **[Enter]** key on the front panel to manually clear the protection information.
- Connected to the host computer, the PC sends a PROTection:CLEar command to the instrument to clear the protection information.

After the protection is cleared, you need to press the **[On/Off]** key on the front panel or send the **OUTPut ON** command to the instrument to reopen **[On/Off]**.



# 4.5.1 Set Over-Voltage Protection (OVP)

Users can enable the OVP function and set the protection limit **Level** and protection delay time **Delay**. When the voltage (i.e., the Meter value) is greater than this protection limit and the delay time is exceeded, the power supply will enter the OVP state.

### **Possible Cause**

Many reasons can cause OVP, the details are as follows:

- The set protection limit **Level** is lower than the voltage Meter value.
- The external (AC input) inputs a higher voltage.
- The power supply outputs a high voltage due to a fault.

### CAUTION

Please avoid inputting a external voltage higher than 120% rated value, or the instrument will be damaged.

### How to Set

The operation steps to set OVP are as follows.

- Press the composite keys [Protect] on the front panel to enter the protection menu. (1U Model)
- 2. Press the composite keys **[Shift]+[Recall]** (Protect) on the front panel to enter the protection menu. (2U Model)
- 3. Rotate the knob to select 1. OVP (Off) and press [Enter].
- 4. Press the left/right key or rotate the knob to select **On** and press **[Enter]** to enter the setting interface.
- 5. Set the protection limit **Level** and the delay time **Delay** in sequence, and press **[Enter]** to confirm.

The VFD screen returns to the Protect menu and the OVP setting (take 150V, 1S as an example) is displayed as follows:

```
PROTECT

1.OVP 150V, 1S
```



# 4.5.2 Set Over-Current Protection (OCP)

Users can enable the OCP function and set the protection limit **Level** and protection delay time **Delay**. When the current (i.e., the Meter value) is greater than this protection limit and the delay time is exceeded, the power supply will enter the OCP state.

### **Possible Cause**

Many reasons can cause OCP, the details are as follows:

- The set protection limit Level is lower than the current Meter value.
- The external (AC input) inputs a higher current.
- The power supply outputs a high current due to a fault.

#### How to Set

The operation steps to set OCP are as follows.

- Press the composite keys [Protect] on the front panel to enter the protection menu. (1U Model)
- 2. Press the composite keys **[Shift]+[Recall]** (Protect) on the front panel to enter the protection menu. (2U Model)
- 3. Rotate the knob to select 2. OCP (Off) and press [Enter].
- 4. Press the left/right key or rotate the knob to select **On** and press **[Enter]** to enter the setting interface.
- 5. Set the protection limit **Level** and the delay time **Delay** in sequence, and press **[Enter]** to confirm.

The VFD screen returns to the Protect menu and the OCP setting (take 10A, 1S as an example) is displayed as follows:

```
PROTECT
2.0CP 10A, 1.000S
```

## 4.5.3 Set Over-Power Protection (OPP)

Users can enable the OPP function and set the protection limit **Level** and protection delay time **Delay**. When the power (i.e., the Meter value) is greater than this protection limit and the delay time is exceeded, the power supply will enter the OPP state.



### **Possible Cause**

Many reasons can cause OPP, the details are as follows:

- The set protection limit **Level** is lower than the power Meter value.
- The power supply outputs a high power due to a fault.

### **How to Set**

The operation steps to set OPP are as follows.

- Press the composite keys [Protect] on the front panel to enter the protection menu. (1U Model)
- 2. Press the composite keys [Shift]+[Recall] (Protect) on the front panel to enter the protection menu. (2U Model)
- 3. Rotate the knob to select 3. OPP (Off) and press [Enter].
- 4. Press the left/right key or rotate the knob to select **On** and press **[Enter]** to enter the setting interface.
- 5. Set the protection limit **Level** and the delay time **Delay** in sequence, and press **[Enter]** to confirm.

The VFD screen returns to the Protect menu and the OPP setting (take 0.15KW, 1S as an example) is displayed as follows:

```
PROTECT
3.OPP 0.15KW, 1.000S
```

### 4.5.4 Set Under-Current Protection (UCP)

Users can enable the UCP function and set the instrument warm-up time **Warm-up**, protection limit **Level** and protection delay time **Delay**. When the current (i.e., the Meter value) is lower than this protection limit and the warm-up time, delay time are exceeded, the power supply will enter the UCP state.

### **Possible Cause**

Many reasons can cause UCP, the details are as follows:

- The set protection limit Level is greater than the current Meter value.
- The external (AC input) inputs a lower current.
- The power supply outputs a low current due to a fault.

### **How to Set**

The operation steps to set UCP are as follows.



- 1. Press the composite keys [Protect] on the front panel to enter the protection menu. (1U Model)
- 2. Press the composite keys [Shift]+[Recall] (Protect) on the front panel to enter the protection menu. (2U Model)
- 3. Rotate the knob to select 4. UCP (Off) and press [Enter].
- 4. Press the left/right key or rotate the knob to select **On** and press **[Enter]** to enter the setting interface.
- 5. Set the warm-up time **Warm-up**, protection limit **Level** and delay time **Delay** in sequence, and then press **[Enter]** to confirm.

The VFD screen returns to the Protect menu and the UCP setting (take 10S, 0.1A, 1S as an example) is displayed as follows:

```
PROTECT
4.UCP 10S, 0.1A, 1.000S
```

# 4.5.5 Set Under-Voltage Protection (UVP)

Users can enable the UVP function and set the instrument warm-up time **Warm-up**, protection limit **Level** and protection delay time **Delay**. When the voltage (i.e., the Meter value) is lower than this protection limit and the warm-up time, delay time are exceeded, the power supply will enter the UVP state.

### **Possible Cause**

Many reasons can cause UVP, the details are as follows:

- The set protection limit Level is greater than the voltage Meter value.
- The external (AC input) inputs a lower voltage.
- The power supply outputs a low voltage due to a fault.

### How to Set

The operation steps to set UVP are as follows.

- Press the composite keys [Protect] on the front panel to enter the protection menu. (1U Model)
- 2. Press the composite keys [Shift]+[Recall] (Protect) on the front panel to enter the protection menu. (2U Model)
- 3. Rotate the knob to select 5. UVP (Off) and press [Enter].
- 4. Press the left/right key or rotate the knob to select **On** and press **[Enter]** to enter the setting interface.



5. Set the warm-up time **Warm-up**, protection limit **Level** and delay time **Delay** in sequence, and then press **[Enter]** to confirm.

The VFD screen returns to the Protect menu and the UVP setting (take 10S, 1V, 1S as an example) is displayed as follows:

```
PROTECT 5.UVP 10S, 1V, 1.000S
```

## 4.5.6 Over-Temperature Protection (OTP)

When internal temperature of instrument is higher than about 85 °C, the instrument is under temperature protection. At this time, the instrument will automatically be **OFF** and VFD status indicator **Prot** lights up and the screen prompts **OTP**.

#### Possible Cause

To prevent damaging heat build-up and ensure specified performance, make sure there is adequate ventilation and air flow around the instrument to ensure proper cooling. Do not cover the ventilation holes on the rear panel, sides, or bottom of the instrument. Even with proper ventilation, the instrument can overheat in the following situations.

- If the ambient temperature is too high.
- If you use the instrument to test for long periods.

#### How to Set

The OTP limit does not need to be set, and the internal device of the instrument automatically detects and determines whether to enter the OTP state.

If an over-temperature condition occurs, power off the instrument and allow it to cool for at least 30 minutes. After the internal temperature of the instrument has cooled down, power it on again.

### CAUTION

When you return power to the instrument, verify that the cooling fan is running. If not, please contact ITECH Technical Support. Leaving the instrument powered on with an inoperative cooling fan may result in damage to the instrument.



### 4.5.7 Sense Reverse Protection

The instrument defaults to provide sense reverse protection. The premise is that the Sense switch is turned on. When the output state is ON and the difference between output terminal voltage and sense remote voltage exceeds the specified voltage, sense reverse protection will be enabled after 500ms. The instrument output will be immediately switched to Off and the display screen will display **SENSE ERR** if the sense terminals are reversed.

When the instrument is in Sense Reverse Protection state, you should check whether the polarities are connected reversely or not firstly. If yes, you can reopen the output after the polarities connect correctly.

The voltage difference between output terminal and remote sense terminal of each model is not the same. When the remote sense terminal is connected reversely, the maximum voltage will not exceed the sum of output terminal voltage and the difference voltage.



When Sense is reversed or short-circuited, the voltage meter value is displayed as a positive/negative value close to 0, and abnormal high voltage output does not occur, which can avoid damage to the DUT.

# 4.6 Function Menu for Power Supply

The Function menu of the power supply includes the following:

Function	Function Menu for Power Supply	
	LIST program editing, file import/export, program running (see 4.6.1 LIST Function).	
	BATTERY	Battery charging testing function (see 4.6.2 Battery Charging Test Function).

### 4.6.1 LIST Function

This series power supply supports a total of 10 List files (List01 to List10), each of which can be set up to 200 steps. You need to edit the voltage/current value, slope and time width of each step, or you can set repeat times (0 to 999999) for



each List file. After the file is edited completely, you can trigger the selected List file to run according to the selected trigger mode.

The descriptions of list function menu are listed in the table below.

LIST	List mer	List menu			
	Run	Indicates to enter the List run mode, waiting for the trigger to run the currently selected List file.			
	Open	Select the	e List file to open.		
		USB	Open the List	file in the external USB flash disk.	
			Load	Import the List file from the exter- nal USB flash disk into the instrument.	
			Not-Load	Cancel the import operation.	
		Internal	Open the List	file stored inside the instrument.	
			Recall Inner Set the name of the recalled List file.		
	Export	Export the USB flash	the internal List file of the instrument to an external a drive.  The name of the exported list file. The default suffix is .csv, and the file name can only be a string of numbers.		
		File Name			
	Edit	Edit list pr	ogram.		
		CC / CV	Set the operation mode for list program: CC priority or CV priority.		
		Step Count	The total num program.	ber of steps included in the List	
		Step 1 Value	Current value or voltage value setting for Step1. (The voltage appears when CV priority is selected; the current appears when CC priority is selected.)		
		Step 1 Slope	Slope value setting for Step1.  Dwell time setting for Step1. The range is from 0.001 to 21000 in seconds.		
		Step 1 Width			
		Repeat	Set the numb	er of list file repetitions.	



	End State	Set the running state after the list program is running over.	
		Last	After the List program finishes running, the output is kept as the setting in the last step, and the working mode remains as the setting in the List file.
			None: No trigger signal output.
			Tout: There is a trigger signal output.
		Normal	After the List program finishes run- ning, the working mode and volt- age/current output return to the settings before the List running.
			None: No trigger signal output.
			Tout: There is a trigger signal output.
		OFF	After the List program finishes running, the output of the instrument is turned off.
			None: No trigger signal output.
			Tout: There is a trigger signal output.
	Save to group	Save the edited List program.	

# **Edit List Program**

The following takes CC priority mode as an example to introduce the operation of editing two test steps.

- 1. Press the composite keys [Shift]+[I-set] (Function) on the front panel to enter the function menu.
- 2. Select 1. LIST: Off and press [Enter].
- 3. Rotate the knob to select **Edit** and press **[Enter]** to enter the editing interface.



- 4. Select CC and press [Enter] to confirm.
- 5. Set the total number of steps in the List program and press **[Enter]** to confirm.
- 6. Set the current, slope and time width of step 1 in turn, and press **[Enter]** to confirm.
- 7. Set the parameters of step 2 in the same method.
- 8. Set the number of list repetitions **Repeat**, and press **[Enter]** to confirm.
- 9. Set the **End State** as **Normal**, and press **[Enter]** to confirm.
- 10. Depending on the test requirement, choose whether to turn on the function switch that triggers synchronization.
- 11. Set the currently edited List program name.

If you choose not to save, press [Esc] to exit the editing interface.

### **Import List Program**

If you need to run the List program on the external USB flash drive, you need to import the List program from the USB flash drive into the instrument.



The format of the List file in the USB flash drive must be in .csv format and saved in the root directory of the USB flash drive. You can refer to Export List Program to customize editing according to the List file template exported to the USB flash drive.

The procedures are as follows:

- 1. Insert the USB flash drive into the front panel USB connector.
- 2. Press the composite keys [Shift]+[I-set] (Function) on the front panel to enter the function menu.
- 3. Select 1. LIST: Off and press [Enter].
- 4. Press the Left/Right key to select **Open** and press **[Enter]**.
- 5. Select **USB** and press **[Enter]**.

Rotate the knob, and the system will automatically read all .csv format files in the root directory of the USB flash drive at this time. The interface is displayed as follows:

```
XXX.csv
Not-Load Load YY/ZZ
```

XXX indicates the name of the List file; YY indicates the serial number of the current List file; ZZ indicates the total number of the List file.



- 6. Rotate the knob to select the List file.
- 7. Press the Left/Right key to select **Load**, press **[Enter]** to complete the import, and wait for the trigger to run this List file.

At this point, the interface returns to the main interface of the system and **LIST RUN** is displayed in the lower right corner.

#### **Select Internal List Program**

You can select a List file saved inside the instrument to be in the **Open** state and wait for subsequent triggers to run. The procedures are as follows:

- 1. Press the composite keys [Shift]+[I-set] (Function) on the front panel to enter the function menu.
- 2. Select 1. LIST: Off and press [Enter].
- 3. Press the Left/Right key to select **Open** and press **[Enter]**.
- 4. Press the Left/Right key to select **Internal** and press **[Enter]**.
- 5. Set the name of the List file to be recalled (that is, the file name set in **Edit**), and press **[Enter]**.

The interface returns to the main interface of the LIST function, which is displayed as follows:

```
FUNCTION LIST
Run Edit Open Export
```

If you select **Run** and press **[Enter]**, the instrument will enter LIST mode and wait for the trigger to run.

#### **Export List Program**

Supports exporting the internal List file to an external USB flash drive. The exported List file is saved in **.csv** format.

- 1. Insert the USB flash drive into the front panel USB connector.
- 2. Press the composite keys [Shift]+[I-set] (Function) on the front panel to enter the function menu.
- 3. Select 1. LIST: Off and press [Enter].
- 4. Press the Left/Right key to select **Open** and press **[Enter]**.
- 5. Press the Left/Right key to select **Internal** and press **[Enter]**.
- 6. Set the name of the List file to be recalled (that is, the file name set in **Edit**), and press **[Enter]**.



The interface returns to the main interface of the LIST function, which is displayed as follows:

```
FUNCTION LIST
Run Edit Open Export
```

- 7. Press the Left/Right key to select **Export** and press **[Enter]**.
- 8. Press the Left/Right key to select **Yes** and press **[Enter]**.
- 9. Set the name of the List file to be exported, and press [Enter].

Indicates that the selected List file in **Open** is exported to the USB flash drive

#### **Run the List Program**

You can select a List file to execute according to your needs, so that the power supply outputs the corresponding waveform sequence. Take the List file in **Internal** as an example. The steps are as follows:

- 1. Press the composite keys [Shift]+[I-set] (Function) on the front panel to enter the function menu.
- 2. Select 1. LIST: Off and press [Enter].
- 3. Press the Left/Right key to select **Open** and press **[Enter]**.
- 4. Press the Left/Right key to select Internal and press [Enter].
- 5. Set the name of the List file to be recalled (that is, the file name set in **Edit**), and press **[Enter]**.

The interface returns to the main interface of the LIST function, which is displayed as follows:

```
FUNCTION LIST
Run Edit Open Export
```

Press the Left/Right key to select Run and press [Enter].

At this point, the interface returns to the main interface of the system and **LIST RUN** is displayed in the lower right corner.

- 7. Turn on the [On/Off].
- 8. Based on the selected trigger method, perform the trigger operation.

Take the manual trigger as an example. Press [Shift]+[On/Off](Trigger) on the front panel to run the selected List file. For details about the List trigger method, see 5.8 Select Trigger Source (Trig Source).



### Note

- The system will adjust the working mode of the power supply according to the CC or CV priority mode set in the List file. For example, if the current power supply is in the CV priority mode, and the list file to be run is set to the CC priority mode, then the power supply will work in the CC priority mode after the List file is triggered to run.
- After the List file finishes running, the system determines whether to return
  to the working mode before the List is run according to the Normal, Last or
  Off option you selected.

#### **Stop Running the List Program**

When the List program is running, if you need to stop running, you can do the following: Press the composite keys **[Shift]+[I-set]** (Function) on the front panel to enter the function menu.

At this point, the interface will prompt whether to stop the running of the Function, you can press the Left/Right key to select **Stop**, then the running will be stopped, and the Function menu item will be displayed, you can re-enter the Function menu for editing; if **Reset** is selected, it means to stop the present running and return to the main interface to wait for the next trigger operation; if **Pause** is selected, it means that the present running is suspended, and you can continue to run by selecting **Resume**.

#### 4.6.1.1 ARB Function

This series of instruments comes standard with ARB (arbitrary waveform) function, which allows the output of user-defined arbitrary complex voltage or current waveforms. It can be operated in the following ways:

#### Import via U disk

The instrument supports importing the edited .csv format file (the template can be downloaded from ITECH official website or contact ITECH to obtain) through the USB interface on the front panel, and generating voltage or current values after parsing, and then outputting complex voltage or current waveforms according to the time width specified by the user. The user can edit a .csv file containing up to 10 million voltage or current points and import it into the instrument for running to realize arbitrary waveform output or working condition simulation. The instrument has the ability to quickly parse data. A .csv file of dozens of megabytes can be imported and parsed within 5S, making testing more convenient and efficient.

This instrument supports importing the **.csv** files corresponding to the following waveforms:

CDWELL: Constant dwell arbitrary waveform



List: User-defined waveform

Sine: Sine wave

Sweep: Sweep wave

The steps are as follows:

- 1. Edit the .csv file corresponding to the template on the PC and save it.
- 2. Save the edited file in the root directory of the U disk.
- 3. Insert the U disk into the front panel of the instrument.
- 4. Press the composite keys **[Shift]+[I-set]** (Function) on the front panel to enter the function menu.
- 5. Select the 1. LIST: Off and press [Enter].
- 6. Press left/right key to select **Open** and press **[Enter]**.
- 7. Select the **USB** and press [Enter].

Rotate the knob, and the system will automatically read all .csv format files in the root directory of the USB flash drive at this time. The interface is displayed as follows:

```
XXX.csv
Not-Load Load YY/ZZ
```

XXX indicates the name of the List file; YY indicates the serial number of the current List file; ZZ indicates the total number of the List file.

- 8. Rotate the knob to select the file.
- 9. Press the Left/Right key to select **Load**, press **[Enter]** to complete the import, and wait for the trigger to run this file.
- 10. Turn on the [On/Off].
- 11. Based on the selected trigger method, perform the trigger operation.
- Programming via SCPI instructions

For detailed instructions and parameter introduction, please refer to the instructions of "ARB Subsystem" in the Programming Guide.

Realized by the software IT9000 on PC

For detailed function usage, please refer to IT9000-PV3900 User Manual.

### 4.6.2 Battery Charging Test Function

This series power supply provides the battery charging test function. Suitable for charging tests on all types of portable batteries.



#### WARNING

- When connecting the DUT (battery/capacitor), do not short-circuit the battery/capacitor.
- When connecting the DUT (battery/capacitor), it is recommended that you purchase the IT-E165A anti-reverse connection and antispark module to prevent the battery/capacitor reverse connection that may cause damage to the instrument and spark during the battery/capacitor wiring; When there is no external auxiliary equipment connected to prevent reverse connection and anti-spark function, please pay attention to the safety of the wiring, and be careful not to reverse the battery/capacitor connection, reverse connection will cause damage to the instrument.
- Before performing the battery test, you need to connect the Sense cables to both ends of the battery. If the Sense cables are not connected, the instrument cannot detect the Sense voltage and prompt "Wait Power Link", which will prevent the battery test from continuing.

BATTERY	Battery charging test function			
	Run	Indicates that the battery test mode is entered and waits to trigger the running of the currently edited battery test file.  Edit the battery charging test file.		
	Edit			
		Charge V	Set the voltage value of the battery charging test.	
		Charge I	Set the current value of the battery charging test.	
		Charge Time	Set the battery charging time.	
		Cut Off Voltage	Battery test cut-off voltage	
		Cut Off Current	Battery test cut-off current	
		Cut Off Capacity	Battery test cut-off capacity	

- 1. Press the composite keys [Shift]+[I-set] (Function) on the front panel to enter the function menu.
- 2. Use knob to select 2.BATTERY: Off and press [Enter].



The interface is displayed as follows:

FUNCTION BATTERY Run Edit

- 3. Press the Left/Right key to select **Edit** and press **[Enter]**.
- 4. Set the charging voltage (**Charge V**), charging current (**Charge I**) and the other parameters, and then press [**Enter**] to confirm.

After the parameter setting is completed, the interface returns to the Battery function main interface and displays as follows:

FUNCTION BATTERY Run Edit

5. Press the Left/Right key to select **Run** and press **[Enter]** to run the battery test.



This product supports Sense anti-reverse function. If you reverse the Sense cables, the VFD will display a negative voltage value, and you cannot turn on the output at this time. It can only be turned on after the cables are properly connected.

6. Based on the selected trigger method, perform the trigger operation.



The trigger method of the battery test is consistent with the trigger method of the List function, that is, the List trigger source is also effective for the Battery function.

If you want to stop running during the battery test, you can do the following: Press the composite keys **[Shift]+[I-set]** (Function) on the front panel to enter the function menu.

At this point, the interface will prompt whether to stop the running of the Function, you can press the Left/Right key to select **Stop**, then the running will be stopped, and the Function menu item will be displayed, you can re-enter the Function menu for editing; if **Reset** is selected, it means that it will not stop running, it will return to the main interface, and run Battery again.



# 5 Basic Operation

This chapter describes the basic functions and features of the instrument. Divided into the following sections:

- ◆ Local/Remote Mode Switch
- ♦ Key Lock Function
- ◆ Save and Recall Operations
- ◆ Data Logging Function
- ◆ Set the Beeper Status (Beep)
- ◆ Set the Power-on State (PowerOn)
- Sense Function (Sense)
- ◆ Select Trigger Source (Trig Source)
- ♦ Set the Communication Information (I/O Con)
- ◆ Set Parallel Operation Mode (Parallel)
- ◆ Digital I/O Function (Digital Port)
- ◆ Analogue Function (Ext-Program) (Optional)
- ♦ View the System Information (System Info)
- ◆ Restored to Factory Setting (System Reset)
- System Upgrade

### 5.1 Local/Remote Mode Switch

The power supply provides both local and remote operation modes. The default mode of the power supply is local operation mode.

- Local operation mode: Use the front panel keys to control the power supply.
- Remote operation mode: The power supply is connected to PC, and the user uses the software in PC to control the power supply remotely.
  - During remote control operation, the remote symbol "Rmt" is displayed.
     All panel keys, except the [On/Off] and [Shift]+[3] (Local) keys, are locked.
  - You can press [Shift]+[3] (Local) to switch the remote control to local control. The mode modification will not affect the output parameters of the power supply.

# 5.2 Key Lock Function

This function can prevent the power supply from the panel keys misoperation during usage. Press the composite keys **[Shift]+[2]** (Lock) to lock front panel keys and the lock symbol "\*" is shown on the front panel display. All panel keys,



except the **[On/Off]** and **[Shift]+[2]** (Lock) keys, are locked. You can repress **[Shift]+[2]** (Lock) to unlock the front panel.

# **5.3 Save and Recall Operations**

This series power supply can save up to 10 common parameters in nonvolatile memory (No. 1 to No. 10) for user to recall conveniently. The saved settings include the following parameters.

Category	Parameter		
Main interface	Voltage setting: Vset		
	Current setting: Iset		
	Upper limit of voltage: Vlim		
	Upper limit of current: Ilim		
	Upper limit of power: Plim		
	The output status of the instrument: [On/Off]		
Config menu	CC/CV loop priority mode: Mode		
	CC/CV loop speed: Speed		
	Voltage/Current rise time: V-Rise Time/I-Rise Time		
	Voltage/Current fall time: V-Fall Time/I-Fall Time		
	On/Off switch delay: On Delay/Off Delay		
	Internal resistance of the power supply: Output Res		
Protect menu	OCP/OVP/OPP/UCP/UVP switch status: On/Off		
	OCP/OVP/OPP/UCP/UVP limit setting: Level		
	OCP/OVP/OPP/UCP/UVP delay time: Delay		
	UCP/UVP warm-up time: Warm-up		

### 5.3.1 Save Operation

The save operation procedures are as follows:



- 1. Press the composite keys [Shift]+[Recall] (Save) to enter the parameter save interface. (1U Model)
- 2. Press the composite keys [Shift]+[+/-] (Save) to enter the parameter save interface. (2U Model)
- 3. Set the storage location.

Enter a number in the "Save data to bank=1" to set the storage location in non-volatile memory.

4. Press [Enter] to save the parameters.

### 5.3.2 Recall Operation

You can recall the parameters you saved in the specified memory location as the setting values.

- 1. Press [Recall] to enter the parameter recall interface.
- 2. Set the storage location.

Enter a number in the "Recall data from bank=1" to set the storage location in non-volatile memory.

3. Press [Enter] to recall the parameters.

# 5.4 Data Logging Function

This series High power Programmable DC Power Supply supports the recording and saving of test data. This Chapter introduces how to use this function in details.

The user can select the following data sources for recording:

Voltage

Only records voltage data during the data acquisition period.

Current

Only records current data during the data acquisition period.

Voltage and current

Records current and voltage data during the data acquisition period.

#### **Configure the Function Menu**

1. Press the composite button [Shift]+[1] (Log) on the front panel to enter the configuration menu of the data logging function.



The parameters are described as follows:

Menu Item	Description	Setting
Sample Period	This parameter indicates the data sampling interval (unit: s), that is, the test data is recorded once every <i>X</i> seconds.  The input range supported by the instrument is: 0.0001-100s	Set the value by inputting the value
Duration	This parameter indicates the time for data recording (unit: s), namely, the data recording will be completed in Y seconds and be ready for the next data record.  The input range supported by the instrument is: 0-50000000s	through the number key or rotating the knob.
Source	This parameter indicates the source of recorded data, including voltage (V), current (I), voltage and current (V+I).	
Data Type	This parameter indicates the type of recorded data, including:  • Aver: This is the default selected data type, namely, the average of all data acquired in the data recording period as indicated in the table of saved data.	Use the Left and Right arrow key or the rotation knob to select.
	Aver+Max+Min: If this option is selected, it means the average value, maximum value and minimum value of data acquired in the data recording period as indicated in the data saving table.	

- 2. Set the value of **Sample Period** and press **[Enter]**.
- 3. Set the value of **Duration** and press **[Enter]**.
- 4. Set the value of **Source** and press **[Enter]**.
- 5. Set the value of **Data Type** and press [Enter].



#### **Select the Trigger Method**

See the steps in the 5.8 Select Trigger Source (Trig Source) section to set how the data logging is triggered.



This setting result is only valid for data recording function. When List function is used, the method for triggering the running of List files needs to be additionally set (by default, triggered by the panel).

#### Start Data Logging

#### CAUTION

- Before this operation, make sure to connect the USB memory device to the memory port on the front panel (The USB interface on the rear panel can only be used for connecting the PC) so that the recorded data can be stored in the external storage device. Otherwise, the Data Recording function is not available for usage.
- Do not connect the USB communication interface on the rear panel to the PC, otherwise the Data Recording function will be unavailable. If you need a communication connection with a PC, use a communication interface other than USB, such as LAN.

#### Trigger immediately

Perform a trigger operation immediately.

#### Manual

Press the composite button **[Shift] + [On/Off]** (Trigger) on the front panel to trigger.

#### Bus

Triggered by the SCPI instruction, for example, when the instrument receives the trigger command \*TRG, a trigger operation is performed.

#### Voltage trigger

When the DC terminals detect that the voltage reaches the trigger voltage setting value and is within the range of the upper and lower trigger limits, a data recording operation is triggered.

- Level: Trigger threshold.
- Up-Level: Trigger upper limit value.



Down-Level: Trigger lower limit value.

#### Current trigger

When the DC terminals detect that the current reaches the trigger current setting value and is within the range of the upper and lower trigger limits, a data recording operation is triggered.

- Level: Trigger threshold.
- Up-Level: Trigger upper limit value.
- Down-Level: Trigger lower limit value.

#### External

Connect to pin 4 of the digital I/O interface (P-IO) and set pin 4 to **Ext-Trig→- Trig-In→Dlog** to trigger.

For details, see 5.11.4 IO-4.Trig(in), Not-Invert.

After the data recording function is started, the recorded data is saved in USB memory device in .csv format. The user can get access to these files for analysis based on needs.

# 5.5 Set the Beeper Status (Beep)

The user can turn the instrument beeper sound on or off base on personal requirement.

The beeper sound works in the following scenarios:

- A beeper sound produced when the front panel key is pressed.
- When an error is generated inside the instrument, such as when the instrument receives an unprocessable command in the remote state. At this time, the instrument produces a beeper sound, and the flag "Error" appears on the VFD.
- When the instrument is under protection status, such as over-temperature protection. At this time, the instrument produces the beeper sound.

The setting procedures are as follows:

Press the composite keys [Shift]+[P-set] (System) on the front panel to enter the system menu.

The first displayed menu item **Beep** is used to set the beeper status.

- 2. Press [Enter] key to enter the parameter setting interface.
- 3. Press the Left / Right key or turn the knob to adjust the value of this parameter.



- On: Default value, indicates the beeper is on.
- Off: Indicates the beeper is off.
- 4. After the parameter settings are complete, press [Enter].

At this point, the beeper status takes effect immediately.

### 5.6 Set the Power-on State (PowerOn)

This menu item is used to control the settings and output state when the power supply is powered on.

The detailed power-on parameters and output state are as follows.

- The voltage, current, power setting values displayed on the main interface when the instrument is powered on.
- Parameter setting values in the Config menu.
- The output state of the power supply, i.e., the [On/Off] key state.

The procedures to set the menu item are as follows.

- Press the composite keys [Shift]+[P-set] (System) on the front panel to enter the system menu.
- 2. Turn the knob to select the **PowerOn** and press [Enter].
- 3. Press the Left / Right key or turn the knob to adjust the value of this parameter.
  - Reset: Default value, indicates when the instrument is powered on, the instrument will initialize some parameter settings or state.

The affected parameters and the reset information are as shown in the following table.

Table 5-1 Initial value of the parameter

Category	Parameter	Initial Value
Main interface	Voltage setting: Vset	0.002V(10V models) 0.2V(Other models)
	Current setting: Iset	One percent of the rated current of the instrument
	Upper limit of voltage: Vlim	Upper limit value: 0.002V(10V models)



Category	Parameter	Initial Value
		Upper limit value: 0.2V (Other models)
	Upper limit of current: Ilim	One percent of the rated current of the instrument
	Upper limit of power: Plim	Rated power value of the instrument
	[On/Off] status	Off
Config menu	Mode	CV
	Speed	High
	V-Rise Time/I-Rise Time	0.1s
	V-Fall Time/I-Fall Time	
	Output Res	1000
	On Delay/Off Delay	0

- Last: Indicates when powered on, the instrument will remain the same parameter settings and output status as last time you powered off the instrument.
- Last+Off: Indicates when powered on, the instrument will remain the same settings as last time you powered off the instrument, but the output status is Off.
- 4. After the parameter settings are complete, press [Enter].

For example, **Last** is selected, and the voltage value is set to 8V. After the instrument is powered off and then powered on, the voltage displayed on the interface is 8V.

# 5.7 Sense Function (Sense)

This menu item is used to switch the power supply to local measurement or remote sensing.

This series power supply supports two connection methods: Local measurement and Remote sensing. The remote sensing is used for maximizing measurement accuracy. (Refer to 2.4 Connecting the Device Under Test (DUT))



The procedures to set the menu item are as follows.

- 1. Press the composite keys [Shift]+[P-set] (System) on the front panel to enter the system menu.
- 2. Turn the knob to select the **Sense** and press [Enter].
- 3. Press the Left / Right key or turn the knob to adjust the value of this parameter.
  - Off: Default value, indicates turn the sense function off.
  - On: Indicates turn the sense function on.
- 4. After the parameter settings are complete, press [Enter].

# **5.8 Select Trigger Source (Trig Source)**

For this series power supply, the List and data logging functions can be triggered for running by the following methods:

- Immediate: Perform a trigger operation immediately.
- Manual: Default value, indicates the trigger occurs when the [Shift]+[On/Off] (Trigger) keys are pressed from the front panel.
- Bus: Indicates the trigger occurs via the communication cables. When the trigger command \*TRG is received, the instrument generates a trigger.
- Voltage (only available in DLogTrig Source): Voltage trigger.

When the DC terminals detect that the voltage reaches the trigger voltage setting value and is within the range of the upper and lower trigger limits, a data recording operation is triggered.

- Level: Trigger threshold.
- Up-Level: Trigger upper limit value.
- Down-Level: Trigger lower limit value.
- Current (only available in DLogTrig Source): Current trigger.

When the DC terminals detect that the current reaches the trigger current setting value and is within the range of the upper and lower trigger limits, a data recording operation is triggered.

- Level: Trigger threshold.
- Up-Level: Trigger upper limit value.
- Down-Level: Trigger lower limit value.



 External: Indicates the trigger occurs via the pin 4 of the digital I/O interface (P-IO).

For details, see 5.11.4 IO-4.Trig(in), Not-Invert.

The List function and the data logging function have the same steps for selecting the trigger source. They need to be set separately in different menu items (**ListTrig Source** and **DLogTrig Source**). Therefore, this section takes the List trigger source setting as an example to introduce the operation steps.

- 1. Press the composite keys [Shift]+[P-set] (System) on the front panel to enter the system menu.
- 2. Turn the knob to select the **ListTrig Source** and press [Enter].



- When setting the trigger source for data logging, select the DLogTrig Source menu item.
- The List trigger source set here is also valid for triggering other functions in the **Function** menu.
- 3. Press the Left / Right key or turn the knob to adjust the value of this parameter.
- 4. After the parameter settings are complete, press [Enter].

# 5.9 Set the Communication Information (I/O Con)

This menu item is used to set the communication information between instrument and PC. The standard communication interfaces for this series power supply are USB, LAN, CAN and VCP. You can also select the non-standard interface GPIB or RS-232 or EtherCAT based on personal requirement.

The procedures to set the menu item are as follows.

- 1. Press the composite keys [Shift]+[P-set] (System) on the front panel to enter the system menu.
- 2. Turn the knob to select the I/O and press [Enter].
- 3. Press the Left / Right key or turn the knob to adjust the value of this parameter.
- 4. After the parameter settings are complete, press [Enter].



### Note

- The default communication method is USB. If other communication method is selected, the related parameters need to be set. For detailed parameter description, refer to 2.5 Remote Interface Connection.
- The instrument supports the non-standard RS-232, GPIB and EtherCAT interfaces, and the configuration items in the menu are dynamically displayed according to the interface user selected.

# 5.10 Set Parallel Operation Mode (Parallel)

This menu item is used to control whether the instrument is working in single mode or in parallel mode. This chapter takes three instruments as an example to describe how to parallelize the single units and how to return from parallel mode to single mode.

The maximum power of this series power supply is 12 kW. The user can connect power supply in parallel to provide a greater current and power capability. The following figure shows three units connected in parallel, the fiber optical is used as connection between master and slaves.



• This series 10V of 2U models can support up to 8 units in parallel, other models can support up to 16 units in parallel.

#### Configure the Menu Item

- 1. Press the composite keys [Shift]+[P-set] (System) on the front panel to enter the system menu.
- 2. Turn the knob to select the **Parallel** and press **[Enter]**.
- 3. Press the Left / Right key or turn the knob to adjust the value of this parameter.
  - Single: Default value, indicates that the instrument is in single mode.
  - Master: Indicates that the current single unit is set to master in parallel mode. When set to Master, you also need to set the number of slaves to be mounted for the master, so you need to set the value of the Total parameter. For example, setting Total = 3 means that the total number of units in the parallel relationship is 3.





In the parallel mode, you only need to operate the master. Synchronous operations on other slaves are implemented by operating the master.

- Slave: Indicates that the instrument is set to the slave in parallel mode.
- 4. After the parameter settings are complete, press [Enter].

#### **Set the Parallel Mode**

#### CAUTION

- Before connecting the fiber optical, you must ensure that each instrument is in single mode (Single).
- Fiber optic cables cannot be flexed or folded. When the cable is too long and needs to be arranged, gently wrap the cable in a circle and gently tie it.

#### WARNING


- Before connecting the cables, ensure that the instrument power switch is off and the main switch of the AC power input (distribution box) is off.
- Before connecting 3 single instruments to the AC distribution box, ensure that the distribution box capacity is sufficient. Refer to the corresponding specifications for the AC input parameters of a single instrument.

The operation steps of parallel function are described below taking 3 instruments (1 Master and 2 Slave) in parallel as an example.

- 1. Ensure that the power switches of the three units and the main switch of the AC power distribution box are off.
- 2. Refer Figure 5-1 Wiring connection diagram to connect three units.




Figure 5-1 Wiring connection diagram



- a. Connect the AC input terminals of the three units separately, and connect them to the AC distribution box.
- b. Connect the DC output terminals of the three units in parallel and connect them to the DUT.
- c. Refer to the blue wiring legend in the figure, connect the fiber optical (i.e., the fiber outer ring interfaces TX and RX) for fiber-optic communication between the master and slaves.

Insert the fiber optic module into the hole corresponding to TX, RX. Insert the plug of the fiber optic cable into the fiber optic module and hear a click sound to indicate that it is inserted in place.



- 3. Turn on the main switch of the AC distribution box and power on each of the three units.
- 4. Set three units in parallel mode with one master and two slaves.
  - a. Press the composite keys [Shift]+[P-set] (System) on the front panel to enter the system menu.
  - b. Set Parallel to Master or Slave and press [Enter].
  - c. After setting the Master, you need to set Total to 3.

For details, see Configure the Menu Item.



5. After the parallel menu of the three units are set, restart the instrument separately.

After the instrument is restarted, the VFD shows that the instrument is working in parallel mode.

#### **Revert to Single Mode**

- 1. Set each of the three instruments to single mode.
  - a. Press the composite keys [Shift]+[P-set] (System) on the front panel to enter the system menu.
  - b. Set the Parallel to Single.

For details, see Configure the Menu Item.

- 2. Power off the three instruments and turn off the main switch of the AC distribution box.
- 3. Remove the cables connection of the fiber optical and DC output terminals between three units.
- 4. Power on the three instruments separately.


After the instrument is restarted, the VFD shows that the instrument is working in single mode.

# **5.11 Digital I/O Function (Digital Port)**

This series power supply supports digital I/O function. The user can realize logic control over signal input or output by related configurations in the system menu.

#### **Pins Introduction**

Different I/O implements different functions. The detailed functions description are shown in the figure below:



Pin	Туре	Description (Default function)	Properties
1	Input/Output	Ps-Fault-Clear, clear the protection state.	Pulse signal
2	Input/Output	Ps, protection state indicator.	Level signal



Pin	Туре	Description (Default function)	Properties
3	Input/Output	Off-Status, OnOff-status indicator.	Level signal
4	Input/Output	Trig(in), trig signal.	Pulse signal
5	Input/Output	INH-Living, Turn off the output under emergency status.	Pulse signal
6	Input/Output	Sync-On, synchronous on control.	Pulse signal
7	Input/Output	Sync-Off, synchronous off control.	Pulse signal
GND	Ground terminal, that is, the negative terminal corresponding to each of the above 7 pins.		



In this chapter, all the pulse signals involved in the digital I/O function are switched from high level to low level.

### **General Digital I/O Function**

#### Signal definition

Digital I/O functions involve input and output levels and pulse signals. The input signal is the control signal provided externally to , the output signal is the level signal provided externally by , and the pulse signal is the edge signal switched between high and low levels.

		Typical: 5V
	High level signal	Range: 1.6V-15V
Input signal		Current: ≤100mA
input signal		Typical: 0V
	Low level signal	Range: -5V-0.8V
		Current: ≤100mA
Outrot singel	High level signal	Voltage level: 5V
Output signal	Low level signal	Voltage level: 0V
	Level rise slope	10us
Pulse	Level fall slope	2us
	Width	30us




#### Input/Output Function

The IO-1  $\sim$  IO-7 pins are featured default function, the user can setting the function of pin according to requirement. The Input and Output are the general digital I/O function, and the parameter settings and functions of the seven pins are the same.

The IO-1~IO-7 pins provide default functions. Users can realize control according to the functions defined. Users can also reset the input or output properties of the present pin and customize the function use of the pin according to their needs.

- When pins 1 to 7 are configured to Output function, either high level (False) or low level (True) can be Output.
- When pins 1 to 7 are configured to Input function, an external signal can be Input to this pin, and the instrument can detect the state of the external signal.
- Under the default condition (Not-Invert), when the pin (1 to 7) is configured as Output→PWM, the user needs to set the frequency (PWM Freq) and duty cycle (PWM Duty) values. For example, if the PWM Freq is set to 100Hz and the PWM Duty is set to 10%, the output waveform is as follows:





In the above figure, the peak voltage (minimum value) is 5.16V and the cycle is 10ms. The high level duration is 9ms and the low level duration is 1ms in one cycle.

#### Signal Revert

Select Invert or not under the IO Settings menu. If setting to Not-Invert, it means the default level will be valid. If setting to Invert, it means the valid signal is reversed. For example, the IO-5 pin is inhibit output by default and the high level is valid, when select revert Invert, the low level is valid and the instrument output is disabled.



# 5.11.1 IO-1. Ps-Clear, Not-Invert

IO-1 pin can be set to 【Ps-Clear】, 【Input】, 【Output】.

### **Parameter Description**

IO–1. Ps-Clear, Not-Invert	Parameter setting for pin 1.				
	Not- Invert	pulse or Inver			nput/output
		Ps- Clear	the inst	trument genera tection state ca	means that when ates protection, an be cleared via
		Input	Pin 1 re	eceives the lev side.	el signal from
		Output		ends the digita to the outside.	l signal (1, 0,
			True	output digital	ot-Invert), the signal is 1 (i.e. d in the case of atput is high
			False	output digital high level), aı	ot-Invert), the signal is 0 (i.e. nd in the case of utput is low level.
			PWM	Digital signal	of PWM.
				PWM Freq	Frequency
				PWM Duty	Duty cycle

#### **How to Use**


When pin 1 is set to default **Ps-Clear** function, pin 1 has bi-directional I/O function, which can receive pulse signal input from the external instrument and also



can output pulse signal to external instrument. Pulse signal parameter requirements are as follows:

Level rise slope	10us
Level fall slope	2us
Minimum time width for low level keep	30us

- Pulse input: When the instrument is under protection, the instrument will clear protection after receiving the pulse signal from external input.
  - 1. Refer to the figure below to connect pin 1 to the external oscilloscope.



- 2. Confirm that pin 1 function is set to the default option, namely IO-1. Ps-Clear, Not-Invert.
- 3. Taking OVP as an example, set the protection point of OVP.
- 4. Build the test environment to enable the instrument to enter the OVP state.
- 5. Send pulse signal to pin 1.
- 6. Check whether the protection state of this instrument is cleared.
- Pulse output: When the instrument's protection state is released, and [On/Off] is from Off to On, pin 1 will send a pulse signal to the external instrument.
  - 1. After confirming that the instrument's OVP protection is cleared, manually turn on **[On/Off]**.
  - 2. Check the oscilloscope and confirm whether pin 1 has pulse output.



# 5.11.2 IO-2. Ps, Not-Invert

IO-2 pin can be set to 【Ps】, 【Input】, 【Output】.

### **Parameter Description**

IO-2. Ps, Not- Invert	Parameter setting for pin 2.				
	Not- Invert	Indicates whether to invert the input/output pulse or level signal.  Invert: Yes  Not-Invert: No			
		Ps This default function means the output level from pin 2, which displays that whether the instrument is under protection or not.		h displays that	
		Input Pin 2 receives the level signal from the outside.		el signal from	
		Output Pin 2 sends the digital signal (1, 0, PWM) to the outside.			
			True	output digital	l <b>ot-Invert</b> ), the signal is 1 (i.e. and in the case of utput is high
			False	output digital high level), a	lot-Invert), the signal is 0 (i.e. nd in the case of utput is low level.
		PWM Digital signal of PWM.		of PWM.	
				PWM Freq	Frequency
				PWM Duty	Duty cycle

#### **How to Use**

When pin 2 is set to default **Ps** function, pin 2 will output high or low level based on whether the instrument is under protection or not. Under normal conditions




(Not under protection), and when pin 2 is under default setting (**Not-Invert**), pin 2 outputs high level; when the instrument is under protection, pin 2 outputs low level.



When pin 2 is set to **Invert**, the output level is completely opposite.

1. Refer to the figure below to connect pin 2 to the external oscilloscope.



- 2. Confirm that pin 2 function is set to the default option, namely IO-2. Ps, Not-Invert.
- 3. Taking OVP as an example, set the protection point of OVP.
- 4. Build the test environment to enable the instrument to enter the OVP state.
- 5. Check the oscilloscope and confirm that pin 2 outputs low level.

### 5.11.3 IO-3. Off-Status, Not-Invert

IO-3 pin can be set to 【Off-Status】, 【Input】, 【Output】.

#### **Parameter Description**

IO-3. Off-Status, Not-Invert	Parameter setting for pin 3.		
	Not- Invert	Indicates whether to invert the input/output pulse or level signal.  Invert: Yes  Not-Invert: No	



	Off- Status		This default function indicates the existing <b>[On/Off]</b> state of the instrument.			
		Input		Pin 3 receives the level signal from the outside.		
		Output	Pin 3 sends the digital signal (1, 0, PWM to the outside.			
			True	put digital sign	t-Invert), the out- al is 1 (i.e. low lev- case of Invert, the evel.	
		False	put digital sign	<b>t-Invert</b> ), the out- al is 0 (i.e. high ne case of <b>Invert</b> , w level.		
		PWM	Digital signal o	f PWM.		
				PWM Freq	Frequency	
				PWM Duty	Duty cycle	

#### **How to Use**


When pin 3 is set to default **Off-Status** function, pin 3 will trigger level output based on the **[On/Off]** state of the instrument. When it is set to **(Not-Invert)**, the **[On/Off]** is turned off, and pin 3 outputs high level; the **[On/Off]** is turned on, and pin 3 outputs low level.



When pin 3 is set to **Invert**, the output level is completely opposite.

1. Refer to the figure below to connect pin 3 to the external oscilloscope.





- 2. Confirm that pin 3 function is set to the default option, namely IO-3. Off-Status, Not-Invert.
- 3. Turn on [On/Off].
- 4. Check the oscilloscope and confirm that pin 3 outputs low level.

# 5.11.4 IO-4.Trig(in), Not-Invert

IO-4 pin can be set to 【Trig(in)】, 【Input】, 【Output】.

### **Parameter Description**

IO-4.Trig (in), Not- Invert	Parameter setting for pin 4.			
	Not- Invert Invert	level sigr  Invert		invert the input/output pulse or
		Trig(in)	the P-IO p	ult function means that pin 4 of performs bi-direction control over ment's trigger function.
			Trig-Out	Indicates that when the instru- ment generates a signal (which triggers the Meter function, Da- ta Recording function and List



			for a limited time), out a pulse signal.
	Trig-In	will trigger the	t the instrument e running of one of below after receiv- nal pulse signal.
		Meter	Triggers the running of Meter function. This function needs to be triggered at the upper computer side through SCPI instruction. For details, refer to instructions related to ACQuire in the Trigger subsystem of the Instruction Manual.
		Dlog	Triggers the run- ning of data re- cording function.
		List	Triggers the run- ning of List files.
Input	Pin 4 rece outside.	ives the level s	signal from the
Output	Pin 4 send to the outs	-	gnal (1, 0, PWM)
	True	put digital sig	ot-Invert), the out- nal is 1 (i.e. low the case of Invert, high level.
	False	put digital sig	ot-Invert), the out- nal is 0 (i.e. high the case of Invert, low level.




PWM	Digital signal of PWM.	
	PWM Freq	Frequency
	PWM Duty	Duty cycle

#### **How to Use**

Taking the triggering of List function as an example, the text below will introduce how to use pin 4's default function **Ext-Trig**.

- Trig-Out
  - 1. Refer to the figure below to connect pin 4 to the external oscilloscope.



- 2. Set pin 4's function to **Not-Invert** and **Trig-Out**.
- 3. Recall the edited List file for trigger running.
- 4. Press [Shift]+[On/Off] (Trigger) on the front panel to trigger the running of List files.



ListTrig Source is set to Manual.


5. Check the oscilloscope and confirm whether pin 4 has following pulse signal output.

Level rise slope	10us
Level fall slope	2us
Minimum time width for low level keep	30us



#### Trig-In

1. Refer to the figure below to connect pin 4 to the external oscilloscope.



- 2. Set pin 4's function to **Not-Invert** and **Trig-In→List**.
- 3. Recall the edited List file for trigger running.
- 4. Set ListTrig Source to External.
- 5. Send pulse signals as per the following requirements from the external oscilloscope to pin 4.

Level rise slope	10us
Level fall slope	2us
Minimum time width for low level keep	30us

6. Observe the VFD screen on the instrument's front panel to confirm whether the List file is running or not.

### 5.11.5 IO-5. INH-Living, Not-Invert

IO-5 pin can be set to 【Inhibit】, 【Input】, 【Output】.



### **Parameter Description**

IO–5. Living, Not-Invert	Parameter setting for pin 5.				
	Not- Invert	Indicates whether to invert the input/output pulse or level signal.  Invert: Yes  Not-Invert: No			
		Inhibit This default function means that pin 5 of the P-IO controls the operation of the instrument.		·	
			Living	_	, and power supply ted in the mode of
		Latch Select Latch, and power supply will be operated in the mode of Latch.		-	
		Input Pin 5 receives the level signal from the outside.			
		Output	Pin 5 sends the digital signal (1, 0, PWM) to the outside.		
			True	put digital sig	lot-Invert), the out- gnal is 1 (i.e. low the case of Invert, high level.
			False	put digital sig	lot-Invert), the out- gnal is 0 (i.e. high the case of Invert, low level.
			PWM Digital signal of PWM.		of PWM.
				PWM Freq	Frequency
				PWM Duty	Duty cycle




#### **How to Use**

- When pin 5 is set to Inhibit-Living (Not-Invert), pin 5 can control the instrument's output state based on the level signal from external input.
  - Under default conditions (namely, pin 5 is not connected), the input is high level, and it will not impact the instrument's output state.
  - When the [On/Off] is in On state, input low level to pin 5, and it will impact the output state: The [On/Off] button light is lighted on and VFD still displays On, but the actual output is 0; when pin 5 receives high level signal again, the output state is recovered.



If pin 5 is set to **Invert**, input high level to pin 5, and it will impact the output state.

1. Referring to the figure below, connect pin 5 to the external oscilloscope.



- 2. Set pin 5's function to **Not-Invert** and **Inhibit**→**Living**.
- 3. Set voltage to 10V and turn on [On/Off].
- 4. Input low level to pin 5.

At this point, the **[On/Off]** button light is lighted on, and VFD indicator light on the front panel displays **On**, while voltage/current Meter value gradually decreases to 0, the output function is prohibited. In addition, the VFD screen on the front panel displays **INH**.

5. Input high level to pin 5.

At this point, **[On/Off]** button light is lighted on, and VFD indicator light on the front panel displays **On**, and voltage/current Meter value gradually recovers to 10V, and the output function is re-initiated.




• When pin 5 is set to **Inhibit-Latch** (**Not-Invert**), pin 5 can control the instrument's output state based on the pulse signal from external input. The parameter requirements of this pulse signal are as follows:

Level rise slope	10us
Level fall slope	2us
Minimum time width for low level keep	30us

- Under default conditions (pin 5 is not connected), it will not effect the instrument's output state.
- If [On/Off] is in On state, when pin 5 receives pulse signal, [On/Off] will be turned off: The [On/Off] button light is lighted off, and the VFD indicator light displays Off.

After confirming that the **[On/Off]** can be turned on again, the user needs to manually turn on **[On/Off]**.

1. Referring to the figure below, connect pin 5 to the external oscilloscope.



- 2. Set pin 5's function to **Not-Invert** and **Inhibit**→**Latch**.
- 3. Set voltage to 10V and turn on [On/Off].
- 4. Input pulse signal to pin 5.

At this point, the **[On/Off]** button light is lighted off, and the VFD indicator light on the front panel displays **Off**, and the output function is switched off. In addition, the VFD screen on the front panel displays **Inhibit-Ps**. When the protection state is cleared, manually turn on **[On/Off]** again.



# 5.11.6 IO-6. Sync-On, Not-Invert

IO-6 pin can be set to 【Sync-On】, 【Input】, 【Output】.

### **Parameter Description**

IO-6. Sync- On, Not- Invert	Parameter setting for pin 6.				
	Not- Invert	Indicates whether to invert the input/output pulse or level signal.  Invert: Yes  Not-Invert: No			
		Sync-On	Sync-On This default function means that pin 6 performs bi-directional and synchronous control over the turn-on of [On/Off].		
		Input Pin 6 receives the level signal from the outside.			
		Output Pin 6 sends the digital signal (1, 0, PWM) to the outside.		l signal (1, 0, PWM)	
			True	put digital si	Not-Invert), the out- gnal is 1 (i.e. low lev- e case of Invert, the h level.
			False	put digital si	Not-Invert), the outgnal is 0 (i.e. high lever case of Invert, the level.
		PWM Digital signal of PWM.		l of PWM.	
				PWM Freq	Frequency
				PWM Duty	Duty cycle

#### **How to Use**

When pin 6 is set to default **Sync-On** function, pin 6 has bi-directional I/O function, which can receive pulse signal input from the external instrument and also



can output pulse signal to external instrument. The parameter requirements of this pulse signal are as follows:


Level rise slope	10us
Level fall slope	2us
Minimum time width for low level keep	30us

The bi-direction I/O functions are introduced as below:

- Press [On/Off] on the instrument's front panel, the instrument's output is changed from Off to On. At this point, the pulse signal output from pin 6 can be detected.
- When the instrument's **[On/Off]** is in On state, input pulse signal to pin 6, and it will not impact the **[On/Off]** state.
- When the instrument's **[On/Off]** is in Off state, when pulse signal is input to pin 6, the **[On/Off]** will be changed from Off to ON.

Taking two instruments as an example, the operation is as below:

1. Referring to the figure below, connect pin 6 of two instruments to the external oscilloscope.



- 2. Set pin 6's function of two instruments to **Not-Invert** and **Sync-On**.
- 3. Confirm that the **[On/Off]** of both instruments is in Off state.
- 4. Set the voltage to 10V on the front panel of instrument A, and turn on **[On/Off]**.

At this time, check the oscilloscope. The instrument A's pin 6 outputs pulse signal and the instrument B's output function is synchronously turned on.



### 5.11.7 IO-7. Sync-Off, Not-Invert

IO-7 pin can be set to 【Sync-Off】, 【Input】, 【Output】.

### **Parameter Description**

IO-7. Sync-Off, Not-Invert	Parameter setting for pin 7.				
	Not- Invert	Indicates whether to invert the input/output pulse or level signal.  Invert: Yes  Not-Invert: No			
		Sync- Off This default function means that pin 7 performs bi-directional and synchronous control over the turn-off of [On/Off].			
		Input Pin 7 receives the level signal from the outside.			
		Output Pin 7 sends the digital signal (1, 0, PWM) to the outside.			
			True By default ( <b>Not-Invert</b> ), the output digital signal is 1 (i.e. low level), and in the case of <b>Invert</b> , the output is high level.		
			False By default ( <b>Not-Invert</b> ), the output digital signal is 0 (i.e. high level), and in the case of <b>Invert</b> , the output is low level.		
			PWM Digital signal of PWM.		
				PWM Freq	Frequency
				PWM Duty	Duty cycle

#### **How to Use**

When pin 7 is set to default **Sync-Off** function, pin 7 has bi-directional I/O function, which can receive pulse signal input from the external instrument and also can output pulse signal to external instrument. The parameter requirements of this pulse signal are as follows:




Level rise slope	10us
Level fall slope	2us
Minimum time width for low level keep	30us

The bi-direction I/O functions are introduced as below:

- Press [On/Off] on the instrument's front panel, the instrument's output is changed from On to Off. At this point, the pulse signal output from pin 7 can be detected.
- When the instrument's **[On/Off]** is in Off state, input pulse signal to pin 7, and it will not impact the **[On/Off]** state.
- When the instrument's **[On/Off]** is in On state, input pulse signal to pin 7, and **[On/Off]** will be changed from On to Off.

Taking two instruments as an example, the operation is as below:

1. Referring to the figure below, connect pin 7 of two instruments to the external oscilloscope.



- 2. Set pin 7's function of two instruments to Not-Invert and Sync-Off.
- 3. Confirm that the **[On/Off]** of both instruments is in On state.
- 4. Press **[On/Off]** on the front panel of instrument A to turn off the output function.

At this time, check the oscilloscope. The instrument A's pin 7 outputs pulse signal and the instrument B's output function is synchronously turned off.



# 5.12 Analogue Function (Ext-Program) (Optional)


The external analog quantity function means that the user can input an analog signal in the range of –10V to 10V through the analog quantity input interface for remote setting of the instrument's input setting value. The external analog quantity function is not the standard-equipped function for the instrument. It is only available when the user selects the IT-E177 interface card.

The rear panel of this series of instrument provides an optional interface card integrating the RS-232 and analog quantity function. The interface card provides the following capability:

- Remotely control voltage and current values.
- Remotely control voltage and current upper limit values.
- Remote monitoring of output voltage/current measurement.
- RS-232 communication interface, please refer to 2.5.5 RS-232 Interface (Optional) for detailed description about the interface.

#### **Analog Card Interface Introduction**

The analog signal bandwidth is less than 100Hz, and the signal bandwidth supports any waveform. When the programmed signal frequency or amplitude exceeds the output capacity, the instrument will automatically limit the output amplitude. The pins description is as below.





Pins	Name	Туре	Description
1, 2, 3	TXD, RXD, DGND	Commu- nication terminal	RS232 interface connection terminal.
4	GND	Ground	Ground for analog inputs and outputs.
5	V-Monitor	Analog out	Voltage monitor signal.
6	I-Monitor	Analog out	Current monitor signal.
7	+10V	Analog out	The +10V reference voltage output by the power supply can be connected to a resistance subdivision for analog control.
8	Input1	Analog in	The setting for the output voltage/current value corresponds to <b>Ch1</b> in the menu.  CV priority: Specify the value of <b>Vset</b> .  CC priority: Specify the value of <b>Iset</b> .
9	Input2	Analog in	The setting for the voltage/current upper limit corresponds to <b>Ch2</b> in the menu.  CV priority: Specify the value of the current upper limit <b>Ilim</b> .
			<ul> <li>CC priority: Specify the value of the voltage upper limit Vlim.</li> </ul>
10	Input3	Analog in	The setting for the voltage/current lower limit corresponds to <b>Ch3</b> in the menu. (IT-M3900D series models do not need to be set)

### Analog quantity menu description

When the analog quantity function is optionally equipped, the system menu displays the analog quantity menu. The analog quantity menu items and parameters are described below:

Ext-Program	External analog function menu	
	On / Off	Function switch:



		<ul> <li>On: Turns on the external analog function.         In this state, the channel parameters cannot be set.     </li> <li>Off: Turns off the external analog function.         In this state, the channel parameters can be set.     </li> </ul>	
C	Ch1	Set the channe	parameters of channel 1 (programmed el).
		Mx	Indicates the slope factor of channel 1.
		Mb	Indicates the offset of channel 1.
C	Ch2	Set the parameters of channel 2 (upper limit channel).	
		Mx Indicates the slope factor of channel 2.	
<u> </u>		Mb Indicates the offset of channel 2.	
C	Ch3	Set the parameters of channel 3 (lower limit channel).	
			ote
		For the IT-M3900D series of unipolar power supplies, the voltage/current lower limit does not need to be specified. Therefore, the Ch3 parameters here do not need to be set.	
		Mx Indicates the slope factor of channel 3.	
		Mb	Indicates the offset of channel 3.

#### **Analog Conversion Relationship Introduction**

When the analog quantity control function of this series of instrument is used, the user needs to set the conversion relationship of the analog quantity expected value based on requirements. The analog quantity values in each channel all follow the calculation relationship of y=Mx+b. The user needs to set the MX (slope coefficient) and MB (offset) values in different channels in the analog quantity menu. For calculation of the analog quantity value. The user can calculate the M and b values based on the analog requirements in accordance with the formula below.



Taking the Ch1 programming channel as an example, the user needs to convert the values of Mx and Mb according to the following formulas, and then set the two values through the front panel keys or SCPI remote commands.



The principle of parameter setting of Ch1 and Ch2 and Ch3 is the same, so the description will not be repeated.

Name	Description
V <sub>in1</sub>	Indicates the minimum voltage input to pin 8. The setting range is from –10V to 10V.
V <sub>in2</sub>	Indicates the maximum voltage input to pin 8. The setting range is from –10V to 10V, and V <sub>in2</sub> >V <sub>in1</sub> .
V <sub>out1</sub>	The minimum value of the output voltage in CV priority mode.
V <sub>out2</sub>	The maximum value of the output voltage in CV priority mode, and $V_{out2}$ > $V_{out1}$ .
I <sub>out1</sub>	The minimum value of the output current in CC priority mode.
I <sub>out2</sub>	The maximum value of the output current in CC priority mode, and I <sub>out2</sub> >I <sub>out1</sub> .

#### CV priority

$$M_x = \frac{(V_{out2} - V_{out1})}{(V_{in2} - V_{in1})}$$

$$M_b = V_{out2} - V_{in2} \times M_x$$

#### CC priority

$$M_x = \frac{(I_{out_2} - I_{out_1})}{(V_{in_2} - V_{in_1})}$$


$$M_b = I_{out2} - V_{in2} \times M_x$$

#### **How to Use**

The following takes the CV priority mode as an example to introduce the usage steps.



1. Refer to the figure below to complete the pin connection.



2. Calculate the **M**x and **Mb** under the Ch1, Ch2 menus according to the above formulas. The sample data used in this manual is shown in the table below.

Pins	Input Voltage	Output Voltage / Current	Mx	Mb	Description
8	V <sub>in1</sub> = 0 V <sub>in2</sub> = 5	V <sub>out1</sub> = 0 V <sub>out2</sub> = 500	10- 0	0	By inputting a voltage of 0V to 5V to pin 8, the actual output voltage <b>Vset</b> is controlled from 0 to 500V.
9	V <sub>in1</sub> = 0 V <sub>in2</sub> = 10	I <sub>out1</sub> = 0 I <sub>out2</sub> = 30	3	0	By inputting a voltage of 0V to 10V to pin 9, the actual output current upper limit <b>!lim</b> is controlled from 0 to 30A.

- 3. Set MX and MB of the corresponding pins.
  - a. Press the composite keys **[Shift]+[P-set]** (System) on the front panel to enter the system menu.
  - b. Use knob key to select Ext-Program and press [Enter].
  - c. According to step 2, set **M**x and **Mb** of the corresponding pins.
  - d. Set the Ext-Program→On / Off to On to turn on the analog function.
- 4. Adjust the output of **DC Power Supply 1** from 0V to 5V, and adjust the output of **DC Power Supply 2** from 0V to 10V.



The actual output voltage and current of the instrument will change according to the following rules:

- Pin 8 controls the actual output voltage of the instrument from 0V to 500V.
- Pin 9 monitors the actual output current of the instrument: When the output current is higher than the upper limit **!lim** set by pin 9, the instrument outputs the current at the value of **!lim**.

# 5.13 View the System Information (System Info)

This menu item is used to view the system information of the instrument.

The procedures to view the system information are as follows.

- 1. Press the composite keys [Shift]+[P-set] (System) on the front panel to enter the system menu.
- 2. Turn the knob to select the System Info and press [Enter].

You can use knob to view the following system information.

Parameter	Description
Model	Display the instrument model.
SN	Display the serial number.
Main Ver	Display the system version information.
Ctrl1 Ver	Display the version information of the control panel 1.
Ctrl2 Ver	Display the version information of the control panel 2.
Date	Display the system time.
Voltage Max	Display the maximum voltage value.
Voltage Min	Display the minimum voltage value.
Current Max	Display the maximum current value.
Current Min	Display the minimum current value.
Power Max	Display the maximum power value.
Power Min	Display the minimum power value.
Resistance Max	Display the maximum resistance value.



Resistance Min	Display the minimum resistance value.
Current Limit	Display the maximum current limit.
Run Time	Display the power-on time.
Boot Update Info	Boot update information.

### 5.14 Restored to Factory Setting (System Reset)

This menu item is used to restore some parameter settings to factory setting values.

The procedures to set the menu item are as follows.

- 1. Press the composite keys [Shift]+[P-set] (System) on the front panel to enter the system menu.
- 2. Turn the knob to select the **System Reset** and press [Enter].
- 3. Press the Left / Right key or turn the knob to adjust the value of this parameter.
  - No: Default value, indicates the instrument cancels this menu setting.
  - Yes: Indicates the instrument restores the factory default settings.
- 4. After the parameter settings are complete, press [Enter].

The parameters affected by **System Reset** and the parameter values after reset are shown in the following table.

Table 5–2 Initial value of the parameter

Category	Parameter	Initial Value
Main interface	Voltage setting: Vset	0.002V(10V models) 0.2V(Other models)
	Current setting: Iset	One percent of the rated current of the instrument
	Upper limit of voltage: Vlim	Upper limit value: 0.002V(10V models) Upper limit value: 0.2V (Other models)
	Upper limit of current: Ilim	One percent of the rated current of the instrument



Category	Parameter	Initial Value
	Upper limit of power: Plim	Rated power value of the instrument
	[On/Off] status	Off
System	Веер	On
menu	PowerOn	Reset
	Sense	Off
	ListTrig Source	Manual
	DataLogger Trig Source	Manual
	I/O Con	USB-VCP
	Digital Port	IO-1: Ps-Clear     IO-2: Ps
		IO-3: Off-Status
		• IO–4: Trig(In)
		IO–5: INH-Living
		• IO–6: Sync-On
		IO-7: Sync-Off
	Parallel	Single
Config menu	Mode	CV
	Speed	High
	V-Rise Time/I-Rise Time	0.1s
	V-Fall Time/I-Fall Time	
	Output Res	1000
	On Delay/Off Delay	0
Protect menu	OVP/OCP/OPP/UCP/UVP Status switch	Off
	OVP/OCP/OPP Protection point: Level	Rated voltage / current / power value of the instrument
	UCP/UVP Protection point: Level	0



Category	Parameter	Initial Value
	OVP/OCP/OPP/UCP/UVP Delay time: Delay	60s
	UCP/UVP Warm time: Warm-up	

# 5.15 System Upgrade

This series power supply supports the upgrade of the system version. System upgrade includes the following two methods:

- During the start-up period after the instrument is powered on, through the USB interface on the front panel, select the system upgrading files in the memory device (USB flash drive) for upgrading.
- The user can access to the Web service programs in the instrument by the Web browser on PC for upgrading operation.

This Chapter introduces in detail how to upgrade the system with the USB interface on the front panel. For the upgrading method of Web, see 2.5.2.1 Using Web Server.

#### **Before You Upgrade**

Before upgrading, you need to note the following points:

1. Description about system upgrading files.

Before upgrading, please contact ITECH technical staff to obtain the following two upgrading files, and put them under the root directory of the USB flash drive.

• itech 3900 P.itech

System upgrading package postfixed with .itech.

• ItechConfig.txt

System upgrading configuration file in text format. Before performing the upgrade, you need to open the configuration file with a text editing tool to confirm that the system upgrade package name in the configuration file is consistent with the present upgrading package name.

For example, when there are multiple system upgrading package postfixed with .itech in the root directory of your USB flash drive, you need to



use a text editing tool to open the configuration file and specify the upgrade package name corresponding to the present upgrade operation.

- 2. The upgrading methods for single unit or units in parallel are slightly different: Under the parallel mode, the user can select to upgrade all units or a single unit only by operating the master. Therefore, the user needs to get access to SN numbers of all instruments in the parallel network (To obtain the unique ID for identifying instrument, see 5.13 View the System Information (System Info)) for selective upgrading based on the SN number in subsequent upgrades.
- 3. If the upgrade fails, the interface will prompt **Update fail**. At this point, you cannot use the instrument. Please contact ITECH technical staff for treatment.

### **Upgrade Operation**

- System Upgrade under Single-unit Mode
  - Insert the USB flash drive into the USB interface on the front panel of the instrument.
  - Power on the instrument. At this point, press **Shift** for several times till the instrument can detect the system upgrading files in the USB flash drive.

After the system upgrading files are detected, the interface displays as follows:

```
Update Now?
No Yes
```



If the USB flash drive is not detected, select **Yes** to detect again; if **No** is selected, it means to exit upgrading, and the system will directly enter into the main interface.

3. Select **Yes**, and press **[Enter]**. The system interface displays as follows:

```
Update Select:00/01
SN: ALL
```

4. Press the right button →, the system interface displays as follows:

```
Update Select:01/01
SN: ALL Y
```

Press [Enter], the system interface displays as follows:

```
Update ? 01/01
No Yes
```



5. Select **Yes**, and press **[Enter]**.

The system will automatically perform upgrading.



If **No** is selected, it means to exit upgrading, and the system will directly enter into the main interface.

- 6. After the upgrading is completed, you need to restart the instrument manually.
- System Upgrade under Parallel Mode (Only Need to Operate the Master)
  - Insert the USB flash drive into the USB interface on the front panel of the instrument.
  - Power on the instrument. At this point, press **Shift** for several times till the instrument can detect the system upgrading files in the USB flash drive.

After the system upgrading files are detected, the interface displays as follows:

```
Update Now?
No Yes
```

Select **Yes**, and press **[Enter]**. The interface displays as follows:

```
Update Select:xx/yy
SN: ALL
```

xx means the number of selected instruments to be upgraded, and yy means the number of instruments in the parallel network.

- 3. Select upgrade in whole or in part based on actual needs. Then, press **[Enter]**.
  - SN: ALL

Indicates to upgrade all.

Indicates to upgrade the selected instrument. Rotate the knob to check the SNs of all instruments in the parallel network; press Right to select the instrument; and press Right again to deselect the instrument.

4. Select **Yes**, and press **[Enter]**.

The system will automatically perform upgrading.





If **No** is selected, it means to exit upgrading, and the system will directly enter into the main interface.

5. After the upgrading is completed, you need to restart the instrument manually.



# **6** Ted

# **Technical Specification**

This chapter will introduce the main technical parameters of the instrument, such as rated voltage/current/power and so on. Besides, we will introduce the working environment and storage temperature.

- ◆ Main Specification
- ♦ IT-M3901D-10-170
- ◆ IT-M3903D-10-340
- ◆ IT-M3905D-10-510
- ◆ IT-M3910D-10-1020
- ◆ IT-M3902D-32-80
- ◆ IT-M3904D-32-160
- ♦ IT-M3906D-32-240
- ◆ IT-M3912D-32-480
- ◆ IT-M3902D-80-40
- ◆ IT-M3904D-80-80
- ◆ IT-M3906D-80-120
- ◆ IT-M3912D-80-240
- ◆ IT-M3902D-300-20
- ◆ IT-M3904D-300-40
- ◆ IT-M3906D-300-60
- ◆ IT-M3912D-300-120
- ◆ IT-M3902D-500-12
- ◆ IT-M3904D-500-24
- ◆ IT-M3906D-500-36
- ♦ IT-M3912D-500-72
- ◆ IT-M3902D-800-8
- ◆ IT-M3904D-800-16◆ IT-M3906D-800-24
- ♦ IT-M3912D-800-48
- ♦ IT-M3906D-1500-12
- ♦ IT-M3912D-1500-24
- ◆ Supplemental Characteristics

# 6.1 Main Specification



# 6.1.1 IT-M3901D-10-170

Parameter		IT-M3901D-10-170
	Voltage	0 ~ 10V
	Current	0A ~ 170A
Rated value	Power	0W ~ 1700W
	Resistance in series ( CV priority )	0 ~ 0.06Ω
	Voltage	0.001V
	Current	0.01A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.001Ω
	Voltage	0.001V
Read Back Resolution	Current	0.01A
	Power	1W
	Voltage	≤0.05% + 0.05%FS
	Current	≤0.1% + 0.1%FS
Setup Accuracy	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS
	Voltage	≤0.05% + 0.05%FS
Read Back Accuracy	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
Voltage ripple*1	Vp-p	≤65mVpp
Voltage rippie	Vrms	≤10mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤50ms
Rise Time( full load )	Voltage	≤100ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time	Voltage	≤10ms



Paran	neter	IT-M3901D-10-170
Line Regulation	Voltage	≤0.05% + 0.05%FS
Line Regulation	Current	≤0.03% + 0.03%FS
Load Regulation	Voltage	≤0.002%*I + 0.05%FS
Load Negalation	Current	≤0.05% + 0.05%FS
	OCP	175A
Output protection	OVP	10.5V
Gutput protoction	Overpower protection	1734W
Remote Sense Compensation Voltage	≤2V	
	current program	External programming voltage 0V to 10V corresponds to current 0A to 170A
External analog (optional)	current monitor	Current 0A to 170A corresponds to external monitoring voltage 0V to 10V
	voltage program	External programming voltage 0 to 10V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 10V corresponds to external monitor- ing voltage 0 to 10V

AC Input*2	Grid voltage range	3phase 200V ~ 480V	
		Single phase 100V ~ 240V	
	Frequency	50Hz/60Hz	
Max. apparent power		1.85kVA	
Max. input current		12.5Aac	
Max. efficiency	92%		
Power Factor	0.99		
DC component	≤0.2A		
Current harmonics	≤3%		
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232		
Command Re- sponse Time	0.1ms		
Parallel Number	≤16		



Working Temperature	0~40°C
Storage Temperature	-10°C ~ 70°C
IP	IP20
Isolation DC to GND	300Vdc
Isolation AC to GND	3500Vdc
Cooling	Air
Dimension(D*W*H)	744.22mm*459mm*56.81mm
Weight( net)	10kg



- \*1: The ripple is got under three-phase AC input.
  \*2: At low voltage input, the set power will decrease. For more information, please contact ITECH.

### 6.1.2 IT-M3903D-10-340

Parameter		IT-M3903D-10-340
	Voltage	0 ~ 10V
	Current	0A ~ 340A
Rated value	Power	0W ~ 3400W
	Resistance in series ( CV priority )	0 ~ 0.02Ω
	Voltage	0.001V
	Current	0.1A
Setup Resolution	Power	1W
	Resistance in series (CV priority)	0.001Ω
	Voltage	0.001V
Read Back Resolution	Current	0.1A
	Power	1W
	Voltage	≤0.05% + 0.05%FS
Setup Accuracy	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
	Resistance in series (CV priority)	≤1%FS



Pa	nrameter	IT-M3903D-10-340
	Voltage	≤0.05% + 0.05%FS
Read Back Accuracy	Current	≤0.1% + 0.1%FS
,	Power	≤0.5% + 0.5%FS
Voltage ripple*1	Vp-p	≤65mVpp
voltage rippie	Vrms	≤10mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤50ms
Rise Time( full load )	Voltage	≤100ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time	Voltage	≤10ms
Line Regulation	Voltage	≤0.05% + 0.05%FS
Line Regulation	Current	≤0.03% + 0.03%FS
Load Describéion	Voltage	0.0035%*I + 0.05%FS
Load Regulation	Current	≤0.05% + 0.05%FS
	OCP	345A
Output protection	OVP	10.5V
	Overpower protection	3468W
Remote Sense Compensation Voltage	≤2V	
	current program	External programming voltage 0V to 10V corresponds to current 0A to 340A
External analog	current monitor	Current 0A to 340A corresponds to external monitoring voltage 0V to 10V
( optional )	voltage program	External programming voltage 0 to 10V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 10V corresponds to external monitoring voltage 0 to 10V



	Grid voltage range	3phase 200V ~ 480V
AC Input*2		Single phase 100V ~ 240V
	Frequency	50/60Hz
Max. apparent power	3.7	/kVA
Max. input current	12	2.5A
Max. efficiency	9.	2%
Power Factor	0	.99
DC component	≤0	.2A
Current harmonics	≤3	3%
Standard Interface		B/LAN/CAN/IO B/Analog&RS232
Command Response Time	0.	1ms
Parallel Number	≤	16
Working Temperature	0~	40°C
Storage Temperature	-10°C	5 ~ 70°C
IP	IF	P20
Isolation DC to GND	300	0Vdc
Isolation AC to GND	350	0Vdc
Cooling		Air
Dimension ( mm)	744.22mm*45	59mm*56.81mm
Weight( net)	12	.5kg



- \*1: The ripple is got under three-phase AC input.
  \*2: At low voltage input, the set power will decrease. For more information, please contact ITECH.

# 6.1.3 IT-M3905D-10-510

Parameter		IT-M3905D-10-510
	Voltage	0 ~ 10V
	Current	0A ~ 510A
Rated value	Power	0W ~ 5100W
	Resistance in series (CV priority)	0 ~ 0.02Ω



Parameter		IT-M3905D-10-510
	Voltage	0.001V
	Current	0.1A
Setup Resolution	Power	1W
	Resistance in series (CV priority)	0.001Ω
	Voltage	0.001V
Read Back Resolution	Current	0.1A
	Power	1W
	Voltage	≤0.05% + 0.05%FS
	Current	≤0.1% + 0.1%FS
Setup Accuracy	Power	≤0.5% + 0.5%FS
	Resistance in series (CV priority)	≤1%FS
D 15 1	Voltage	≤0.05% + 0.05%FS
Read Back Accuracy	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
Voltage ripple*1	Vp-p	≤65mVpp
Vollago rippio	Vrms	≤10mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤50ms
Rise Time( full load )	Voltage	≤100ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time	Voltage	≤10ms
Line Regulation	Voltage	≤0.05% + 0.05%FS
Line Negalation	Current	≤0.03% + 0.03%FS
Load Regulation	Voltage	0.0035%*I + 0.05%FS
Lodd Rogaldion	Current	≤0.05% + 0.05%FS
Output protection	OCP	520A



Parameter		IT-M3905D-10-510
	OVP	10.5V
	Overpower protection	5202W
Remote Sense Compensation Voltage		≤2V
External analog (optional)	current program	External programming voltage 0V to 10V corresponds to current 0A to 510A
	current monitor	Current 0A to 510A corresponds to external monitoring voltage 0V to 10V
	voltage program	External programming voltage 0 to 10V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 10V corresponds to external monitoring voltage 0 to 10V

	Grid voltage range	3phase 200V ~ 480V
AC Input*2		Single phase 100V ~ 240V
	Frequency	50/60Hz
Max. apparent power		5.55kVA
Max. input current		12.5Aac
Max. efficiency		92%
Power Factor		0.99
DC component	≤0.2A	
Current harmonics	≤3%	
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	
Command Re- sponse Time	0.1ms	
Parallel Number	≤16	
Working Temperature	0~40°C	
Storage Temperature	-10°C ~ 70°C	
IP		IP20
Isolation DC to GND	300Vdc	



Isolation AC to GND	3500Vdc
Cooling	Air
Dimension(D*W*H)	744.22mm*459mm*56.81mm
Weight( net)	15kg



# 6.1.4 IT-M3910D-10-1020

Parameter		IT-M3910D-10-1020
	Voltage	0 ~ 10V
	Current	0A ~ 1020A
Rated value	Power	0W ~ 10200W
	Resistance in series ( CV priority )	0 ~ 0.02Ω
	Voltage	0.001V
	Current	0.1A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.001Ω
	Voltage	0.001V
Read Back Resolution	Current	0.1A
	Power	1W
	Voltage	≤0.05% + 0.05%FS
	Current	≤0.1% + 0.1%FS
Setup Accuracy	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS
	Voltage	≤0.05% + 0.05%FS
Read Back Accuracy	Current	≤0.1% + 0.1%FS
·	Power	≤0.5% + 0.5%FS
Ripple	Vp-p	≤65mVpp
Γτιρρίο	Vrms	≤10mV

<sup>\*1:</sup> The ripple is got under three-phase AC input.
\*2: At low voltage input, the set power will decrease. For more information, please contact ITECH.



Parar	meter	IT-M3910D-10-1020
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤50ms
Rise Time( full load )	Voltage	≤100ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 25% to 90% of rated current)	Voltage	≤10ms
Line Regulation	Voltage	≤0.05% + 0.05%FS
Line rregulation	Current	≤0.03% +0.03%FS
Load Regulation	Voltage	0.0035%*I + 0.05%FS
Load Nogalation	Current	≤0.05% + 0.05%FS
	OCP	1040A
Output protection	OVP	10.5V
	Overpower protection	10710W
Remote Sense Compensation Voltage	≤2V	
External analog (optional)	current program	External programming voltage 0V to 10V corresponds to current 0A to 1020A
	current monitor	Current 0A to 1020A corresponds to external mon- itoring voltage 0V to 10V
	voltage program	External programming voltage 0 to 10V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 10V corresponds to external monitor- ing voltage 0 to 10V

AC Input*1	Grid voltage range	3phase 200V ~ 480V
	Frequency	50/60Hz



	,
Max. apparent power	11.0kVA
Max. input current	25Aac
Max. efficiency	92%
Power Factor	0.99
DC component	≤0.2A
Current harmonics	≤3%
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232
Command Re- sponse Time	0.1ms
Parallel Number	≤8
Working Temperature	0~40°C
Storage Temperature	-10°C ~ 70°C
IP	IP20
Isolation DC to GND	300Vdc
Isolation AC to GND	3500Vdc
Cooling	Air
Dimension ( mm)	767.62mm*483mm*106.9mm
Weight( net)	30kg



\*1: At low voltage input, the set power will decrease. For more information, please contact ITECH.

### 6.1.5 IT-M3902D-32-80

Parameter		IT-M3902D-32-80
Rated value	Voltage	0 ~ 32V
	Current	0A ~ 80A
	Power	0W ~ 2000W
	Resistance in series ( CV priority )	0 ~ 0.2Ω
Setup Resolution	Voltage	0.001V



Paran	neter	IT-M3902D-32-80
	Current	0.01A
	Power	1W
	Resistance in series ( CV priority )	0.001Ω
	Voltage	0.001V
Read Back Resolution	Current	0.01A
	Power	1W
	Voltage	≤0.05% + 0.05%FS
	Current	≤0.1% + 0.1%FS
Setup Accuracy	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS
	Voltage	≤0.05% + 0.05%FS
Read Back Accuracy	Current	≤0.1% + 0.1%FS
·	Power	≤0.5% + 0.5%FS
Voltage ripple*1	Vp-p	≤160mVpp
Voltage ripple	Vrms	≤30mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤30ms
Rise Time( full load )	Voltage	≤60ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 25% to 90% of rated current)	Voltage	≤1ms
Line Regulation	Voltage	≤0.02% + 0.02%FS
Line Regulation	Current	≤0.03% + 0.03%FS
Lood Dogulation	Voltage	≤0.02% + 0.02%FS
Load Regulation	Current	≤0.05% + 0.05%FS
Output protection	OCP	83A



Parameter		IT-M3902D-32-80
	OVP	33V
	Overpower protection	2040W
Remote Sense Compensation Voltage		≤5V
External analog (optional)	current program	External programming voltage 0V to 10V corresponds to current 0A to 80A
	current monitor	Current 0A to 80A corresponds to external monitor- ing voltage 0V to 10V
	voltage program	External programming voltage 0 to 32V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 32V corresponds to external monitor- ing voltage 0 to 10V

AC Input*2	Grid voltage range	3phase 200V ~ 480V
		Single phase 100V ~ 240V
	Frequency	50/60Hz
Max. apparent power	2.25kVA	
Max. input current		12.5Aac
Max. efficiency		92%
Power Factor	0.99	
DC component	≤0.2A	
Current harmonics	≤3%	
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	
Command Re- sponse Time	0.1ms	
Parallel Number	≤16	
Working Temperature	0~40°C	
Storage Temperature	-10°C ~ 70°C	
IP	IP20	
Isolation DC to GND	300Vdc	



Isolation AC to GND	3500Vdc
Cooling	Air
Dimension ( mm)	744.22mm*459mm*56.81mm
Weight( net)	10kg



# 6.1.6 IT-M3904D-32-160

Parameter		IT-M3904D-32-160
	Voltage	0~32V
	Current	0A ~ 160A
Rated value	Power	0W ~ 4000W
	Resistance in series ( CV priority )	0 ~ 0.2Ω
	Voltage	0.001V
	Current	0.01A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.001Ω
	Voltage	0.001V
Read Back Resolution	Current	0.01A
	Power	1W
	Voltage	≤0.05% + 0.05%FS
	Current	≤0.1% + 0.1%FS
Setup Accuracy	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS
Read Back Accuracy	Voltage	≤0.05% + 0.05%FS
	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
Voltage ripple*1	Vp-p	≤80mVpp
voltage rippie	Vrms	≤30mV

<sup>\*1:</sup> The ripple is got under three-phase AC input.
\*2: At low voltage input, the set power will decrease. For more information, please contact ITECH.



Para	meter	IT-M3904D-32-160
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Tem-	Voltage	≤30ppm/°C
perature Coefficient	Current	≤50ppm/°C
Rise Time( no load	Voltage	≤30ms
Rise Time( full load )	Voltage	≤60ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 20% to 90% of rated current)	Voltage	≤1ms
Line Population	Voltage	≤0.02% + 0.02%FS
Line Regulation	Current	≤0.03% +0.03%FS
Load Regulation	Voltage	≤0.02% + 0.02%FS
Load Nogalation	Current	≤0.05% + 0.05%FS
	OCP	165A
Output protection	OVP	33V
	Overpower protection	4080W
Remote Sense Compensation Voltage	≤5V	
External analog (optional)	current program	External programming voltage 0V to 10V corresponds to current 0A to 160A
	current monitor	Current 0A to 160A corresponds to external monitoring voltage 0V to 10V
	voltage program	External programming voltage 0 to 32V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 32V corresponds to external monitor- ing voltage 0 to 10V

AC Input*2	Grid voltage range	3phase 200V ~ 480V
------------	--------------------	--------------------



		Single phase 100V ~ 240V
	Frequency	50/60Hz
Max. apparent power		4.5kVA
Max. input current		12.5Aac
Max. efficiency		92%
Power Factor		0.99
DC component		≤0.2A
Current harmonics		≤3%
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	
Command Re- sponse Time	0.1ms	
Parallel Number	≤16	
Working Temperature	0 ~ 40°C	
Storage Temperature	-10°C ~ 70°C	
IP	IP20	
Isolation DC to GND	300Vdc	
Isolation AC to GND	3500Vdc	
Cooling	Air	
Dimension(D*W*H)	744.22mm*459mm*56.81mm	
Weight( net)	12.5kg	



### 6.1.7 IT-M3906D-32-240

Parameter		IT-M3906D-32-240
	Voltage	0 ~ 32V
Rated value	Current	0A ~ 240A
	Power	0W ~ 6000W

<sup>\*1:</sup> The ripple is got under three-phase AC input.
\*2: At low voltage input, the set power will decrease. For more information, please contact ITECH.



Parameter		IT-M3906D-32-240
	Resistance in series ( CV priority )	0 ~ 0.2Ω
	Voltage	0.001V
	Current	0.01A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.001Ω
	Voltage	0.001V
Read Back Resolution	Current	0.01A
	Power	1W
	Voltage	≤0.05% + 0.05%FS
	Current	≤0.1% + 0.1%FS
Setup Accuracy	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS
	Voltage	≤0.05% + 0.05%FS
Read Back Accuracy	Current	≤0.1% + 0.1%FS
,	Power	≤0.5% + 0.5%FS
Voltage ripple*1	Vp-p	≤80mVpp
voltage ripple	Vrms	≤30mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤30ms
Rise Time( full load )	Voltage	≤60ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 25% to 90% of rated current)	Voltage	≤1ms
Line Regulation	Voltage	≤0.02% + 0.02%FS
Line Regulation	Current	≤0.03% + 0.03%FS



Parameter		IT-M3906D-32-240
Load Regulation	Voltage	≤0.02% + 0.02%FS
Load Negulation	Current	≤0.05% + 0.05%FS
	OCP	250A
Output protection	OVP	33V
Output protostion	Overpower protection	6120W
Remote Sense Compensation Voltage	≤5V	
External analog (optional)	current program	External programming voltage 0V to 10V corresponds to current 0A to 240A
	current monitor	Current 0A to 240A corresponds to external monitoring voltage 0V to 10V
	voltage program	External programming voltage 0 to 32V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 32V corresponds to external monitor- ing voltage 0 to 10V

AC Input*2	Grid voltage range	3phase 200V ~ 480V
		Single phase 100V ~ 240V
	Frequency	50/60Hz
Max. apparent power	6.5kVA	
Max. input current		12.5Aac
Max. efficiency	92%	
Power Factor	0.99	
DC component	≤0.2A	
Current harmonics	≤3%	
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	
Command Re- sponse Time	0.1ms	
Parallel Number	≤16	
Working Temperature	0 ~ 40°C	



Storage Temperature	-10°C ~ 70°C
IP	IP20
Isolation DC to GND	300Vdc
Isolation AC to GND	3500Vdc
Cooling	Air
Dimension(D*W*H)	744.22mm*459mm*56.81mm
Weight( net)	15kg



# 6.1.8 IT-M3912D-32-480

Parameter		IT-M3912D-32-480
	Voltage	0~32V
	Current	0A ~ 480A
Rated value	Power	0W ~ 12000W
	Resistance in series ( CV priority )	0 ~ 0.2Ω
	Voltage	0.001V
	Current	0.01A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.001Ω
	Voltage	0.001V
Read Back Resolution	Current	0.01A
	Power	1W
	Voltage	≤0.05% + 0.05%FS
	Current	≤0.1% + 0.1%FS
Setup Accuracy	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS
Read Back Accuracy	Voltage	≤0.05% + 0.05%FS

<sup>\*1:</sup> The ripple is got under three-phase AC input.
\*2: At low voltage input, the set power will decrease. For more information, please contact ITECH.



Parameter		IT-M3912D-32-480
	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
Voltage ripple	Vp-p	≤80mVpp
voltago rippio	Vrms	≤30mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤30ms
Rise Time( full load )	Voltage	≤60ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 20% to 90% of rated current)	Voltage	≤1ms
Line Regulation	Voltage	≤0.02% + 0.02%FS
Line Regulation	Current	≤0.03% +0.03%FS
Load Pagulation	Voltage	≤0.02% + 0.02%FS
Load Regulation	Current	≤0.05% + 0.05%FS
	OCP	500A
Output protection	OVP	33V
	Overpower protection	12240W
Remote Sense Compensation Voltage	≤5V	
External analog (optional)	current program	External programming voltage 0V to 10V corresponds to current 0A to 480A
	current monitor	Current 0A to 480A corresponds to external monitoring voltage 0V to 10V
	voltage program	External programming voltage 0 to 32V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 32V corresponds to external monitor- ing voltage 0 to 10V



A.C. Immust*1	Grid voltage range	3phase 200V ~ 480V
AC Input*1	Frequency	50/60Hz
Max. apparent power		13kVA
Max. input current		25Aac
Max. efficiency		92%
Power Factor		0.99
DC component		≤0.2A
Current harmonics		≤3%
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	
Command Re- sponse Time	0.1ms	
Parallel Number	≤16	
Working Temperature	0~40°C	
Storage Temperature	-10°C ~ 70°C	
IP	IP20	
Isolation DC to GND	300Vdc	
Isolation AC to GND	3500Vdc	
Cooling	Air	
Dimension(D*W*H)	767.62mm*483mm*106.9mm	
Weight( net)	30kg	



\*1: At low voltage input, the set power will decrease. For more information, please contact ITECH.

# 6.1.9 IT-M3902D-80-40

Parameter		IT-M3902D-80-40
Rated value	Voltage	0 ~ 80V
	Current	0A ~ 40A



Parameter		IT-M3902D-80-40
	Power	0W ~ 2000W
	Resistance in series ( CV priority )	0 ~ 0.3Ω
	Voltage	0.001V
	Current	0.01A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.001Ω
	Voltage	0.001V
Read Back Resolution	Current	0.01A
	Power	1W
	Voltage	≤0.03% +0.03%FS
	Current	≤0.1% + 0.1%FS
Setup Accuracy	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS
	Voltage	≤0.03% +0.03%FS
Read Back Accuracy	Current	≤0.1% + 0.1%FS
,	Power	≤0.5% + 0.5%FS
Voltage ripple*1	Vp-p	≤200mVpp
Voltage Tipple	Vrms	≤80mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤15ms
Rise Time( full load	Voltage	≤30ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 25% to 90% of rated current)	Voltage	≤1ms
Line Regulation	Voltage	≤0.01% + 0.01%FS



Parameter		IT-M3902D-80-40
	Current	≤0.03% + 0.03%FS
Load Regulation	Voltage	≤0.01% + 0.01%FS
Load Negalation	Current	≤0.05% + 0.05%FS
	OCP	42A
Output protection	OVP	82V
Output protoction	Overpower protection	2040W
Remote Sense Compensation Voltage	≤5V	
External analog (optional)	current program	External programming voltage 0V to 10V corresponds to current 0A to 40A
	current monitor	Current 0A to 40A corresponds to external monitor- ing voltage 0V to 10V
	voltage program	External programming voltage 0 to 80V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 80V corresponds to external monitor- ing voltage 0 to 10V

AC Input*2	Grid voltage range	3phase 200V ~ 480V
		Single phase 100V ~ 240V
	Frequency	50/60Hz
Max. apparent power	2.25kVA	
Max. input current		12.5Aac
Max. efficiency	92%	
Power Factor	0.99	
DC component	≤0.2A	
Current harmonics	≤3%	
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	
Command Re- sponse Time	0.1ms	
Parallel Number	≤16	
Working Temperature	0~40°C	



Storage Temperature	-10°C ~ 70°C
IP	IP20
Isolation DC to GND	300Vdc
Isolation AC to GND	3500Vdc
Cooling	Air
Dimension(D*W*H)	744.22mm*459mm*56.81mm
Weight( net)	10kg



# 6.1.10 IT-M3904D-80-80

Parameter		IT-M3904D-80-80
	Voltage	0~80V
	Current	0A ~ 80A
Rated value	Power	0W ~ 4000W
	Resistance in series ( CV priority )	0~0.3Ω
	Voltage	0.001V
	Current	0.01A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.001Ω
	Voltage	0.001V
Read Back Resolution	Current	0.01A
	Power	1W
	Voltage	≤0.03% + 0.03%FS
	Current	≤0.1% + 0.1%FS
Setup Accuracy	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS
Read Back Accuracy	Voltage	≤0.03% +0.03%FS

<sup>\*1:</sup> The ripple is got under three-phase AC input.
\*2: At low voltage input, the set power will decrease. For more information, please contact ITECH.



Parameter		IT-M3904D-80-80
	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
Voltage ripple*1	Vp-p	≤200mVpp
Voltage Tipple	Vrms	≤80mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤15ms
Rise Time( full load )	Voltage	≤30ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 25% to 90% of rated current)	Voltage	≤1ms
Line Regulation	Voltage	≤0.01% + 0.01%FS
Line regulation	Current	≤0.03% +0.03%FS
Load Regulation	Voltage	≤0.01% + 0.01%FS
Load Negalation	Current	≤0.05% + 0.05%FS
	OCP	84A
Output protection	OVP	82V
	Overpower protection	4080W
Remote Sense Compensation Voltage		
	current program	External programming voltage 0V to 10V corresponds to current 0A to 80A
External analog (optional)	current monitor	Current 0A to 80A corresponds to external monitoring voltage 0V to 10V
	voltage program	External programming voltage 0 to 80V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 80V corresponds to external monitor- ing voltage 0 to 10V



		3phase 200V ~ 480V
AC Input*2	Grid voltage range	·
		Single phase 100V ~ 240V
	Frequency	50/60Hz
Max. apparent power	4.5kVA	
Max. input current		12.5Aac
Max. efficiency		92%
Power Factor		0.99
DC component		≤0.2A
Current harmonics	≤3%	
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	
Command Re- sponse Time	0.1ms	
Parallel Number	≤16	
Working Temperature	0~40°C	
Storage Temperature	-10°C ~ 70°C	
IP	IP20	
Isolation DC to GND	300Vdc	
Isolation AC to GND	3500Vdc	
Cooling	Air	
Dimension(D*W*H)	744.22mm*459mm*56.81mm	
Weight( net)	12.5kg	



<sup>\*1:</sup> The ripple is got under three-phase AC input.

# 6.1.11 IT-M3906D-80-120

Parameter		IT-M3906D-80-120
Rated value	Voltage	0~80V

<sup>\*2:</sup> At low voltage input, the set power will decrease. For more information, please contact ITECH.



Parameter		IT-M3906D-80-120
	Current	0A ~ 120A
	Power	0W ~ 6000W
	Resistance in series ( CV priority )	0 ~ 0.3Ω
	Voltage	0.001V
	Current	0.01A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.001Ω
	Voltage	0.001V
Read Back Resolution	Current	0.01A
rtocolation	Power	1W
	Voltage	≤0.03% + 0.03%FS
	Current	≤0.1% + 0.1%FS
Setup Accuracy	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS
	Voltage	≤0.03% +0.03%FS
Read Back Accuracy	Current	≤0.1% + 0.1%FS
,	Power	≤0.5% + 0.5%FS
Voltage ripple*1	Vp-p	≤200mVpp
Voltage ripple	Vrms	≤80mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤15ms
Rise Time( full load	Voltage	≤30ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 25% to 90% of rated current)	Voltage	≤1ms



Parameter		IT-M3906D-80-120
Line Regulation	Voltage	≤0.01% + 0.01%FS
Line Regulation	Current	≤0.03% + 0.03%FS
Load Regulation	Voltage	≤0.01% + 0.01%FS
Load Negalation	Current	≤0.05% + 0.05%FS
	OCP	125A
Output protection	OVP	82V
	Overpower protection	6120W
Remote Sense Compensation Voltage	≤5V	
External analog (optional)	current program	External programming voltage 0V to 10V corresponds to current 0A to 120A
	current monitor	Current 0A to 120A corresponds to external monitoring voltage 0V to 10V
	voltage program	External programming voltage 0 to 80V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 80V corresponds to external monitor- ing voltage 0 to 10V

AC Input*2	Grid voltage range	3phase 200V ~ 480V
		Single phase 100V ~ 240V
	Frequency	50/60Hz
Max. apparent power	6.5kVA	
Max. input current	12.5Aac	
Max. efficiency	92%	
Power Factor	0.99	
DC component	≤0.2A	
Current harmonics	≤3%	
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	
Command Re- sponse Time	0.1ms	
Parallel Number	≤16	



Working Temperature	0 ~ 40°C
Storage Temperature	-10°C ~ 70°C
IP	IP20
Isolation DC to GND	300Vdc
Isolation AC to GND	3500Vdc
Cooling	Air
Dimension(D*W*H)	744.22mm*459mm*56.81mm
Weight( net)	15kg



- \*1: The ripple is got under three-phase AC input.
  \*2: At low voltage input, the set power will decrease. For more information, please contact ITECH.

### 6.1.12 IT-M3912D-80-240

Parameter		IT-M3912D-80-240
	Voltage	0 ~ 80V
	Current	0A ~ 240A
Rated value	Power	0W ~ 12000W
	Resistance in series ( CV priority )	0 ~ 0.3Ω
	Voltage	0.001V
	Current	0.01A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.001Ω
	Voltage	0.001V
Read Back Resolution	Current	0.01A
	Power	1W
	Voltage	≤0.03% + 0.03%FS
	Current	≤0.1% + 0.1%FS
Setup Accuracy	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS



Parameter		IT-M3912D-80-240
	Voltage	≤0.03% + 0.03%FS
Read Back Accuracy	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
Voltage ripple	Vp-p	≤200mVpp
voltage rippie	Vrms	≤80mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤15ms
Rise Time( full load )	Voltage	≤30ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 25% to 90% of rated current)	Voltage	≤1ms
Line Regulation	Voltage	≤0.01% + 0.01%FS
Line Regulation	Current	≤0.03% + 0.03%FS
Load Regulation	Voltage	≤0.01% + 0.01%FS
Load Negulation	Current	≤0.05% + 0.05%FS
	OCP	250A
Output protection	OVP	82V
	Overpower protection	12240W
Remote Sense Compensation Voltage	≤5V	
External analog (optional)	current program	External programming voltage 0V to 10V corresponds to current 0A to 240A
	current monitor	Current 0A to 240A corresponds to external monitoring voltage 0V to 10V
	voltage program	External programming voltage 0 to 80V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 80V corresponds to external monitor- ing voltage 0 to 10V



	Grid voltage range	3phase 200V ~ 480V
AC Input*1	Frequency	50/60Hz
Max. apparent power		13kVA
Max. input current		25Aac
Max. efficiency		92%
Power Factor		0.99
DC component		≤0.2A
Current harmonics		≤3%
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	
Command Re- sponse Time	0.1ms	
Parallel Number	≤16	
Working Temperature	0 ~ 40°C	
Storage Temperature	-10°C ~ 70°C	
IP	IP20	
Isolation DC to GND	300Vdc	
Isolation AC to GND	3500Vdc	
Cooling	Air	
Dimension(D*W*H)	767.62mm*483mm*106.9mm	
Weight( net)	30kg	



\*1: At low voltage input, the set power will decrease. For more information, please contact ITECH.

### 6.1.13 IT-M3902D-300-20

Parameter		IT-M3902D-300-20
Rated value	Voltage	0~300V



Parameter		IT-M3902D-300-20
	Current	0A ~ 20A
	Power	0W ~ 2000W
	Resistance in series ( CV priority )	0 ~ 1Ω
	Voltage	0.01V
	Current	0.001A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.001Ω
	Voltage	0.01V
Read Back Resolution	Current	0.001A
	Power	1W
	Voltage	≤0.03% + 0.03%FS
	Current	≤0.1% + 0.1%FS
Setup Accuracy	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS
	Voltage	≤0.03% +0.03%FS
Read Back Accuracy	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
Voltage ripple*1	Vp-p	≤900mVpp
Voltage rippie	Vrms	≤120mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤30ms
Rise Time( full load )	Voltage	≤60ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 20% to 90% of rated current)	Voltage	≤1ms
Line Regulation	Voltage	≤0.01% + 0.01%FS



Parameter		IT-M3902D-300-20
	Current	≤0.03% +0.03%FS
Load Regulation	Voltage	≤0.01% + 0.01%FS
Load Nogalation	Current	≤0.05% + 0.05%FS
	OCP	21A
Output protection	OVP	303V
Output proteotion	Overpower protection	2040W
Remote Sense Compensation Voltage	≤5V	
External analog (optional)	current program	External programming voltage 0V to 10V corresponds to current 0A to 20A
	current monitor	Current 0A to 20A corresponds to external monitoring voltage 0V to 10V
	voltage program	External programming voltage 0 to 300V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 300V corresponds to external monitoring voltage 0 to 10V

AC Input*2	Grid voltage range	3phase 200V ~ 480V
		Single phase 100V ~ 240V
	Frequency	50/60Hz
Max. apparent power		2.25kVA
Max. input current		12.5Aac
Max. efficiency	94.5%	
Power Factor	0.99	
DC component	≤0.2A	
Current harmonics	≤3%	
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	
Command Response Time	0.1ms	
Parallel Number	≤16	
Working Temperature	0 ~ 40°C	



Storage Temperature	-10°C ~ 70°C
IP	IP20
Isolation DC to GND	800Vdc
Isolation AC to GND	3500Vdc
Cooling	Air
Dimension(D*W*H)	744.22mm*459mm*56.81mm
Weight( net)	10kg



# 6.1.14 IT-M3904D-300-40

Parameter		IT-M3904D-300-40
	Voltage	0~300V
	Current	0A ~ 40A
Rated value	Power	0W ~ 4000W
	Resistance in series ( CV priority )	0~1Ω
	Voltage	0.01V
	Current	0.001A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.001Ω
	Voltage	0.01V
Read Back Resolution	Current	0.001A
	Power	1W
	Voltage	≤0.03% + 0.03%FS
Setup Accuracy	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS
Read Back Accuracy	Voltage	≤0.03% + 0.03%FS

<sup>\*1:</sup> The ripple is got under three-phase AC input.
\*2: At low voltage input, the set power will decrease. For more information, please contact ITECH.



Parameter		IT-M3904D-300-40
	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
Voltage ripple*1	Vp-p	≤600mVpp
voltage rippie	Vrms	≤90mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤30ms
Rise Time( full load )	Voltage	≤60ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 20% to 90% of rated current)	Voltage	≤1ms
Line Regulation	Voltage	≤0.01% + 0.01%FS
Line Regulation	Current	≤0.03% + 0.03%FS
Load Regulation	Voltage	≤0.01% + 0.01%FS
Load Negulation	Current	≤0.05% + 0.05%FS
	OCP	42A
Output protection	OVP	303V
	Overpower protection	4080W
Remote Sense Compensation Voltage	≤5V	
	current program	External programming voltage 0V to 10V corresponds to current 0A to 40A
External analog	current monitor	Current 0A to 40A corresponds to external monitoring voltage 0V to 10V
( optional )	voltage program	External programming voltage 0 to 300V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 300V corresponds to external monitoring voltage 0 to 10V



		2nh 200\/ 400\/
AC Input*2	Grid voltage range	3phase 200V ~ 480V
		Single phase 100V ~ 240V
	Frequency	50/60Hz
Max. apparent power		4.5kVA
Max. input current		12.5Aac
Max. efficiency		94.5%
Power Factor		0.99
DC component		≤0.2A
Current harmonics		≤3%
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	
Command Response Time	0.1ms	
Parallel Number	≤16	
Working Temperature	0~40°C	
Storage Temperature	-10°C ~ 70°C	
IP	IP20	
Isolation DC to GND	800Vdc	
Isolation AC to GND	3500Vdc	
Cooling	Air	
Dimension(D*W*H)	744.22mm*459mm*56.81mm	
Weight( net)	12.5kg	



<sup>\*1:</sup> The ripple is got under three-phase AC input.

### 6.1.15 IT-M3906D-300-60

Parameter		IT-M3906D-300-60
Rated value	Voltage	0~300V

<sup>\*2:</sup> At low voltage input, the set power will decrease. For more information, please contact ITECH.



Parameter		IT-M3906D-300-60
	Current	0A ~ 60A
	Power	0W ~ 6000W
	Resistance in series ( CV priority )	0 ~ 1Ω
	Voltage	0.01V
	Current	0.001A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.001Ω
	Voltage	0.01V
Read Back Resolution	Current	0.001A
	Power	1W
	Voltage	≤0.03% + 0.03%FS
	Current	≤0.1% + 0.1%FS
Setup Accuracy	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS
	Voltage	≤0.03% + 0.03%FS
Read Back Accuracy	Current	≤0.1% + 0.1%FS
Ţ	Power	≤0.5% + 0.5%FS
Voltage ripple*1	Vp-p	≤300mVpp
Voltage ripple	Vrms	≤60mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤30ms
Rise Time( full load )	Voltage	≤60ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 25% to 90% of rated current)	Voltage	≤1ms



Parameter		IT-M3906D-300-60
Line Regulation	Voltage	≤0.01% + 0.01%FS
Line Regulation	Current	≤0.03% +0.03%FS
Load Regulation	Voltage	≤0.01% + 0.01%FS
Load Negalation	Current	≤0.05% + 0.05%FS
	OCP	63A
Output protection	OVP	303V
	Overpower protection	6120W
Remote Sense Compensation Voltage	≤5V	
	current program	External programming voltage 0V to 10V corresponds to current 0A to 60A
External analog (optional)	current monitor	Current 0A to 60A corresponds to external monitoring voltage 0V to 10V
	voltage program	External programming voltage 0 to 300V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 300V corresponds to external monitor- ing voltage 0 to 10V

AC Input*2	Grid voltage range	3phase 200V ~ 480V
		Single phase 100V ~ 240V
	Frequency	50/60Hz
Max. apparent power	6.5kVA	
Max. input current	12.5Aac	
Max. efficiency	94.5%	
Power Factor	0.99	
DC component	≤0.2A	
Current harmonics	≤3%	
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	
Command Re- sponse Time	0.1ms	
Parallel Number	≤16	



Working Temperature	0 ~ 40°C
Storage Temperature	-10°C ~ 70°C
IP	IP20
Isolation DC to GND	800Vdc
Isolation AC to GND	3500Vdc
Cooling	Air
Dimension(D*W*H)	744.22mm*459mm*56.81mm
Weight( net)	15kg



<sup>\*1:</sup> The ripple is got under three-phase AC input.

### 6.1.16 IT-M3912D-300-120

Parameter		IT-M3912D-300-120
	Voltage	0~300V
	Current	0A ~ 120A
Rated value	Power	0W ~ 12000W
	Resistance in series ( CV priority )	0 ~ 1Ω
	Voltage	0.01V
	Current	0.001A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.001Ω
	Voltage	0.01V
Read Back Resolution	Current	0.001A
	Power	1W
	Voltage	≤0.03% +0.03%FS
Setup Accuracy	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS

<sup>\*2:</sup> At low voltage input, the set power will decrease. For more information, please contact ITECH.



Parameter		IT-M3912D-300-120
Read Back Accuracy	Voltage	≤0.03% + 0.03%FS
	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
Voltage ripple	Vp-p	≤300mVpp
voltage rippie	Vrms	≤100mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤30ms
Rise Time( full load )	Voltage	≤60ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 20% to 90% of rated current)	Voltage	≤1ms
Line Regulation	Voltage	≤0.01% + 0.01%FS
Line Regulation	Current	≤0.03% + 0.03%FS
Load Regulation	Voltage	≤0.01% + 0.01%FS
Load Negulation	Current	≤0.05% + 0.05%FS
	OCP	63A
Output protection	OVP	303V
	Overpower protection	12240W
Remote Sense Compensation Voltage	≤5V	
External analog (optional)	current program	External programming voltage 0V to 10V corresponds to current 0A to 120A
	current monitor	Current 0A to 120A corresponds to external monitoring voltage 0V to 10V
	voltage program	External programming voltage 0 to 300V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 300V corresponds to external monitoring voltage 0 to 10V



A O I 4*4	Grid voltage range	3phase 200V ~ 480V
AC Input*1	Frequency	50/60Hz
Max. apparent power		13kVA
Max. input current		25Aac
Max. efficiency		94.5%
Power Factor		0.99
DC component		≤0.2A
Current harmonics		≤3%
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	
Command Re- sponse Time	0.1ms	
Parallel Number	≤16	
Working Temperature	0~40°C	
Storage Temperature	-10°C ~ 70°C	
IP	IP20	
Isolation DC to GND	800Vdc	
Isolation AC to GND	3500Vdc	
Cooling	Air	
Dimension(D*W*H)	767.62mm*483mm*106.9mm	
Weight( net)	30kg	



\*1: At low voltage input, the set power will decrease. For more information, please contact ITECH.

### 6.1.17 IT-M3902D-500-12

Parameter		IT-M3902D-500-12
Rated value	Voltage	0 ~ 500V



Parameter		IT-M3902D-500-12
	Current	0A ~ 12A
	Power	0W ~ 2000W
	Resistance in series ( CV priority )	0 ~ 1Ω
	Voltage	0.01V
	Current	0.001A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.01Ω
	Voltage	0.01V
Read Back Resolution	Current	0.001A
1 (000) 4 (0)	Power	1W
	Voltage	≤0.03% + 0.03%FS
	Current	≤0.1% + 0.1%FS
Setup Accuracy	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS
5 15 1	Voltage	≤0.03% + 0.03%FS
Read Back Accuracy	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
Voltage ripple*1	Vp-p	≤1500mVpp
voltage rippie	Vrms	≤180mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤30ms
Rise Time( full load )	Voltage	≤60ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 20% to 90% of rated current)	Voltage	≤1ms
Line Regulation	Voltage	≤0.01% + 0.01%FS
I		



Parameter		IT-M3902D-500-12
	Current	≤0.05% + 0.05%FS
Load Regulation	Voltage	≤0.01% + 0.01%FS
Load Negalation	Current	≤0.05% + 0.05%FS
	OCP	12.5A
Output protection	OVP	505V
Guipai protoction	Overpower protection	2040W
Remote Sense Compensation Voltage	≤5V	
	current program	External programming voltage 0V to 10V corresponds to current 0A to 12A
External analog	current monitor	Current 0A to 12A corresponds to external monitoring voltage 0V to 10V
( optional )	voltage program	External programming voltage 0 to 500V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 500V corresponds to external monitoring voltage 0 to 10V

AC Input*2	Grid voltage range	3phase 200V ~ 480V
		Single phase 100V ~ 240V
	Frequency	50/60Hz
Max. apparent power		2.25kVA
Max. input current		12.5Aac
Max. efficiency	94.5%	
Power Factor	0.99	
DC component	≤0.2A	
Current harmonics	≤3%	
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	
Command Response Time	0.1ms	
Parallel Number	≤16	
Working Temperature	0 ~ 40°C	



Storage Temperature	-10°C ~ 70°C
IP	IP20
Isolation DC to GND	1600Vdc
Isolation AC to GND	3500Vdc
Cooling	Air
Dimension(D*W*H)	744.22mm*459mm*56.81mm
Weight( net)	10kg



# 6.1.18 IT-M3904D-500-24

Parameter		IT-M3904D-500-24
	Voltage	0 ~ 500V
	Current	0A ~ 24A
Rated value	Power	0W ~ 4000W
	Resistance in series ( CV priority )	0~1Ω
	Voltage	0.01V
	Current	0.001A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.01Ω
	Voltage	0.01V
Read Back Resolution	Current	0.001A
	Power	1W
	Voltage	≤0.03% + 0.03%FS
	Current	≤0.1% + 0.1%FS
Setup Accuracy	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS
Read Back Accuracy	Voltage	≤0.03% + 0.03%FS

<sup>\*1:</sup> The ripple is got under three-phase AC input.
\*2: At low voltage input, the set power will decrease. For more information, please contact ITECH.



Parameter		IT-M3904D-500-24
	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
Voltage ripple*1	Vp-p	≤1000mVpp
voltage rippie	Vrms	≤135mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤30ms
Rise Time( full load )	Voltage	≤60ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 25% to 90% of rated current)	Voltage	≤1ms
Line Regulation	Voltage	≤0.01% + 0.01%FS
Line Regulation	Current	≤0.03% + 0.03%FS
Load Regulation	Voltage	≤0.01% + 0.01%FS
Load Negulation	Current	≤0.05% + 0.05%FS
	OCP	24.6A
Output protection	OVP	505V
	Overpower protection	4080W
Remote Sense Compensation Voltage		
	current program	External programming voltage 0V to 10V corresponds to current 0A to 24A
External analog (optional)	current monitor	Current 0A to 24A corresponds to external monitor- ing voltage 0V to 10V
	voltage program	External programming voltage 0 to 500V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 500V corresponds to external monitor- ing voltage 0 to 10V



		3phase 200V ~ 480V
AC Input*2	Grid voltage range	Single phase 100V ~ 240V
	Frequency	50/60Hz
Max. apparent power		6.5kVA
Max. input current		12.5Aac
Max. efficiency		94.5%
Power Factor		0.99
DC component		≤0.2A
Current harmonics	≤3%	
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	
Command Re- sponse Time	0.1ms	
Parallel Number	≤16	
Working Temperature	0~40°C	
Storage Temperature	-10°C ~ 70°C	
IP	IP20	
Isolation DC to GND	1600Vdc	
Isolation AC to GND	3500Vdc	
Cooling	Air	
Dimension ( mm)	744.22mm*459mm*56.81mm	
Weight( net)	15kg	



# 6.1.19 IT-M3906D-500-36

Parameter		IT-M3906D-500-36
Rated value	Voltage	0 ~ 500V

<sup>\*1:</sup> The ripple is got under three-phase AC input.
\*2: At low voltage input, the set power will decrease. For more information, please contact ITECH.



Parameter		IT-M3906D-500-36
	Current	0A ~ 36A
	Power	0W ~ 6000W
	Resistance in series ( CV priority )	0 ~ 1Ω
	Voltage	0.01V
	Current	0.001A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.01Ω
	Voltage	0.01V
Read Back Resolution	Current	0.001A
	Power	1W
	Voltage	≤0.03% +0.03%FS
	Current	≤0.1% + 0.1%FS
Setup Accuracy	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS
	Voltage	≤0.03% + 0.03%FS
Read Back Accuracy	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
Voltage ripple*1	Vp-p	≤500mVpp
v ollago rippio	Vrms	≤90mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤30ms
Rise Time( full load )	Voltage	≤60ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 20% to 90% of rated current)	Voltage	≤1ms
Line Regulation	Voltage	≤0.01% + 0.01%FS



Parameter		IT-M3906D-500-36
	Current	≤0.03% + 0.03%FS
Load Regulation	Voltage	≤0.01% + 0.01%FS
Load (Cgalation	Current	≤0.05% + 0.05%FS
	OCP	37A
Output protection	OVP	505V
Catpat protoction	Overpower protection	6120W
Remote Sense Compensation Voltage	≤5V	
External analog (optional)	current program	External programming voltage 0V to 10V corresponds to current 0A to 36A
	current monitor	Current 0A to 36A corresponds to external monitor- ing voltage 0V to 10V
	voltage program	External programming voltage 0 to 500V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 500V corresponds to external monitor- ing voltage 0 to 10V

AC Input*2	Grid voltage range	3phase 200V ~ 480V
		Single phase 100V ~ 240V
	Frequency	50/60Hz
Max. apparent power	6.5kVA	
Max. input current		12.5Aac
Max. efficiency	94.5%	
Power Factor	0.99	
DC component	≤0.2A	
Current harmonics	≤3%	
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	
Command Re- sponse Time	0.1ms	
Parallel Number	≤16	
Working Temperature	0 ~ 40°C	



Storage Temperature	-10°C ~ 70°C
IP	IP20
Isolation DC to GND	1600Vdc
Isolation AC to GND	3500Vdc
Cooling	Air
Dimension(D*W*H)	744.22mm*459mm*56.81mm
Weight( net)	15kg



# 6.1.20 IT-M3912D-500-72

Parameter		IT-M3912D-500-72
	Voltage	0 ~ 500V
	Current	0A ~ 72A
Rated value	Power	0W ~ 12000W
	Resistance in series ( CV priority )	0 ~ 1Ω
	Voltage	0.01V
	Current	0.01A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.01Ω
	Voltage	0.01V
Read Back Resolution	Current	0.01A
	Power	1W
	Voltage	≤0.03% +0.03%FS
Setup Accuracy	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS
Read Back Accuracy	Voltage	≤0.03% + 0.03%FS

<sup>\*1:</sup> The ripple is got under three-phase AC input.
\*2: At low voltage input, the set power will decrease. For more information, please contact ITECH.



Parameter		IT-M3912D-500-72
	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
Voltage ripple	Vp-p	≤500mVpp
voltage rippie	Vrms	≤90mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤30ms
Rise Time( full load )	Voltage	≤60ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 20% to 90% of rated current)	Voltage	≤1ms
Line Regulation	Voltage	≤0.01% + 0.01%FS
Line regulation	Current	≤0.03% +0.03%FS
Load Regulation	Voltage	≤0.01% + 0.01%FS
Load Negdiation	Current	≤0.05% + 0.05%FS
	OCP	74A
Output protection	OVP	505V
	Overpower protection	12240W
Remote Sense Compensation Voltage	≤5V	
External analog (optional)	current program	External programming voltage 0V to 10V corresponds to current 0A to 72A
	current monitor	Current 0A to 72A corresponds to external monitoring voltage 0V to 10V
	voltage program	External programming voltage 0 to 500V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 500V corresponds to external monitoring voltage 0 to 10V



A C. Immust*4	Grid voltage range	3phase 200V ~ 480V
AC Input*1	Frequency	50/60Hz
Max. apparent power		13kVA
Max. input current		25Aac
Max. efficiency		94.5%
Power Factor		0.99
DC component		≤0.2A
Current harmonics		≤3%
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	
Command Re- sponse Time	0.1ms	
Parallel Number	≤16	
Working Temperature	0 ~ 40°C	
Storage Temperature	-10°C ~ 70°C	
IP	IP20	
Isolation DC to GND	1600Vdc	
Isolation AC to GND	3500Vdc	
Cooling	Air	
Dimension(D*W*H)	767.62mm*483mm*106.9mm	
Weight( net)	30kg	



<sup>\*1:</sup> At low voltage input, the set power will decrease. For more information, please contact ITECH.

# 6.1.21 IT-M3902D-800-8

Parameter		IT-M3902D-800-8
	Voltage	0~800V
Rated value	Current	0 ~ 8A
	Power	0 ~ 2000W



Parameter		IT-M3902D-800-8
	Resistance in series ( CV priority )	0~1Ω
	Voltage	0.01V
	Current	0.001A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.01Ω
	Voltage	0.01V
Read Back Resolution	Current	0.001A
	Power	1W
	Voltage	≤0.03% +0.03%FS
	Current	≤0.1% + 0.1%FS
Setup Accuracy	Power	≤0.5% +0.5%FS
	Resistance in series ( CV priority )	≤1%FS
	Voltage	≤0.03% +0.03%FS
Read Back Accuracy	Current	≤0.1% + 0.1%FS
,	Power	≤0.5% +0.5%FS
Voltage ripple*1	Vp-p	≤2400mVpp
Voltage ripple	Vrms	≤240mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤30ms
Rise Time( full load )	Voltage	≤60ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 20% to 90% of rated current)	Voltage	≤1ms
Line Regulation	Voltage	≤0.01% + 0.01%FS
Line Negulation	Current	≤0.03% + 0.03%FS



Parameter		IT-M3902D-800-8
Load Regulation	Voltage	≤0.01% + 0.01%FS
	Current	≤0.05% + 0.05%FS
	OCP	8.5A
Output protection	OVP	808V
Cutput protoction	Overpower protection	2040W
Remote Sense Compensation Voltage		
External analog (optional)	current program	External programming voltage 0V to 10V corresponds to current 0A to 8A
	current monitor	Current 0A to 8A corresponds to external monitor- ing voltage 0V to 10V
	voltage program	External programming voltage 0 to 800V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 800V corresponds to external monitor- ing voltage 0 to 10V

AC Input*2	Grid voltage range	3phase 200V ~ 480V
		Single phase 100V ~ 240V
	Frequency	50/60Hz
Max. apparent power	2.25kVA	
Max. input current	12.5Aac	
Max. efficiency	94.5%	
Power Factor	0.99	
DC component	≤0.2A	
Current harmonics	≤3%	
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	
Command Re- sponse Time	0.1ms	
Parallel Number	≤16	
Working Temperature	0 ~ 40°C	



Storage Temperature	-10°C ~ 70°C	
IP	IP20	
Isolation DC to GND	1600Vdc	
Isolation AC to GND	3500Vdc	
Cooling	Air	
Dimension ( D*W*H )	744.22mm*459mm*56.81mm	
Weight( net)	10kg	



<sup>\*1:</sup> The ripple is got under three-phase AC input.

# 6.1.22 IT-M3904D-800-16

Parameter		IT-M3904D-800-16
	Voltage	0~800V
	Current	0A ~ 16A
Rated value	Power	0W ~ 4000W
	Resistance in series ( CV priority )	0~1Ω
	Voltage	0.01V
	Current	0.001A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.01Ω
	Voltage	0.01V
Read Back Resolution	Current	0.001A
	Power	1W
	Voltage	≤0.03% + 0.03%FS
Setup Accuracy	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS

<sup>\*2:</sup> At low voltage input, the set power will decrease. For more information, please contact ITECH.



Parameter		IT-M3904D-800-16
Read Back Accuracy	Voltage	≤0.03% +0.03%FS
	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
Voltage ripple*1	Vp-p	≤1600mVpp
Voltage ripple	Vrms	≤200mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤30ms
Rise Time( full load )	Voltage	≤60ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 25% to 90% of rated current)	Voltage	≤1ms
Line Regulation	Voltage	≤0.01% + 0.01%FS
Line Regulation	Current	≤0.03% + 0.03%FS
Load Regulation	Voltage	≤0.01% + 0.01%FS
Load Negulation	Current	≤0.05% + 0.05%FS
	OCP	16.8A
Output protection	OVP	808V
	Overpower protection	4080W
Remote Sense Compensation Voltage		
	current program	External programming voltage 0V to 10V corresponds to current 0A to 16A
External analog (optional)	current monitor	Current 0A to 16A corresponds to external monitor- ing voltage 0V to 10V
	voltage program	External programming voltage 0 to 800V Corresponding voltage 0 to 10V



Parameter	IT-M3904D-800-16
voltage monitor	Voltage 0 to 800V corresponds to external monitor- ing voltage 0 to 10V

AC Input*2	Grid voltage range	3phase 200V ~ 480V
		Single phase 100V ~ 240V
	Frequency	50/60Hz
Max. apparent power	4.5kVA	
Max. input current		12.5Aac
Max. efficiency		94.5%
Power Factor		0.99
DC component		≤0.2A
Current harmonics		≤3%
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	
Command Re- sponse Time	0.1ms	
Parallel Number	≤16	
Working Temperature	0 ~ 40°C	
Storage Temperature	-10°C ~ 70°C	
IP	IP20	
Isolation DC to GND	1600Vdc	
Isolation AC to GND	3500Vdc	
Cooling	Air	
Dimension ( mm)	744.22mm*459mm*56.81mm	
Weight( net)	12.5kg	



<sup>\*1:</sup> The ripple is got under three-phase AC input.
\*2: At low voltage input, the set power will decrease. For more information, please contact ITECH.



# 6.1.23 IT-M3906D-800-24

Parameter		IT-M3906D-800-24
	Voltage	0~800V
	Current	0A ~ 24A
Rated value	Power	0W ~ 6000W
	Resistance in series ( CV priority )	0~1Ω
	Voltage	0.01V
	Current	0.001A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.01Ω
	Voltage	0.01V
Read Back Resolution	Current	0.001A
	Power	1W
	Voltage	≤0.03% +0.03%FS
	Current	≤0.1% + 0.1%FS
Setup Accuracy	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS
	Voltage	≤0.03% +0.03%FS
Read Back Accuracy	Current	≤0.1% + 0.1%FS
•	Power	≤0.5% + 0.5%FS
Voltage ripple*1	Vp-p	≤1000mVpp
Voltage ripple	Vrms	≤160mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤30ms
Rise Time( full load )	Voltage	≤60ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time	Voltage	≤1ms



Parameter		IT-M3906D-800-24
(change from 25% to 90% of rated current)		
Line Regulation	Voltage	≤0.01% + 0.01%FS
Ellie Regulation	Current	≤0.03% + 0.03%FS
Load Regulation	Voltage	≤0.01% + 0.01%FS
Load Negalation	Current	≤0.05% + 0.05%FS
	OCP	25A
Output protection	OVP	808V
Cutput protoction	Overpower protection	6120W
Remote Sense Compensation Voltage		
External analog (optional)	current program	External programming voltage 0V to 10V corresponds to current 0A to 24A
	current monitor	Current 0A to 24A corresponds to external monitoring voltage 0V to 10V
	voltage program	External programming voltage 0 to 800V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 800V corresponds to external monitor- ing voltage 0 to 10V

AC Input*2	Grid voltage range	3phase 200V ~ 480V
		Single phase 100V ~ 240V
	Frequency	50/60Hz
Max. apparent power	6.5kVA	
Max. input current	12.5Aac	
Max. efficiency	94.5%	
Power Factor	0.99	
DC component	≤0.2A	
Current harmonics	≤3%	
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	



Command Re- sponse Time	0.1ms
Parallel Number	≤16
Working Temperature	0~40°C
Storage Temperature	-10°C ~ 70°C
IP	IP20
Isolation DC to GND	1600Vdc
Isolation AC to GND	3500Vdc
Cooling	Air
Dimension ( D*W*H )	744.22mm*459mm*56.81mm
Weight( net)	15kg



- \*1: The ripple is got under three-phase AC input.
  \*2: At low voltage input, the set power will decrease. For more information, please contact ITECH.

## 6.1.24 IT-M3912D-800-48

Parameter		IT-M3912D-800-48
	Voltage	0~800V
	Current	0 ~ 48A
Rated value	Power	0 ~ 12000W
	Resistance in series ( CV priority )	0 ~ 1Ω
	Voltage	0.01V
	Current	0.001A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.01Ω
Read Back Resolution	Voltage	0.01V
	Current	0.001A
	Power	1W
Setup Accuracy	Voltage	≤0.03% +0.03%FS



Parameter		IT-M3912D-800-48
	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS
	Voltage	≤0.03% +0.03%FS
Read Back Accuracy	Current	≤0.1% + 0.1%FS
•	Power	≤0.5% + 0.5%FS
Voltage ripple	Vp-p	≤1000mVpp
voltage ripple	Vrms	≤300mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤30ms
Rise Time( full load )	Voltage	≤60ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 25% to 90% of rated current)	Voltage	≤1ms
Line Regulation	Voltage	≤0.01% + 0.01%FS
Line Regulation	Current	≤0.03% + 0.03%FS
Load Regulation	Voltage	≤0.01% + 0.01%FS
Load Negulation	Current	≤0.05% + 0.05%FS
	OCP	50A
Output protection	OVP	808V
, ,	Overpower protection	12240W
Remote Sense Compensation Voltage	≤8V	
External analog	current program	External programming voltage 0V to 10V corresponds to current 0A to 48A
( optional )	current monitor	Current 0A to 48A corresponds to external monitoring voltage 0V to 10V



Parameter		IT-M3912D-800-48
	voltage program	External programming voltage 0 to 800V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 800V corresponds to external monitor- ing voltage 0 to 10V

#### Other parameters:

A C. Immut*1	Grid voltage range	3phase 200V ~ 480V
AC Input*1	Frequency	50/60Hz
Max. apparent power		13kVA
Max. input current		25Aac
Max. efficiency		94.5%
Power Factor		0.99
DC component		≤0.2A
Current harmonics		≤3%
Standard Interface	(	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232
Command Re- sponse Time	0.1ms	
Parallel Number	≤16	
Working Temperature	0 ~ 40°C	
Storage Temperature	-10°C ~ 70°C	
IP	IP20	
Isolation DC to GND	1600Vdc	
Isolation AC to GND	3500Vdc	
Cooling	Air	
Dimension ( mm)	767.62mm*483mm*106.9mm	
Weight( net)	30kg	



<sup>\*1:</sup> At low voltage input, the set power will decrease. For more information, please contact ITECH.



## 6.1.25 IT-M3906D-1500-12

Parameter		IT-M3906D-1500-12
	Voltage	0 ~ 1500V
	Current	0A ~ 12A
Rated value	Power	0W ~ 6000W
	Resistance in series ( CV priority )	0~1Ω
	Voltage	0.01V
	Current	0.001A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.01Ω
	Voltage	0.01V
Read Back Resolution	Current	0.001A
	Power	1W
	Voltage	≤0.03% + 0.03%FS
	Current	≤0.1% + 0.1%FS
Setup Accuracy	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS
	Voltage	≤0.03% + 0.03%FS
Read Back Accuracy	Current	≤0.1% + 0.1%FS
,	Power	≤0.5% + 0.5%FS
Voltago ripplo*1	Vp-p	≤1500mVpp
Voltage ripple*1	Vrms	≤150mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤30ms
Rise Time( full load )	Voltage	≤60ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time	Voltage	≤1ms



Parameter		IT-M3906D-1500-12
(change from 20% to 90% of rated current)		
Line Regulation	Voltage	≤0.01% + 0.01%FS
Line regulation	Current	≤0.03% +0.03%FS
Load Regulation	Voltage	≤0.01% + 0.01%FS
Load Negalation	Current	≤0.05% + 0.05%FS
	OCP	12.5A
Output protection	OVP	1515V
Output proteodion	Overpower protection	6120W
Remote Sense Compensation Voltage	≤15V	
	current program	External programming voltage 0V to 10V corresponds to current 0A to 12A
External analog (optional)	current monitor	Current 0A to 12A corresponds to external monitoring voltage 0V to 10V
	voltage program	External programming voltage 0 to 500V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 500V corresponds to external monitoring voltage 0 to 10V

#### Other parameters:

	Grid voltage range	3phase 200V ~ 480V
AC Input*2		Single phase 100V ~ 240V
	Frequency	50/60Hz
Max. apparent power	6.5kVA	
Max. input current	12.5Aac	
Max. efficiency	94.5%	
Power Factor	0.99	
DC component	≤0.2A	
Current harmonics	≤3%	
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232	



Command Re- sponse Time	0.1ms
Parallel Number	≤16
Working Temperature	0~40°C
Storage Temperature	-10°C ~ 70°C
IP	IP20
Isolation DC to GND	1800Vdc
Isolation AC to GND	3500Vdc
Cooling	Air
Dimension ( D*W*H )	744.22mm*459mm*56.81mm
Weight( net)	15kg



- \*1: The ripple is got under three-phase AC input.
  \*2: At low voltage input, the set power will decrease. For more information, please contact ITECH.

## 6.1.26 IT-M3912D-1500-24

Parameter		IT-M3912D-1500-24
	Voltage	0 ~ 1500V
	Current	0A ~ 24A
Rated value	Power	0W ~ 12000W
	Resistance in series ( CV priority )	0~1Ω
	Voltage	0.01V
	Current	0.001A
Setup Resolution	Power	1W
	Resistance in series ( CV priority )	0.01Ω
Read Back Resolution	Voltage	0.01V
	Current	0.001A
	Power	1W
Setup Accuracy	Voltage	≤0.03% + 0.03%FS



Parameter		IT-M3912D-1500-24
	Current	≤0.1% + 0.1%FS
	Power	≤0.5% + 0.5%FS
	Resistance in series ( CV priority )	≤1%FS
	Voltage	≤0.03% +0.03%FS
Read Back Accuracy	Current	≤0.1% + 0.1%FS
·	Power	≤0.5% + 0.5%FS
Voltage ripple	Vp-p	≤1500mVpp
voltage ripple	Vrms	≤150mV
Setup Temperature	Voltage	≤30ppm/°C
Coefficient	Current	≤50ppm/°C
Read Back Temper-	Voltage	≤30ppm/°C
ature Coefficient	Current	≤50ppm/°C
Rise Time( no load )	Voltage	≤30ms
Rise Time( full load )	Voltage	≤60ms
Fall Time( no load )	Voltage	≤1s
Fall Time( full load )	Voltage	≤100ms
Transient Response Time (change from 20% to 90% of rated current)	Voltage	≤1ms
Line Regulation	Voltage	≤0.01% + 0.01%FS
Line Regulation	Current	≤0.03% + 0.03%FS
Load Regulation	Voltage	≤0.01% + 0.01%FS
Load Negulation	Current	≤0.05% + 0.05%FS
	OCP	25A
Output protection	OVP	1515V
Cutput protoculon	Overpower protection	12240W
Remote Sense Compensation Voltage	≤15V	
External analog (optional)	current program	External programming voltage 0V to 10V corresponds to current 0A to 24A
	current monitor	Current 0A to 24A corresponds to external monitor- ing voltage 0V to 10V



Parameter		IT-M3912D-1500-24
	voltage program	External programming voltage 0 to 500V Corresponding voltage 0 to 10V
	voltage monitor	Voltage 0 to 500V corresponds to external monitor- ing voltage 0 to 10V

#### Other parameters:

AC loguet*1	Grid voltage range	3phase 200V ~ 480V	
AC Input*1	Frequency	50/60Hz	
Max. apparent power	13kVA		
Max. input current		25Aac	
Max. efficiency		94.5%	
Power Factor		0.99	
DC component		≤0.2A	
Current harmonics		≤3%	
Standard Interface	Standard: USB/LAN/CAN/IO Optional: GPIB/Analog&RS232		
Command Response Time	0.1ms		
Parallel Number	≤16		
Working Temperature	0~40°C		
Storage Temperature	-10°C ~ 70°C		
IP	IP20		
Isolation DC to GND	1800Vdc		
Isolation AC to GND	3500Vdc		
Cooling	Air		
Dimension ( mm)	660mm*437mm*87mm		
Weight( net)	30kg		



 $<sup>^{\</sup>ast} 1:$  At low voltage input, the set power will decrease. For more information, please contact ITECH.



## **6.27 Supplemental Characteristics**

State storage capacity: 10 sets

Recommended calibration frequency: once a year

Cooling style: fans



## 7 Routine Maintenance

This chapter describes the general maintenance items and maintenance methods of the device.

- ♦ Instrument Self-Test
- Cleaning and Maintenance
- Contact of ITECH Engineers
- Return for Repair

#### 7.1 Instrument Self-Test

Self-test checks that the minimum set of logic and power mesh systems are functioning properly. Self-test does not enable the output or place any voltages on the output. Self-test can be achieved in two ways:

- Re-start the instrument. Each time the instrument is powered on, the selftest is performed. This test assumes that the instrument is running.
- SCPI command: \*TST?. If the return value is 0, the self-test passes; if it is 1, the self-test fails. If the self-test fails, please send command SYSTem:ER-Ror? to view the self-test error. Please refer to *Programming Guide* for the list of error codes.



Ensure that all test cables connections are removed when self-test is performed. During self-test, errors may be induced by signals present on external wiring, such as long test leads that can act as antennae.

## 7.2 Cleaning and Maintenance

To ensure the safety function and performance of the instrument, please clean and maintain the instrument properly.



#### WARNING

- To prevent electrical shock, disconnect the instrument from AC mains power and disconnect all test leads before cleaning.
- Do not use detergent or solvents.
- Do not disassemble the instrument and attempt to clean internally.

Clean the outside and the front panel screen of the instrument using a soft, lintfree, cloth slightly dampened with water. Use a brush to clean the dust on the vent and cooling fans.

## 7.3 Contact of ITECH Engineers

This section describes operations to be carried out by the user in case of failure of the instrument.

#### Preparation before contact

When the instrument fails, you should make the following preparations before returning the instrument to ITECH for repair or contacting engineers.

- Check all the items listed in the Self-inspection of equipment faults and confirm whether there are still some problems.
- Collect the SN of the instrument.
   For details, see Collect the SN number.

If there are still some problems, carefully read the **Warranty** and **Limitation of Warranty** in the preface of the manual. Confirm that your instrument complies with warranty service conditions. If after your warranty expires, ITECH offers repair services at competitive prices.

#### Self-inspection of equipment faults

When the instrument fails, make the following checks to ensure that the failure is in the instrument rather than any external connections. If the instrument failure can be eliminated via simple inspection, the maintenance cost and time can be saved.

- Check whether the AC power cord is securely connected to the instrument and to a AC distribution panel.
- Check whether the front-panel Power On switch has been turned on.
- Check whether self-inspection of the instrument is successful and whether the specifications and performance are within the indicator ranges.



- Check whether the instrument displays error information.
- Use other instruments instead of this instrument for confirmation.

#### Collect the SN number

ITECH will constantly improve the product performance, availability and reliability. The service personnel of ITECH will record changes of each instrument. All relevant information is marked uniquely according to the serial number of each instrument. The equipment returned for repair must adopt the SN number as the tracking ID.

When you contact the engineer, the effective SN number of the instrument will be the effective guarantee for effective service and complete information. You can obtain the SN number of the instrument by the following ways:

- Enter the System menu to obtain the SN.
  - 1. Press the composite keys **[Shift]+[P-set]** (System) on the front panel to enter the system menu.
  - 2. Rotate the knob to select **System Info** and press **[Enter]** key.
  - 3. Rotate the knob to view the SN number.
    - Please record the SN number and provide SN information when doing maintenance service.
- View the barcode on the back panel of the instrument.

#### **How to contact ITECH engineers**

Access ITECH official website www.itechate.com or call the service number 4006-025-000 for technical support and services.

## 7.4 Return for Repair

If your instrument fails during the warranty period, ITECH will repair or replace it under the terms of your warranty. After your warranty expires, ITECH offers repair services at competitive prices. Also you can purchase an extended maintenance service contract that exceeds the standard warranty period.

#### **Get Repair Service**

To get the service for your instrument, choose the easiest way to contact the ITECH engineers. ITECH will arrange for repair or replacement of your instrument or provide warranty and repair cost information (if applicable).



#### Repackaging for Shipment

#### CAUTION

Never use styrene pellets in any shape as packaging materials. They do not adequately cushion the instrument or prevent it from shifting in the carton. Styrene pellets cause the instrument damage by generating static electricity and by lodging in the rear panel.

ITECH recommends that you retain the original shipping carton for return shipments and always insure shipments. To ship the unit to ITECH for service or repair:

- 1. Download the **ITECH maintenance service application** from our website, complete it and place it in the box with the instrument.
- 2. Place the unit in its original container with appropriate packaging material. If the original shipping container is unavailable, use a container that will ensure at least 10 cm (4 in.) of compressible packaging material around the entire instrument. Use static-free packaging materials.
- 3. Secure the container with strong tape or metal bands.



# **A** Appendix

- ◆ Specifications of Red and Black Test Cables
- ◆ Troubleshooting
- ◆ Fuse Replacement

## A.1 Specifications of Red and Black Test Cables

ITECH provides you with optional red and black test cables, which are sold individually and you can select for test. For specifications of ITECH test cables and maximum current values, refer to the table below.

Model	Specifica- tion	Length	Description
IT-E30110-AB	10A	1m	A pair of red and black test ca- bles with an alligator clip at one end and a banana plug at the other end
IT-E30110-BB	10A	1m	A pair of red and black test ca- bles with banana plugs at both ends
IT-E30110-BY	10A	1m	A pair of red and black test ca- bles with a banana plug at one end and a Y-terminal at the other end
IT-E30312-YY	30A	1.2m	A pair of red and black test ca- bles with Y-terminals at both ends
IT-E30320-YY	30A	2m	A pair of red and black test cables with Y-terminals at both ends
IT-E30615-OO	60A	1.5m	A pair of red and black test ca- bles with round terminals at both ends
IT-E31220-OO	120A	2m	A pair of red and black test ca- bles with round terminals at both ends



Model	Specifica- tion	Length	Description
IT-E32410-OO	240A	1m	A pair of red and black test ca- bles with round terminals at both ends
IT-E32420-OO	240A	2m	A pair of red and black test ca- bles with round terminals at both ends
IT-E33620-OO	360A	2m	A pair of red and black test ca- bles with round terminals at both ends

For maximum current of AWG copper wire, refer to table below.

AWG	8	10	12	14	16	18	20	22	24	26	28
The Maxi- mum Current Value (A)	60	40	30	20	13	10	7	5	3.5	2.5	1.7



- AWG (American Wire Gage), it means X wire (marked on the wire). The table above lists current capacity of single wire at working temperature of 30°C. For reference only.
- Along with temperature, you must also consider voltage drop when selecting wire sizes.

Although the instrument will compensate for the voltage in the wires, it is recommended to minimize the voltage drop as much as possible to prevent excessive power consumption from the instrument and poor dynamic response to load changes. Larger diameter wire sizes will help minimize wire voltage drops. Twisting or bundling wires will help reduce transient voltage drops.

### A.2 Troubleshooting

The fault information of this series of instruments is described below.



Term or abbreviation	Description	How to do
MODULE CHECK FAIL	Module detection failed	Re-check after
ECP	Current equalization protection	power-off restart. If it still fails to check, please contact
HARDWARE FAIL	Hardware fault	ITECH authorized dealer or ITECH technical support.
INH LATCH	Disable output, turn off the output.	For details, see 5.11.5 IO-5. INH-
INH LIVING	Disable output, turn on the output.	Living, Not-Invert.
UVP PROT	Undervoltage protection	For details, see 4.5
OVP PROT	Overvoltage protection	Protection Function for Power Supply.
OCP PROT	Overcurrent protection	lorr ower cupply.
OPP PROT	Over power protection	
UCP PROT	Undercurrent protection	
OTP PROT	Over temperature protection	
SENSE PROT	Sense abnormal protection	
SRVS PROT	Sense reverse protection	Reconnect the test
ORVS PROT	Output reverse connection protection	cables.
FIBER MULTI MASTER	Multi-master conflict	When multiple master unit are connected in parallel, multiple Masters are set in System menus. Just set 1 Master, and the other units are Slave.
FIBER EXT UNLOCK	The outer ring of the fiber is not locked.	Fiber multi-master parallel: set the parallel in the System menu in turn. For details, see 5.10



		Set Parallel Operation Mode (Parallel).
FIBER INNER UNLOCK	The inner ring of the fiber is not locked.	Please contact ITECH authorized dealer or ITECH technical support.
Fiber Locking / Networking	Optical fiber parallel error, parallel networking failure	Please contact ITECH authorized dealer or ITECH technical support.
POWER FAIL	Power down	Power on again
CURR SHARE FAIL	Current output unequalization	Check the specifications of the DUT
CAP OCP	Capacitor overcurrent	and reconnect the DUT. If the fault still occurs, please contact ITECH authorized dealer or ITECH technical support.

## A.3 Fuse Replacement

Different models of our company product are supplied with different fuse assembly. The way to replace the fuse changes accordingly. The common ways are as follows. Please choose the corresponding way of disassembly and replacement based on the fuse assembly of the actual instrument.



If there are no fuse assembly on the instrument rear panel, it means that you can't replace the fuse by yourself. Please contact the ITECH engineer on the condition of the same malfunction.



## The type of the fuse The way to replace 1. Use a screwdriver to push and turn the fuse box anti-clockwise. When turned to 90 degrees, release the screwdriver. Refer to the picture below. 2. The fuse box will bounce up, then you can see the fuse in it. Take out the blown fuse. 3. Please replace with a fuse of the same specification. Refer to the technical specification of the corresponding instrument. 4. When install, put into the fuse box as the picture below. Then use a screwdriver to push and turn the fuse box to 90 degrees clockwise. Refer to the picture below. The power cord jack of the instrument includes the fuse. Please refer to the rear panel introduction of the corresponding instrument for the detailed position. The replacement steps for this type of the fuse are as follows. 1. First pull out the power cord, and then take out the fuse block from the power cord jack with a small screwdriver, as shown below. 2. Have a visual inspection of the fuse to see whether it is burnt out; if yes, replace it with another fuse of the same specification. Refer to the corresponding technical specifications for fuse rating.



The type of the fuse	The way to replace
	After replacement, mount the fuse block to the original position, as illustrated below.
	<ol> <li>Push and turn the fuse box anti-clockwise by hand. When turned to 90 degrees, release the screwdriver.</li> <li>The fuse box will bounce up, then you can see the fuse in it. Take out the blown fuse.</li> <li>Please replace with a fuse of the same specification. Refer to the technical specification of the corresponding instrument.</li> <li>When install, put into the fuse box firstly. Then Push and turn the fuse box to 90 degrees clockwise.</li> </ol>



#### Connect with us

Thank you for purchasing ITECH products. Any questions, pls. feel free to let us know.

